

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

TABLE OF CONTENTS

<u>Section</u>	<u>Page</u>	<u>Topic</u>
1-1	8	Roles and Responsibilities of the Project Monitor
1-2		Characteristics of Asbestos and of ACM (AsbestosContaining Materials)
1-3		Health Effects of Asbestos Exposure
2	21	Asbestos Regulations
2-1		U.S. EPA Asbestos Regulations
2-2		OSHA Regulations
2-3		DPH Regulations
2-4		DOT Regulations
2-5		DEP Disposal Regulations
3	71	Understanding Facility Construction and Facility Systems; Renovations and the Effect of Asbestos Abatement on Facility Systems;
4	85	Asbestos Abatement Contracts, Specifications and Drawings; Common Enforcement Responsibilities and Authority of Project Monitor
5-1	94	Asbestos Abatement Equipment
5-2		Response Actions and Abatement Practices
6	119	Personal Protective Equipment
7	132	Air Monitoring
8	160	Safety and Health Issues Other Than Asbestos
9	168	Conducting Visual Inspections
10-1	175	Legal Responsibilities and Liabilities of Project Monitors
10-2		Record Keeping and Report Writing
11	191	Terminology and Selective Index

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

INITIAL TRAINING WORKSHOPS

Six (6) hours spread over three (3) days:

Workshop A contracts, specifications and drawings. Participant shall be issued a set of contracts, specifications, and drawings and then asked to answer questions and make recommendations to a project architect, engineer or to the building owner based on given conditions and these documents. A SAMPLE SPECIFICATION WILL BE HANDED OUT FOR THE WORK SESSION, BUT MUST BE RETURNED INTACT AT THE END OF THE SESSION.

(ii) Workshop B - air monitoring strategies and asbestos abatement equipment: simulated abatement sites for which sampling strategies would have to be developed e.g. occupied facilities, industrial situations. A SITE AT THE TRAINING CENTER WILL BE USED FOR DEMONSTRATION AND HANDS-ON TRAINING.

TRAINEES WILL SET UP DECON, CRITICALS AND NEGATIVE AIR UNITS AND, WHILE OPERATING, PERFORM PRESSURE AND FLOW CHECKS AND SELECT SAMPLING LOCATIONS FOR SIMULATED WORK AREAS AT THE TRAINING CENTER.

(iii) Workshop C - conducting visual inspections: an interactive video in which a participant is "taken through" a Work Area and asked to make notes of what is seen. A series of Questions will be asked which are designed to stimulate a person's recall of the area. A series of two or three videos with different site conditions and different degrees of cleanliness. A reasonable substitute may be used subject to the approval of the Department.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

COURSE OVERVIEW AND CURRICULUM

Required training for asbestos Project Monitors in Connecticut and other CONES States.

Five days of training totaling 40 hours and including at least 6 hours of Hands-on instruction and individual respirator fit testing for initial training courses and an annual one day refresher course.

Existing Licensed Project Monitors only need take 8- hr refresher training.

(A) Roles and responsibilities of the project monitor: definition and responsibilities of the project monitor, including regulatory/specification compliance monitoring, air monitoring, conducting visual inspections and final clearance monitoring; (Section 1)

(B) Characteristics of asbestos and asbestos containing materials: typical uses of asbestos; physical appearance of asbestos; review of asbestos abatement and control techniques; presentation of the health effects of asbestos exposure, including routes of exposure, dose-response relationships and latency periods for asbestos-related diseases; (Section 1)

(C) Federal asbestos regulations: overview of pertinent EPA regulations, including: NESHAP, 40 CFR Part 61, Subparts A and M; AHERA, 40 CFR Part 763, Subpart E and the EPA Worker Protection Rule, 40 CFR Part 763, Subpart G; overview of pertinent OSHA regulations, including: Construction Industry Standard for Asbestos, 29 CFR 1926.58 (now) 1101; Respirator Standard, 29 CFR 1910.134; Hazard Communication Standard, 29 CFR 1926.59 and Occupational Exposure to Asbestos, 29 CFR 1926.1101. applicable state and local asbestos regulations and regulatory interrelationships; (Section 2)

(D) Understanding facility construction and facility systems: facility construction basics and facility physical plant layout; understanding facility systems (HVAC, electrical, etc.); layout and organization, where asbestos is likely to be found on facility systems; renovations and the effect of asbestos abatement on facility systems;

(E) Asbestos abatement contracts, specifications and drawings: basic provisions of the contract; relationships between principal parties and establishing chain of command; types of specifications, including means and methods; performance and proprietary and nonproprietary; reading and interpreting records and abatement drawings; discussion of change orders; common enforcement responsibilities and authority of project monitor;

(F) Response actions and abatement practices: prework inspections; prework considerations, precleaning of the Work Area, removal of furniture, fixtures and equipment; shutdown/modification of facility systems; construction and maintenance of containment barriers and proper demarcation of Work Areas; Work Area entry and exit and hygiene practices; determining the effectiveness of air filtration equipment; techniques for minimizing fiber release, wet methods and continuous cleaning; abatement methods other than removal; abatement area clean-up procedures; waste transport and disposal procedures and contingency planning for emergency response;

(G) Asbestos abatement equipment: typical equipment found on an abatement project; air filtration devices, vacuum systems and negative pressure differential monitoring; HEPA filtration units, theory of filtration, design and construction of HEPA filtration units, qualitative and quantitative performance of HEPA filtration units, sizing the ventilation requirements, location of HEPA filtration units, qualitative and quantitative tests of containment barrier integrity and best available technology;

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

(H) Personal protective equipment: proper selection of respiratory protection; classes and characteristics of respirator types, limitations of respirators; proper use of other safety equipment, protective clothing selection, use and proper handling, hard or bump hats, safety shoes, breathing air systems, high pressure versus low pressure, testing for Grade D air and determining proper backup air volumes;

(I) Air monitoring strategies: sampling equipment, sampling pumps (low versus high volume), flow regulating devices (critical and limiting orifices) and use of fibrous aerosol monitors on abatement projects; Sampling media, types of filters, types of cassettes, filter orientation, storage and shipment of filters; calibration techniques, primary calibration standards, secondary calibration standards, temperature and pressure effects, frequency of calibration, recordkeeping and field work documentation and calculations; air sample analysis, techniques available and limitations of AHERA on their use, transmission electron microscopy (e.g. background to sample preparation and analysis, air sample conditions which prohibit analysis, EPA's recommended technique for analysis of final air clearance samples), phase contrast microscopy (background to sample preparation and AHERA's limits on the use of phase contrast microscopy) and what each technique measures; analytical methodologies, AHERA TEM protocol, NIOSH 7400, OSHA reference method (non clearance) and EPA recommendation for clearance (TEM); sampling strategies for clearance monitoring, types of air samples (personal breathing zone versus fixed-station area) , sampling location and objectives to include pre-abatement, during abatement and clearance monitoring, number of samples to be collected, minimum and maximum air volumes, clearance monitoring to include post-visualinspection (e.g. number of samples required, selection of sampling locations, period of sampling, aggressive sampling, interpretations of sampling results and calculations) and quality assurance; special sampling problems, crawl spaces, acceptable samples for laboratory analysis and sampling in occupied facilities such as barrier monitoring;

(J) Safety and health issues other than asbestos: confined-space entry, electrical hazards, fire and explosion concerns, ladders and scaffolding, heat stress, air contaminants other than asbestos, fall hazards and hazardous materials on abatement projects;

(K) Conducting visual inspections: inspections during abatement, visual inspections using the ASTM E1368 document; conducting inspections for completeness of removal and discussion of "how clean is clean?"

(L) Legal responsibilities and liabilities of project monitors: specification enforcement capabilities; regulatory enforcement; licensing and powers delegated to project monitors through contract documents;

(M) Recordkeeping and report writing: developing project logs and daily logs; what should be included and who sees them; final report preparation and recordkeeping under federal regulations;

(N) Workshops six (6) hours spread over three (3) days: See page 2.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Course Outline

Section 1-1 Roles and Responsibilities of the Project Monitor

- A. Definition of a project monitor.
- B. Responsibilities of the Project Monitor

Section 1-2 Characteristics of Asbestos and AsbestosContaining Materials

- A. Characteristics and Physical Appearance of Asbestos and ACM
- B. Typical Uses of Asbestos
- C. Review of Asbestos Abatement and Control Techniques

Section 1-3 Health Effects of Asbestos Exposure

- A. Nature of Asbestos Related Diseases
- B. Routes of Exposure to Asbestos fibers
- C. Synergistic effect between cigarette smoking and asbestos exposure
- D. Relationship Between Asbestos Exposure and Diseases
- E. Man-Made Mineral Fibers

Section 2-1 U.S. EPA Asbestos Regulations

- A. TSCA, Title II AHERA
- B. NESHAP
- C. ASHAA
- D. EPA Worker Protection Rule
- E. The 1982 Asbestos in Schools Rule:
- F. EPA Asbestos Bans
- G. ASHARA: Asbestos School Hazard Abatement Reauthorization Act

Section 2-2 OSHA Regulations

- A. Scope of OSHA Asbestos Standards:
- B. OSHA Construction Standard: (29 CFR 1926.1101)
- C. OSHA Hazard Communication Program for Construction (CFR 29 1926.59)
- D. Respiratory Protection Standard OSHA 29 CFR 1910.134
- E. Other Important OSHA Regulations Affecting Asbestos Abatement
- F. Required Written Safety and Health Plans/programs
- G. Negative Initial Exposure Assessment Summary

Section 2-3 DPH Regulations

- A. DPH Asbestos Standard: 19a 332-1-16
- B. Changes in DPH Asbestos Regulations This Decade:
- C. 1994 State Licensure Requirements:
- D. Licensing Requirements Sec. 20-440-1-7
- E. Asbestos in Schools: Connecticut General Statutes Sections 19a-333-11b
- F. Other States

Section 2-4 DOT Regulations

Section 2-5 DEP Disposal Regulations

CHEM SCOPE PROJECT MONITOR TRAINING

Updated 4/2/10

Section 3 Understanding Facility Construction and Facility Systems

- A. Physical Plant Layout
- B. Building Construction
- C. Facility Systems, Where ACM is Found
- D. Effect of Renovation and asbestos abatement on facility systems

Section 4 Asbestos Abatement Contracts

- A. Basic Provisions of the Contract
- B. Key Issues
- C. Relationships Between Principal Parties and Establishing Chain of Command
- D. Types of Specifications
- E. Reading and Interpreting Records and Abatement Drawings
- F. Change Orders
- G. Disagreements
- H. Common Enforcement Responsibilities and Authority of Project Monitor

Section 5-1 Equipment

- A. Equipment and Supplies Overview
- B. Determining the Effectiveness of Air Filtration Equipment

Section 5-2 Abatement Operations

- A. Asbestos Removal
- B. Abatement Methods Other Than Removal
- C. Other Control Methods
- D. Prework Considerations
- E. Techniques for Minimizing Fiber Release
- F. Waste Transport and Disposal Procedures Including Proper Clean-up
- G. Contingency Planning for Emergency Response

Section 6 Personal Protective Equipment

- A. Regulations Covering Respiratory Protective Equipment Covered in This Section
- B. Classes and characteristics of respirator types
- C. Limitations of Respirators
- D. Proper Respirator Selection
- E. Respirator Donning, Use, Maintenance, Inspection and Storage Procedures
- F. Qualitative Fit Testing Protocol Using Irritant Smoke (Stannic Chloride)
- G. Other Qualitative Methods
- H. Seal Check)
- I. Factors that Alter Respirator Fit and Cause Variability Between Field and Laboratory Protection Factors:
- J. Personal protective clothing

Section 7 Air Monitoring Strategies

- A. Sampling equipment
- B. Calibration techniques and Calculations
- C. Air Monitoring Recordkeeping and Field work Documentation and Calculations
- D. Air Sample Analysis, Techniques Available and AHERA Limitations on Their Use
- F. Sampling Strategies
- G. Collection of Area Samples (Fixed Station Samplers)
- H. Special Sampling Problems
- I. Interpretation of Results and Calculations
- J. Quality Assurance

CHEM SCOPE PROJECT MONITOR TRAINING

Updated 4/2/10

Section 8 Safety and Health Issues Other Than Asbestos

- A. Electrical Safety
- B. Ladder safety (see OSHA 29 CFR 1926.450)
- C. Scaffold safety (See OSHA CFR 29 1926.450-454 Amended 8/30/96)
- D. Fire (and explosion) Safety
- E. Heat Related Disorders
- F. Chemical and biological hazards / Contaminants other than Asbestos
- G. Slips Trips and Falls
- H. Power tools (see CFR 29 1926.302. for electric and pneumatic power tools)
- I. Control of Hazardous Energy Lockout/Tagout (see CFR 29 1910.147)
- J. Supplied air respirators- carbon monoxide
- K. General construction hazards from falling objects
- L. Confined spaces
- M. Other Hazards
- N. Lead Dust on Asbestos Jobs

Section 9 Conducting Visual Inspections According to the ASTM E1368 Document

- A. Inspections During Abatement
- B. Inspections After Abatement
- C. How Clean is Clean
- D. Completeness of Encapsulation
- E. Completeness of Enclosure
- F. Review of Final Clearance Process

Section 10-1 Legal Responsibilities/Project Monitor Enforcement Capabilities

- A. Project Monitor Responsibilities
 - 1. DPH Regulations Authorizing Legal Responsibility and Liability
 - 2. General Project Monitor Duties
 - 3. Enforcement of Contractor Duties
 - 4. Personal Inspection and Measurements (Besides air samples)
 - 5. Optional during Work Background Air Monitoring (daily monitoring)
 - 6. Post Abatement Testing
 - 7. Contingency Procedures for Air Sample Non-Compliance
 - 8. Final Report Preparation and Recordkeeping
- B. Owner Responsibilities
- C. Liability Types
- D. Insurance

Section 10-2 Records

- A. Paperwork Copies the Project Monitor Must Bring With Him to the Project
- B. Paperwork Copies Project Monitor Must Collect and/or Develop at the Project
- C. AHERA Required O&M Work Records for Schools

Section 11 Terminology and Selected index

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

SECTION 1

1-1 ROLES AND RESPONSIBILITIES OF THE PROJECT MONITOR

A. DEFINITION OF A PROJECT MONITOR.

- 1. Any licensed individual who functions as an on-site representative of the facility owner or other persons by over-seeing the activities of the asbestos abatement contractor.**
- 2. One of the disciplines of "Asbestos consultant" which means a certified and licensed individual who engages in any activity involving asbestos abatement consultation services: inspector; management planner; project designer or project monitor.**

B. RESPONSIBILITIES OF THE PROJECT MONITOR

- 1. Regulatory/specification compliance enforcement (See Section 10-1)**
- 2. Air monitoring (See Section 7)**
- 3. Conducting visual inspections (See Section 9)**

A person who conducts a visual inspection in a facility to determine whether a response action is complete need not be licensed as an inspector, but shall be a licensed Project Monitor.

- 4. Final clearance monitoring. (See Section 7)**
- 5. Project Monitor Scope of Licensure:**

Licensure as a Project Monitor authorizes the asbestos consultant to:

- a. Function in the capacity of on-site representative of the facility owner or other persons,
- b. Interpret project specifications or abatement management plans
- c. Monitor and evaluate contractor or employee compliance with applicable regulations or specifications and
- d. Ensure that abatement projects are properly conducted and completed.

6. Conflict of Interest:

The Project Monitor shall not function as the asbestos contractor, or as an employee of the asbestos contractor on the same asbestos abatement project.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

7. Qualifications. Per DPH (CT Dept. of Public Health)

a. Applicants shall hold either a bachelor's degree from a regionally accredited institution in engineering, architecture, industrial hygiene or a scientific field determined by the commissioner to be closely related or an associate's degree from a regionally accredited institution in biology, chemistry or a scientific field determined by the commissioner to be closely related. (30 semester hours of math and science). Applicants shall have a minimum of one (1) year experience in asbestos abatement, including experience in asbestos abatement project monitoring or six (6) months field experience under the supervision of a licensed Project Monitor.

b. Applicants shall have successfully completed the training requirements as set forth in subdivision 20-440-6(c)(7) of the DPH regulations:

- 1) 5 day initial Project Monitor course and annual refresher Project Monitor course
- 2) 1 day refresher course for existing licensed project monitors.

c. Exemption.

An individual who between July 1, 1985 and November 1, 1994, has been employed for a minimum of two (2) years as an asbestos consultant may be licensed as an asbestos consultant without the bachelor's degree, provided the applicant has met all other DPH requirements.

There is a much more detailed discussion of the Project Monitor's Legal Responsibilities in Section 10 of this manual which will be more meaningful after the rest of the course presentation.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 1-2

Characteristics of Asbestos and AsbestosContaining Materials

KEY WORDS:

ACM = Asbestos Containing Material, loosely used to mean ACBM.

ACBM = Asbestos Containing Building Material

TSI = Thermal system insulation

Friable ACM: ACM that can be crumbled, pulverized or reduced to powder when dry by hand pressure and which releases Asbestos fibers into the environment.

Non-friable: ACM normally not friable but which can become friable with disturbance or wear.

A. CHARACTERISTICS AND PHYSICAL APPEARANCE OF ASBESTOS AND ACM

1. Naturally occurring fibrous silicate minerals.

2. Fibrous forms:

- a. Parallel bundles of minute fibers.
- b. Smaller bundles called "fibrils."
- c. Minute individual fibers.
- d. Perfect lengthwise cleavage
- e. Length-to-width ratio typically > 10:1

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. There are 6 asbestos fibrous mineral forms: 1 serpentine form and 5 amphibole forms.

a. Chrysotile (Serpentine)- Most common form of asbestos

- 1) White Asbestos
- 2) Wavy fibers
- 3) Wettable
- 4) Considered the least dangerous type of asbestos
- 5) 93 percent of total domestic Asbestos products

b. Amphiboles -Less common, more dangerous forms, straight rigid fibers:

- 1) Amosite
 - a) Brown Asbestos
 - b) Brittle fibers
 - c) High resistance to heat.
 - d) 5% of asbestos used
- 2) Crocidolite -
 - a) Blue Asbestos
 - b) 2% of asbestos used
 - c) Acid resistance
- 3) Anthophyllite rare white form
- 4) Actinolite rare green form
- 5) Tremolite rare white form

Note: Actinolite and tremolite usually occur together.

4. Non-fibrous Forms

a. Not considered dangerous

b. Most common is non-Fibrous actinolite or actinolite-tremolite.

c. Not regulated by most agencies but due to lack of updating regulations, sometimes non-Fibrous forms are included in the definition.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

5. Laboratory Analysis to Identify ACM

- a. PLM (polarized light microscopy)
- b. **NIST (National Institute of Standards and Technology) Accredited PLM Lab**
- c. > 1 % asbestos = ACM

6. Useful Properties

Thermal insulating ability	Inexpensive
Virtually indestructible	Mechanical strength
Chemical resistance	Flexibility
Fire resistance	Friction and wear characteristics
Wet strength	Acoustical properties

7. Aerodynamic Characteristics and Settling Time

- a. Number of fibers per unit weight or volume is astronomical
- b. Shape of fibers and light weight promotes entrainment into the air with little force.
- c. Long, slender and thin fibers. To be demonstrated using the microscope.
- d. More stable Chrysotile vs more volatile Amphiboles
- e. Air Entrainment occurs when ACM is worn or not intact.
- f. Chemicals used in asbestos abatement are designed to weigh-down the fibers. These chemicals include water with surfactants and removal encapsulants.
- g. When water is used to wet asbestos, the asbestos can become airborne again when dry.
- h. Fibers may remain suspended in air indefinitely with moderate air movement, can spread throughout a building on air currents.
- i. Any kind of force such as cutting, abrasion, vibration, erosion by wind, forced air, or general aging and weathering can cause air entrainment.
- j. Even in the absence of air movement, fibers may take days to settle.

B. TYPICAL USES OF ASBESTOS

1. General Information:

- a. 3,600 products since the early 1900's.
- b. 90,000 tons of asbestos used in the USA in 1989 compared to 900,000 tons in 1973.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Asbestos Cement Products: "Transite"

- a. 65 % of all asbestos used, a hard and tough flexible cement sheet or rolled material
- b. Two major forms:
 - 1) Flat or corrugated sheets
 - a) Siding
 - b) Tiles
 - c) Insulating board
 - 2) Pipe
 - a) Rainwater drains
 - b) Gutters
 - c) Pressure piping including water mains = largest single use.

3. Major Building Uses of Asbestos:

- a. Flooring: Found in finished areas, generally non-friable
 - 1) Vinyl floor tiles and linoleum, top layer or felt backing (up to about 1989)
 - 2) Mastic - used for vinyl flooring or carpets. Asbestos still may be used- check labels and MSDS's (Material Safety Data Sheets)
- b. Thermal Insulation: Generally considered friable.

Pipes, ducts and vessels: Rarely used after 1980. Retards heat loss or gain.
 - 1) Boiler rooms
 - 2) Other mechanical rooms
 - 3) Steam tunnels
 - 4) Pipes and HVAC (heating, ventilation and air conditioning) ducts throughout building leading to radiators, registers, sinks and other fixtures
- c. Fireproofing and Condensation Control:
 - 1) Surfacing on steel beams and decking: Rarely used after 1980. Delay or prevent collapse of structures in fires.
 - 2) Applied to steel and concrete to minimize condensation.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

d. Acoustical:

- 1) Used extensively prior to the 1970's.
- 2) Surfacing on ceilings and sometimes walls: Rarely used after 1980.
- 3) Ceiling tiles and panels

e. Roofing:

- 1) Shingles- Rarely used after 1980.
- 2) Felts used in Flashing or Built up roof- Rarely used after 1980.
- 3) Tar portion of flashing or built up roof is frequently asbestos through the 90's.

f. Transite panels:

Rarely used after 1980. Frequently seen behind radiators and in siding

g. Electric cable insulation and lighting fixtures

h. Glues and putties - frequently have asbestos through the 90's.

i. Preformed boards

4. Special Building Uses:

a. Amosite: High temperature applications

- 1) Steam boilers and lines
- 2) Exhaust fire boxes
- 3) Power plants generating high pressure steam.

b. Crocidolite: Very resistant to acids and to outdoor exposure.

c. Chrysotile and crocidolite are used in Asbestos textiles and filtration products.

d. Anthophyllite, actinolite, and tremolite are used primarily in adhesives and cements. They are too brittle for textile products or for use as fibrous reinforcement.

5. Major Non - Building Uses:

- a. Brake linings and clutch facings
- b. Gaskets
- c. Reinforced plastics.
- d. Appliances

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

6. Categories of Asbestos Containing Building Materials (ACBM)- Suspect Materials

a. Surfacing

Material that is sprayed-on, troweled-on, or otherwise applied to surfaces, such as acoustical plaster on ceilings and fireproofing materials on structural members, or other materials on surfaces for acoustical, fireproofing, or other purposes.

b. Thermal System Insulation (TSI)

Material applied to pipes, fittings, boilers, breeching, tanks, ducts or other interior structural components to prevent heat loss or gain, or water condensation, or for other purposes.

c. Miscellaneous Materials

ACM or ACBM other than surfacing or TSI, such as transite, floor and ceiling tiles, roofing, mastics, tars, putties, glues, caulks, preformed sheets, etc.

7. Assumptions

a. Any suspect material may be assumed to contain asbestos.

b. Non-suspect materials such as modern fiberglass, metal, wood, and glass may be assumed to not contain asbestos.

C. REVIEW OF ASBESTOS ABATEMENT AND CONTROL TECHNIQUES

1. There is a detailed discussion of abatement techniques in Section 5-2 including:

- a. Removal
- b. Encapsulation
- c. Enclosure
- d. Repair

2. In principle the techniques rely on the following:

- a. Wet methods to make the fibers heavy
- b. **HEPA (high efficiency particulate air)** filtration and air flow control to trap fibers.
- c. Containment Practices and negative pressure inside the Work Area to keep fibers inside the Work Area.
- d. Personal protection measures including hygiene and decontamination practices, to protect workers and prevent tracking asbestos out of the Work Area.
- e. Isolation of Work Area with barriers to keep unauthorized people out.
- f. Air Monitoring to detect fibers in air.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 1-3

Presentation of the Health Effects of Asbestos Exposure

INTRODUCTION:

The adverse health effects from Asbestos exposure were first described in the early 1900's. Nevertheless, widespread concern about Asbestos developed only recently as a result of the extensive health problems that have emerged among people who were heavily exposed during and immediately after World War II.

Repeatedly breathing large amounts of Asbestos is associated with Asbestosis, increased risk of lung cancer and mesothelioma.

Individuals vary considerably in their ability to withstand disease. Asbestos fibers can produce a fatal disease in one person, and yet leave no marks on a colleague working nearby. Preventive measures must be adequate to protect all including those most likely to develop disease.

Asbestos fibers in the air are not visible to the naked eye and there is no odor, irritation or other tangible signs of exposure. Only sophisticated air sampling and analysis using microscopic methods can detect the presence of these fibers.

The mere presence of Asbestos materials in a building should not produce airborne fibers as long as the material is maintained in a secure wrapping or binder and otherwise maintained in good condition. Release of Asbestos into the air in occupied areas must be carefully avoided. Exposures to Asbestos in buildings may occur upon wear or damage and is often due to improperly handling the material and permitting fibers to become airborne. Once inhaled, Asbestos fibers may enter the lungs and last indefinitely there.

**A. NATURE OF ASBESTOS RELATED DISEASES;
DOSE RESPONSE RELATIONSHIPS, LATENCY PERIODS AND THE LACK OF A SAFE EXPOSURE
LEVEL**

KEY TERMS:

Dose-Response relationship -

A principle in toxicology wherein increases in the dose, or exposure, result in proportional increases in the response, or effects.

Latency Period -

Length of time between exposure to a toxic substance and the onset or appearance of resultant disease. Asbestos-related diseases have relatively long latency periods.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

1. Major Diseases:

a. Asbestosis:

- 1) Scarring of the lung tissue seen on x-ray, a form of pulmonary fibrosis. A form of pneumoconiosis, which is a generic name for lung diseases caused by inhalation of dusts.
- 2) Associated with breathing large amounts of asbestos.
- 3) A restrictive lung disease. When fibers lodge in the alveoli, the resultant scarring results in decreased surface area, thereby reducing the lung's ability to oxygenate the blood. Also, as the lung's ability to expand and the breathing capacity are reduced, patients become short of breath.
- 4) A progressive lung disease, which means that it can progress even after exposure is discontinued. If the disease process is advanced, it can cause disability and death.
- 5) Prevention and early detection include chest x-rays, pulmonary function tests and exposure history.
- 6) The latency period for Asbestosis is 5 - 10 years with very heavy exposure. Otherwise it may be 20 - 40 years.

b. Lung Cancer: - abnormal cell growth

- 1) Asbestos is a known human carcinogen.
- 2) Generally, a dose-response relationship exists: the risk of disease increases in direct proportion to the increase in Asbestos exposure.
- 3) However, for lung cancer, there is no known threshold, or "safe" dose, at which it can be said that the risk of this response, lung cancer, is zero.
- 4) Latency period > 15 years, with a peak at 30-35 yrs.

c. Mesothelioma: -

- 1) A rare form of cancer of the pleural cavity or peritoneal cavity, associated only with Asbestos exposure.
- 2) An essentially incurable form of cancer.
- 3) Mesothelioma tumors are the uncontrolled growth of cells in the lining of the chest cavity (called the pleura) in between the chest walls and the lungs, or in the lining of the abdominal cavity (called the peritoneum).
- 4) Associated with low levels of Asbestos exposure.
- 5) Latency period for mesothelioma is up to 40 years.
- 6) Usually fatal within 1-2 years after diagnosis.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Minor Occurrence of Diseases:

a. Other Cancers- (Less common).

1) Gastrointestinal tract or digestive tract due to the ingestion of Asbestos fibers.

- a) Esophagus
- b) Stomach
- c) Colon

2) Vaginal (very rare)

3) With early detection, these types of cancers can be curable.

b. Pleural Diseases - Less Serious Disease,

Thickening or scarring of the pleural tissues which normally have no serious health effect but indicate Asbestos exposure

B. ROUTES OF EXPOSURE TO ASBESTOS FIBERS.

1. Lung diseases caused by inhalation (breathing)

a. Lungs continuously exposed to vapors and suspended particulate matter.

b. Defenses: Most particles, including Asbestos fibers, are trapped and eliminated by the defense mechanism.

1) Breathing passages lined with a sticky mucous layer that traps small particles.

2) Cilia line the bronchial tubes. These are hair-like projections that continuously move the mucous layer toward the mouth.

c. Some Asbestos fibers can be carried along in the air, down the bronchial tubes, and lodge in the lung tissue where they may remain and incite a reaction in the surrounding lung tissue.

d. Some fibers break into small fragments and are eliminated from the body.

e. Other fibers migrate to the mesothelial lining. These retained fibers trigger tissue defense reactions and create lung disease.

2. Less common gastrointestinal diseases caused by ingestion.

a. Ingestion means to take into the gastrointestinal system. May include eating or indirectly by swallowing fibers that were inhaled.

b. Asbestos can contaminate food, water or other beverage

c. Residues of asbestos on the skin may result in this extra exposure by hand to mouth activity.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

C. SYNERGISTIC EFFECT BETWEEN CIGARETTE SMOKING AND ASBESTOS EXPOSURE;

1. Synergistic effect means the combined, or multiplicative, effect of two factors wherein the whole is greater than the sum of its parts.
2. Incidence of lung cancer is much higher among smokers who were also exposed to Asbestos:
3. Smokers not exposed to Asbestos ten times that of non-exposed, non-smokers.
4. Non - smokers exposed to asbestos have a risk of approximately five (5) times that of non-exposed, non-smokers.
5. Combination (synergistic) effect, among smokers who are also exposed to Asbestos, is 50 - 90 times that of non-exposed, non-smokers.
6. Cigarette smoke has numerous other adverse effects.
7. Cigarette smoke deactivates the cilia.
8. Extrapolation: Conclusions above about the synergistic effect have been extrapolated from data at high exposures to risk assessments for low exposures.
9. Greater lung cancer risk for smokers exposed to asbestos
10. Mesothelioma: No synergistic effect known.
11. Stop smoking and risk of lung cancer can decrease to close to that of a non-smoker.

D. RELATIONSHIP BETWEEN ASBESTOS EXPOSURE AND ASBESTOSIS, LUNG CANCER, MESOTHELIOMA, AND CANCER OF OTHER ORGANS.

1. Signs of exposure to Asbestos:

No way to tell except by:

Personal air monitoring or

Knowing that Asbestos is being disturbed in the area.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Relative Hazards of Asbestos Types

- a. All agree that the amphibole types are dangerous.
- b. Generally accepted that chrysotile Asbestos is less dangerous than amphiboles.
- c. Other important factors known are the fiber length and diameter which combined with the long latency make it extremely difficult to draw conclusions.
- d. The most prudent approach is to treat all forms of Asbestos with due care and minimize exposure.
- e. One point is generally agreed on: Crocidolite and amosite are more dangerous than chrysotile
- f. Much controversy over Chrysotile. some say it is harmless; some say just as bad as amphibole type asbestos.

3. Fiber size and shape:

- a. Fibers longer than 5 microns and thinner than 0.5 microns appear to be more carcinogenic than shorter and thicker fibers.
- b. Fibers longer than 8 microns are not generally respirable and much less dangerous.
- c. Therefore, thin fiber between 5-8 microns are the worst.

E. MAN-MADE MINERAL FIBERS

- 1. Fiberglass, Mineral Wool and Refractory Ceramic Fibers may be linked with lung cancer.**
- 2. Mineral wool (rock wool) according to EPA is a probable human carcinogen and fiberglass is a possible human carcinogen.**
- 3. These man-made mineral fibers do not appear to be as toxic as asbestos, which is a known human carcinogen.**
- 4. OSHA regulates airborne exposure to man-made mineral fibers. There are monitoring and respirator requirements. Can be tested by NIOSH 7400.**
- 5. There is a NIOSH guideline for glass fibers of about 2 f/cc.**
- 6. OSHA standards are expressed in mg/m³ (mg of dust/cubic meter of air). The OSHA permissible exposure limit (PEL) for total particulate matter in air for nuisance dust is 15 mg/m³ if the matter has <1% asbestos.**
- 7. Established ACGIH limits for mineral wool are in the classification of nuisance dust with a Permissible Exposure Limit of 10 Mg/m³.**

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

SECTION 2

ASBESTOS REGULATIONS

Key points are presented from selected regulations. The professional Project Monitor should read the entire regulation referenced and be familiar with other existing regulations. Regulations vary in scope but overlap considerably. Some regulations are more detailed or are stricter than other regulations on certain requirements. Where regulations differ, the strictest provision must apply.

In this section, we examine some of the pure aspects of each regulation; in other sections the combined requirements are woven together. This creates some duplication in the text, but it is important for the student to know the source of each requirement. In addition, some new terms are presented which are explained more fully in sections to follow.

Section 2-1

U.S. EPA Asbestos Regulations

A. TSCA, TITLE II AHERA ASBESTOS HAZARD EMERGENCY RESPONSE ACT

40 CFR 763 subpart E, Oct 1986, Asbestos in Schools Rule.

1. Synopsis:

- a. Covers Schools public or private grades k-12
- b. Inspections required for friable and non-friable ACBM every 3 years.
- c. Management plans required for all schools
- d. Response actions must be implemented which will "protect human health and the environment".
- e. EPA Accreditation required for individuals: Abatement Workers; Supervisors and Monitors; Inspectors; Management Planners, and Project Designers.
- f. LEA must have a "designated person"
- g. 2 hr awareness training for custodial and maintenance workers within 60 days of hire.
- h. Signs in routine maintenance areas.
- i. Can assume materials are ACBM or collect bulk samples of materials and submit to NIST Accredited Lab for PLM analysis. Damaged assumed ACBM must be tested
- j. Periodic Surveillance every six months and Annual notification to PTO.
- k. Rigorous recordkeeping requirements.
- l. DPH regulation 19a-333-1-13 include all of the AHERA requirements plus a few more; a copy of this DPH regulation is in the handout on W.W.W.Chem-scope.com.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Requirements for School Inspections: by licensed inspector

- a. Visual inspection
- b. Materials Not Included in AHERA Inspections:
 - 1) Stored material
 - 2) Concrete
 - 3) Cinder block
 - 4) Blackboards
 - 5) Pressed wood
 - 6) Carpets
 - 7) Curtains
 - 8) Table and desk tops
 - 9) Chemical lab gloves and other fire resistant equipment
 - 10) Exterior roofing and most other exterior materials
- c. Identify all homogeneous areas of friable and non-friable suspected ACBM.
- d. Assume ACBM or sample.
- e. Assess friable ACBM.
- f. Prepare Inspection Report and Management Plan.

3. Asbestos Abatement Projects Records:

See Section 10-2

Records of abatement projects at schools have a high chance of being inspected by DPH within 2 years of the project.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

B. NESHAP

National Emission Standards for Hazardous Air Pollutants.

40 CFR Part 61 Subparts A (general) and M (Asbestos). Clean Air Act,

Covers practically all facilities, activities and buildings except some residential.

1. Main Subparts:

a. Subpart A includes parts 61.01 -.19 which are of general nature and apply to asbestos and 32 other Hazardous Air Pollutants.

b. Subpart M deals with Asbestos and consists of parts 140-157. The original part M was effective March 31, 1971. There were major amendments effective on November 20, 1990.

61.140 Applicability

61.141 Definitions

61.142 Asbestos mills

61.143 roadways

61.144 manufacturing

61.145 Demolition and Renovation

61.146 spraying

61.147 fabricating

61.148 insulating materials

61.149 waste disposal from asbestos mills

61.150 waste disposal from manufacturing, fabricating, demolition, renovation and spraying

61.151 inactive disposal sites for asbestos mills, manufacturing, and fabricating.

61.152 air cleaning

61.153 reporting

61.154 active waste disposal sites

61.155 waste conversion

61.157 delegation of authority

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Requirements of Subpart M:

a. **Homes with 4 or less units** exempted from regulation, unless a number of homes are done as part of the project or a home had former non-residential usage.

b. **MUST inspect for asbestos prior to any demolition or renovation project**

c. **PLM is official test method.**

d. Many special definitions including:

Demolition means any work involving taking out load supporting building members or intentional burning.

Renovation means altering a facility component in any way including stripping of asbestos.

Category 1 non-friable asbestos means resilient flooring, asphalt roofing, gaskets, and packings > 1% asbestos by PLM.

Category 2 non-friable asbestos means any other non-friable material with > 1% asbestos by PLM.

Regulated asbestos containing material (RACM) means any of the following:

- 1) Friable asbestos
- 2) Category 1 asbestos which has become friable
- 3) Category 1 asbestos which is subject to sanding, grinding, saw-cutting or abrading.
- 4) Category 2 asbestos which has a high probability of becoming pulverized, crumbled or reduced to powder during the demolition or renovation work.

In other words RACM means asbestos which is friable or likely to become friable.

3. Notification Requirements Effective 10/1/97: in Maine, NH, Mass and CT.

Normal state DPH asbestos notifications (in CT of 10 calendar days or emergency notifications) satisfy NESHAP requirements and EPA does not also need to be notified. However, failure to notify DPH will also subject the party to EPA violation.

(In other states, one still must notify EPA directly.)

Note: Effective about June 2004, DPH requires notification of all demolitions.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Normal EPA Notification Requirements (exclusive of item 3 above)

Note: These would apply in other states than above.

Note: For States listed in item 5, it is only necessary to follow the State notification requirements to comply with NESHAP, regardless of the EPA requirements below.

a. For projects involving any demolition or renovation which may disturb more than 260 linear ft or 160 Sq ft of RACM:

1) Prepare and submit 10- (weekday) notification forms required by the USEPA.

2) Submit forms to:

USEPA, Region 1
Air and Management Division
J F Kennedy Federal Building
Boston MA 02203
(617) 565-3273

b. Remember, for demolition, notification is required even if no asbestos is involved.

c. If amount of RACM changes by 20% or more, a revised notice is needed.

d. If start date of project changes, a revised notice is needed.

e. Blanket notification for the year:

If a series of jobs is expected to be done at a site in the course of the year and the total RACM work is >260 lin ft or 160 sq ft, a blanket notification may be sent for a calendar year by about 12/15 of the year preceding. Must notify by the next day of each individual job.

1) Non-scheduled renovation: A series of jobs is expected because of routine equipment failure.

2) Planned renovation: A renovation operation or a series of renovations at a site where RACM will be occasionally stripped within a year.

f. Emergency renovation: Must result from a sudden unexpected event that, if not taken care of, poses a hazard or may cause damage or an unreasonable financial burden. Must notify by the next day.

5. Emission controls.

a. No visible emissions

b. Wet removal

c. Material drop restrictions

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

6. Waste disposal manifests

- a. **Label each waste bag** with site and generator name in addition to the usual OSHA labeling.
- b. **EPA Approved Landfill**
- c. Waste vehicle labeled during loading and unloading
- d. EPA must be notified if the dump receipt is not received within 45 days of the manifest date.

7. NESHAP Training certification posted on site

8. RACM must be removed:

- a. Before demolition or renovation if friability is possible. Removal required before disturbance or dislodging will result or
- b. If the work precludes future removal.

Note: In some cases, non-regulated asbestos may be left in the affected area before demolition or renovation but the follow up work for waste disposal may be enormous since contaminated parts of the structure must be disposed of or the asbestos sorted out after demolition. These sites should be evaluated on a case by case basis. For interior asbestos, because of CT and OSHA regulations, it is usually necessary to properly remove the asbestos before disturbance.

9. Unexpected Asbestos:

There must be a plan to handle unexpected RACM which is exposed during a project. If the unexpected RACM becomes part of the rubble, then all contaminated rubble must be properly disposed of.

10. Interaction with State and OSHA regulations:

- a. The NESHAP regulation potentially relaxes standards for Category 1 asbestos which would be significant if state regulations are relaxed.
- b. Other fine points of the regulations are in line with existing state or OSHA regulations and not mentioned here.

C. ASHAA

1. The Asbestos School Hazard Abatement Act of 1984.

2. Congress adopted it as a mechanism to fund schools and for initial funding of EPA Asbestos Information Centers

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

D. EPA WORKER PROTECTION RULE

1. 40 CFR part 763 subpart G, 1987.
2. For public sector employees not otherwise covered by OSHA, including school employees.
3. Same requirements as the old OSHA asbestos standard, 29 CFR 1926.58. (Will be undergoing revisions to match 29 CFR 1926.1101.

E. THE 1982 ASBESTOS IN SCHOOLS RULE:

1. Required inspections for friable ACBM only
2. Required notification of employees and PTAs and posting of notices.
3. No requirement for management plans or response actions

F. EPA ASBESTOS BANS

1. 1970:

Spraying of commercial Asbestos products and the use of ACM pre-molded or wet-applied thermal insulating products.

2. 1989

Was put on hold due to court stay

3. 1993:

- a. Ban of 1989 is still on hold due to legal ramifications.
- b. Prohibition of new uses or resumption of uses stopped.
- c. Labeling requirement.

4. Despite Bans,:

- a. Still possible to encounter asbestos in new building materials. Especially glues, tars, mastics and putties. See page 79 for example.
- b. Make sure the building owner knows to specify asbestos free materials in new installations and to check the MSDS'

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

G. ASHARA: Asbestos School Hazard Abatement Reauthorization **Act 40 CFR Part 763 Subpart E, Appendix C.**

1. Synopsis:

- a. This regulation requires extension of **EPA Accreditation requirements to public and commercial buildings** for individuals doing asbestos inspection, project design and abatement. Individuals doing more than one task must be EPA Accredited in each discipline. A Model Accreditation Plan (MAP) is included with this regulation which, as adopted by DPH, defines the syllabus of approved asbestos courses.
- b. There are also increased training requirements compared to the original AHERA regulation.
- c. The proposed EPA regulations were published in May of 1992. The effective date was to be 11/28/92, but the final rule was published on 2/3/94 and really **effective 4/3/94**.
- d. Licensing and training requirements in many states such as CT reinforce this regulation and generally follow the MAP. Some states are stricter.

2. Applicability:

Public and commercial buildings which means All buildings other than schools and residential with < 10 units.

3. Principal Changes in Training Requirements Compared to AHERA:

- a. Separate worker and contractor courses for initial and refresher. (Can no longer upgrade workers by taking an additional day.) (5 day contractor/supervisor and 4 day worker.)
- b. Increased Hands-on training to:
 - Worker 14 hrs (from 6)
 - Supervisor 14 hrs (from 6)
 - Inspector no change still 4 hrs
- c. Changes in Curricula:
 - 1) Worker training:
 - Minor additions and deletions. Add a discussion of the relationship of exposure to asbestosis, lung cancer, mesothelioma and diseases of other organs.
 - Some wording changes in the employee personal protective equipment and work practices training.
 - 2) Con/Sup training:
 - Air monitoring: add EPA's recommendation that TEM be used for final air samples and a NIST Accredited lab be used.
 - Minor wording changes.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3) Inspector:

Under Bulk Sampling:

Add EPA's Recommendation that a NIST Accredited PLM lab be used.

Under Recordkeeping: Add EPA's Recommendation that standardized forms be used for recording inspection results for schools and for public and commercial buildings.

4) Management Planner:

Not a required but a recommended EPA Accreditation for public and commercial buildings.

Add a recommendation that standardized forms be used for recording inspection results for schools and for public and commercial buildings. And add the forms to the curriculum.

5) Project Monitor:

Not required by EPA. States are allowed to adopt the MAP for this discipline.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 2-2

OSHA Regulations

A. SCOPE OF OSHA ASBESTOS STANDARDS:

1. OSHA Construction STANDARD: (29 CFR 1926.1101; formerly 1926.58):

- a. Coverage under a standard is determined by the work operation and not on the primary activity of the employer.
- b. All construction-related work which may disturb asbestos including general industry applications of any of the following:
 - 1) Demolition
 - 2) Removal
 - 3) Encapsulation
 - 4) Construction
 - 5) Alteration
 - 6) Repair
 - 7) Maintenance and custodial work
 - 8) Renovation
 - 9) Installation
 - 10) Emergency clean-up
 - 11) Transportation, disposal or storage
 - 12) Excludes asphalt roof coatings, roofing cements and roofing mastics. (includes roof felts).

2. OSHA General Industry Asbestos Standard, (29 CFR 1910.1001):

Covers brake and clutch repair and manufacturing of asbestos products and any operations where the PEL may be exceeded.

Note: Maintenance or other construction activities are covered by 1926.1101.

3. 1915.1001 Shipyard Industry Asbestos Standard

Not discussed in this course. Similar to the construction standard below, but one must exactly review this regulation if one works in shipyards or shipboard.

Note: DPH asbestos standard discussed below also applies to ships in dry-dock.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

B. OSHA CONSTRUCTION STANDARD: (29 CFR 1926.1101) Final Rule Effective 10/11/94; As Amended 7/30/98 and As Amended by 1910.134 Eff 4/98.

1. Special Definitions Include:

Disturbance means activity that crumbles or pulverizes ACM or generates visible debris.

Employee exposure is defined as the exposure outside any respirator use. Designation of controls according to classification:

Class I work = TSI and surfacing removal of ACM or PACM (TSI and Surfacing have the same meaning as in EPA AHERA except drywall is not classed as surfacing but plaster is.

Class II work = Removal of ACM or PACM other than TSI and surfacing, for example floor tile, sheetrock, roofing, transite, ceiling tiles, glues and putties, etc.

Inspectors must sample the taping compound and untaped areas separately. OSHA regulates sheetrock taping compound separately when other agencies do not. If the taping compound is >1%, this is an OSHA ACM. If there are no surfacing layers with ACM and the combined analysis of the sheetrock and taping compound is <1 % asbestos then EPA and DPH don't regulate it. Removal of sheetrock is a class II job.

Class III work = repair and maintenance where small amount of ACM may be disturbed, less than a standard glove bag (**< 3 square ft factoring in the state DPH regulations for spot repairs**).

Class IV work = maintenance and custodial including work in general industry or construction industry associated with Class I, II and III work, i.e., custodial and maintenance work is Class IV work only if associated with a construction asbestos project. Class IV persons may not disturb ACM; they may do jobs like mopping/cleaning intact VAT.

Regulated area = an area established by the employer to demarcate areas where Class 1, II, and III asbestos work is conducted, and any adjoining area where debris and waste from such asbestos work accumulate; and a Work Area within which airborne concentrations of asbestos, exceed or there is a reasonable possibility they may exceed the permissible exposure limit. Requirements for regulated areas are set out in paragraph (e) of this section.

2. Regulated Areas (Asbestos Work Areas) 1926.1101 (e)

a. All Class I, II and III Asbestos Work

Any area where Asbestos is disturbed (Does not depend on exceeding PEL)

b. Demarcation including Signs

1) Signs posted at all entries to Work Areas.

DANGER
 ASBESTOS
 CANCER AND LUNG DISEASE HAZARD
 AUTHORIZED PERSONNEL ONLY
 RESPIRATORS AND PROTECTIVE CLOTHING REQUIRED IN THIS AREA

2) Supplementary bilingual, pictograph, and/or graphics signs must be available.

3) Demarcation usually includes critical barriers or negative pressure enclosures in addition to signs.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- c. Limited Access (to authorized persons)
- d. Respirators and protective clothing (See page 33, items 5. and 6.)
- e. Prohibited activities

No one can eat, drink, smoke, chew tobacco or gum, or apply cosmetics in the regulated area.

- f. Competent Person
- g. Personal monitoring
- h. Trained personnel

3. Exposure Limits:

- a. Permissible Exposure Limit (PEL): 0.1 f/cc, 8 hour TWA
- b. Excursion Limit (EL) 1.0 f/cc, 30 minute monitoring during each day's peak work disturbing asbestos in each Work Area
- c. Method: We can use the method that only counts asbestos fibers, OSHA Method ID-160 (Same as the method in Appendix B of 1926.1101) for personal samples.

4. Personal Air Sampling:

- a. **Required for Class I, II and for Class III jobs.**
- b. Required **daily** for each Work Area.
- c. Very tough to rely on first day or past work history to avoid doing this sampling.
 - 1) OSHA says that first day monitoring can no longer be relied on to predict the exposures of a job since the first day may have lighter exposure.
 - 2) Assessments are needed to rely on historical data and these will be discussed (below on page 40).
- d. Employees must be able to observe this monitoring and the results must be posted daily at the work site.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

5. Respirator Use:

a. Operation specific requirements. Respirators are required for:

- 1) Class I work
- 2) Class II work where ACM is not removed intact
- 3) All Class II and III work where the employer cannot produce a negative initial exposure assessment
- 4) Class IV work in regulated areas (e.g. cleanup in a Class I job is Class IV work).

b. Class I jobs require Supplied Air Respirators in positive pressure mode unless a negative exposure assessment is produced. (Exposure is below 0.1 f/cc for the 8 hr PEL.

c. Assessment: If competent person determines exposures will be below the PEL, must use at least 1/2 face negative pressure, non disposable respirator with HEPA filters in the regulated area.

d. In addition to the operation specific requirements for regulated areas, respirators are required at any time when exposure is above the PEL.

e. A PAPR must be used when the employee wants it.

6. Protective Clothing

a. Disposable Coveralls (see page 129)

b. Laundering (for non-disposable clothing)

Discussed on page 131.

c. Contaminated clothing.

Either as wastes or for laundering, handled as Asbestos Wastes see page 131, page 97.

a) Must be transported in sealed impermeable bags, or other closed, impermeable containers, and

b) Have required labels (see page 97).

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

d. Inspection of protective clothing.

- 1) The competent person shall examine worksuits worn by employees at least once per workshift for rips or tears.
- 2) When rips or tears are detected, immediately mend or replace.

7. Hygiene Facilities and Practices: "Decons"

a. Class I asbestos jobs > 25 linear or 10 square feet:

1) Decons or Decontamination areas: adjacent and connected to (contiguous) the regulated area with an equipment room, shower area, and clean room connected to each other in series. See schematic drawings in the handout on W.W.W.Chem-scope.com.

a) Equipment room. Supplied with impermeable, labeled bags and containers for the containment and disposal of contaminated protective equipment.

b) Shower Area unless the employer can demonstrate that it is not feasible. Provided per 29 CFR 1910.141(d)(3) (**One shower per 10 employees or fraction thereof of each sex and soap with warm water.**)

c) Remote Shower: Where the employer can demonstrate that it is not feasible to locate the shower between the equipment room and the clean room, or where the work is performed outdoors, the employers shall ensure that employees:

(1) Remove asbestos contamination from their worksuits in the equipment room using a HEPA vacuum before proceeding to a shower that is not adjacent to the Work Area; or

(2) Remove their contaminated worksuits in the equipment room, then don clean worksuits, and proceed to a shower that is not adjacent to the Work Area.

d) Clean Change Room. The clean room shall be equipped with a locker or appropriate storage container for each employee's use. When the employer can demonstrate that it is not feasible to provide a clean change area adjacent to the Work Area or where the work is performed outdoors, the employer may permit employees engaged in Class I asbestos jobs to clean their protective clothing with a portable HEPA-equipped vacuum before such employees leave the regulated area. Following showering, such employees however must then change into street clothing in clean change areas provided by the employer which otherwise meet the requirements of this section.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- 2) Decontamination Area Entry Procedures. The employer shall ensure that employees:
 - a) Enter the decontamination area through the clean room;
 - b) Remove and deposit street clothing within a locker provided for their use; and
 - c) Put on protective clothing and respiratory protection before leaving the clean room.
 - d) Before entering the regulated area, the employer shall ensure that employees pass through the equipment room.
 - 3) Decontamination area exit procedures. The employer shall ensure that:
 - a) Before leaving the regulated area, employees shall remove all gross contamination and debris from their protective clothing.
 - b) Employees shall remove their protective clothing in the equipment room and deposit the clothing in labeled impermeable bags or containers.
 - c) Employees shall not remove their respirators in the equipment room.
 - d) Employees shall shower prior to entering the clean room.
 - e) After showering, employees shall enter the clean room before changing into street clothes.
 - 4) Lunch Areas. Whenever food or beverages are consumed at the worksite where employees are performing Class I asbestos work, the employer shall provide lunch areas in which the airborne concentrations of asbestos are below the permissible exposure limit and/or excursion limit.
- b. Small Class I work (< 25 linear or 10 square feet) and for Class II and Class III Jobs Where no Negative Initial Exposure assessment was produced). (DPH is stricter.)
- 1) Contiguous equipment room with impermeable drop cloth on the floor.
 - 2) The area must be of sufficient size as to accommodate cleaning of equipment and removing personal protective equipment without spreading, contamination beyond the area (as determined by visible accumulations).
 - 3) Work clothing must be cleaned with a HEPA vacuum before it is removed.
 - 4) All equipment and surfaces of containers filled with ACM must be cleaned prior to removing them from the equipment room or area.
 - 5) The employer shall ensure that employees enter and exit the regulated area through the equipment room or area.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

c. Requirements for Class IV work.

Employees performing Class IV work within a Class I, II or III area must comply with the respective hygiene practice required within that area.

d. In Review: Considering OSHA and DPH Regulations, There are Four exceptions to Contiguous Shower Requirement:

- 1) Outdoors
- 2) Where is shown not to be feasible.
- 3) Class III jobs.
- 4) Any job involving less than 3 sq ft or 3 lin ft of ACM.

8. Medical Surveillance:

a. Required for those employees who:

- 1) **Are issued a negative pressure respirator.**
- 2) For a combined total of **30 days or more per year** either engage in Class I, II or III work and/or who are exposed above the PEL or EL.

b. More than one hour of work counts as a day.

Note: This is one area where the General Industry Standard is stricter: All exposed above the PEL or EL, irrespective of the 30 days, must have medical surveillance.

c. At least once per year and at time of hire unless done within the year hired.

d. Requires

- 1) Examination under supervision of a licensed physician.
- 2) No cost to the employee.
- 3) At a reasonable time and place.
- 4) Always requires a **Questionnaire** with medical and work history with special emphasis directed to the pulmonary, cardiovascular, and gastrointestinal systems.
- 5) Medical Exam including pulmonary function testing of forced vital capacity (FVC) and forced expiratory volume at one second (FEV 1).
- 6) Optional chest X-ray if ordered by the physician.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

7) Information provided to the physician.

- a) A copy of 1926.1101 with Appendices D, E, G and I;
- b) Description of the affected employee's duties as they relate to the employee's exposure;
- c) The employee's representative exposure level or anticipated exposure level;
- d) A description of any personal protective and respiratory equipment used or to be used; and
- e) Information from previous medical examinations of the affected employee that is not otherwise available to the examining physician.

8) Physician's written opinion

- a) Whether the employee has any detected medical conditions that would place the employee at an increased risk of material health impairment from exposure to asbestos;
- b) Any recommended limitations on the employee or on the use of personal protective equipment such as respirators; and
- c) A statement that the employee has been informed by the physician of the results of the medical examination and of any medical conditions that may result from asbestos exposure.
- d) A statement that the employee has been informed by the physician of the increased risk of lung cancer attributable to the combined effect of smoking and asbestos exposure.
- e) The employer shall instruct the physician not to reveal in the written opinion given to the employer specific findings or diagnoses unrelated to occupational exposure to asbestos.
- f) The employer shall provide a copy of the physician's written opinion to the affected employee within 30 days from its receipt.

9. OSHA Asbestos Record Retention

- a. Exposure monitoring results (30 years)
- b. Medical surveillance records (duration of work +30 years)
- c. Training records (one year)

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- 10. Presumption of asbestos:** Assume material is asbestos or test to prove otherwise.
- a. All TSI and surfacing materials installed before 1980 are PACM (presumed asbestos containing material).
 - b. All floor tile and roofing installed before 1980 is assumed to contain asbestos.
 - c. Assumed asbestos materials as adopted by EPA are also asbestos unless shown to be otherwise.
 - d. If the owner wishes to not assume materials are asbestos, OSHA requires the following:
 - 1) Inspection and sampling using an EPA Accredited Inspector.
 - 2) Sampling requirements for bulk samples are now the same as the EPA requirements. For each homogeneous area:
 - a) Surfacing:
 - 3 samples up to 1000 sq ft,
 - 5 samples for 1-5000 sf
 - 7 samples above 5000 sf
 - b) Miscellaneous Materials: in a manner sufficient to be correct. (Industry practice is to generally take 3 samples unless it is a patch or very small area.)
 - c) TSI 3 samples
 - 3) PLM analysis: Lab used must be **NIST(National Institute Of Standards And Technology) or AIHA (American Industrial Hygiene Association)** proficient in bulk sample analysis. AIHA Proficiency is rated twice a year by AIHA based on ability to run unknown samples for asbestos content.
 - 4) To prove material in a homogeneous area is not asbestos, all samples in the area must test negative (<1% asbestos).
 - e. Building owner or employer is responsible for treating the above materials as asbestos.
 - f. If there is good cause to know that a material is asbestos containing the employer and/or building owner is deemed to know that fact. This includes material besides those mentioned above.
 - g. Debris in an enclosed area where TSI or surfacing is present, and not intact, is presumed to be asbestos containing.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

11. Hazard Communication Requirements for Employers Besides Owners:

- a. Employers who discover the presence of ACM or PACM on the worksite must notify the project or building owner.
- b. On worksites having multi employers:
 - 1) The person who discovers the material is also to notify the other employers.
 - 2) An employer planning Class I or Class II asbestos work is to inform all the other employers on the site of the location and quantity of these materials and the measures to be taken to protect them from exposure.
- c. Employers who are not owners planning Class I, II or III work must notify the owner of the location and quantity of ACM and PACM known or later discovered.
 - 1) Within 10 days of completion of Class I or II asbestos work, the employer of the employees who performed the work shall inform the owner and employers who will be working in the area of the quantity and PACM or ACM remaining in the former regulated area and the final monitoring results.
 - 2) For inadvertently discovered ACM/PACM there is a 24 hour notification requirement to the owner and all employers at the site.

12. Owners - Notification and Labeling

- a. Building "Owners":
 - 1) OSHA considers building owners as statutory employers, who must "take necessary and appropriate action to protect employees other than their own..."
 - 2) OSHA is requiring the owner to receive, maintain and communicate knowledge of the location and amount of ACM or PACM to employers of employees who may be exposed.
 - 3) The building owner must keep records of all information received through this notification scheme, or through other means, which relates to the presence, location and quantity of ACM and PACM in the owner's building, project or vessel and transfer all such information to successive owners.
 - 4) OSHA has defined 'building owner' to include those lessees who control the management and record keeping functions of a building/facility.
 - 5) When the lease expires the records go to the owner or the next lessee.
- b. Owners must notify of the location of ACM/PACM:
 - 1) Employers who bid for work
 - 2) Tenants
 - 3) Employees

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

c. Asbestos materials must be visibly labeled when feasible as close to the installed material as feasible:

- 1) In construction areas where there is any possibility for disturbance.
- 2) In areas of buildings where they may be disturbed by any type of construction related activity including custodial, maintenance or outside contractors.

d. Exemption: products which the manufacturer demonstrates cannot release fibers in excess of the PELs. OSHA has found that this exemption will never apply to PACM (surfacing or TSI); rarely will it apply to other asbestos containing materials.

e. Housekeeping workers must be informed that all resilient floor material that they clean buff or otherwise maintain may contain asbestos.

13. Note on Assessments which are discussed below.

a. There are 2 kinds of assessments done by a competent person: one is called "Initial Exposure assessment" which is required for Class I, II, and III jobs; and the other is called "Negative initial exposure assessment", which is an optional process.

b. A new Initial Exposure Assessment must be produced immediately before or at the initiation of a new job. Employers may evaluate repetitive operations with highly similar characteristics, as one job, such as cable pulling in the same building so long as historic data used reflect operations of the same duration and frequency."

c. The best approach for the monitor is to see that personal air sampling is done daily, evaluate those results and also to complete the pre-abatement inspection form in the handout on W.W.W.Chem-scope.com.

14. Initial Exposure Assessment:

a. Class I, II, III jobs: Immediately before each job or at the beginning of each job unless a Negative Initial Exposure assessment has already been made for this job.

b. Purpose is to ascertain actual or expected employee exposures during the job, to make sure that all control systems are appropriate for the operation and will work properly.

c. Basis of assessment:

- 1) Assessment shall be based on personal air monitoring for this job, if feasible, and
- 2) Consideration of all observations, information or calculations which indicate employee exposure to asbestos, including any previous monitoring. The initial assessment may conclude that exposures are likely to be below the PEL only as the result of a negative initial exposure assessment.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

15. Negative Initial Exposure Assessment:

It is possible, but difficult, to make a Negative Initial Exposure Assessment for any one specific asbestos job by any one of three methods:

a. Objective Data: Use objective data to demonstrate that the product involved in the work or the process used cannot exceed PEL's.

- 1) This is virtually impossible for Class I work,
- 2) Very difficult to prove for Class II work and
- 3) May apply to Class III or IV work.

Note: The stricter state regulations would limit the changes in work practices to practically every situation.

b. Historical Data: Monitoring data from prior jobs closely resembling the present job (PEL and EL):

- 1) Within 12 months of the present job
- 2) Monitoring and analysis done in accordance with the OSHA standard in effect at the time.
- 3) Data obtained during work operations closely resembling the present job considering:
 - a) Process used
 - b) Type of material
 - c) Control methods including placing and repositioning the ventilation equipment,
 - d) Work Practices including techniques used for wetting the ACM or PACM in the various circumstances encountered
 - e) Environmental conditions including impacts due to weather conditions
 - f) Employee training
 - g) Employee experience
 - h) Workplace conditions
 - i) Degree and quality of supervision
 - j) Duration of the job and corresponding monitoring

The form in the handout on W.W.W.Chem-scope.com may be used

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

c. Personal Monitoring of the Present Job: (PEL and EL for Class I and II work)

- 1) For Class I jobs, we must assume PEL is exceeded until we actually have test results unless the steps in b. above are completed.
- 2) Furthermore, the results of the first day's monitoring cannot be used to predict the results for the additional days unless the operation is identical.

16. Methods of Compliance (work practices):

Note: For interior work, State regulations are still stricter except as specified below. For details See 1926.1101 (g) 4 if interested in details of the OSHA regulation. Most of the following are in addition to the DPH requirements:

a. Must smoke test all negative pressure enclosures.

b. Must have manometer readings of negative pressure of 0.02 inches of water or greater recorded daily.

c. Required in all jobs (Class 1, II, III and IV) regardless of the results of the Assessment:

1) HEPA vacuums

2) Wet methods "OSHA will allow employers to claim infeasibility if they cannot use wet methods due to conditions such as electrical hazards, hot surfaces, and the presence of technical equipment which cannot tolerate moisture. (NOTE for NESHAP jobs): ALL ACM MUST BE KEPT WET until sealed in a leak tight container .

3) Prompt cleanup and disposal in leak-tight containers.

d. Prohibitions:

1) High speed abrasive disc saws

2) Dry sweeping and dry cleanup including shoveling

3) Employee rotation

4) Compressed air unless in a negative pressure enclosure

e. Added Requirements for Class I Jobs:

1) Require PAPR air unless the exposure is proven below 0.1 f/cc for the 8 hr PEL and supplied air if the exposure is above 1.0 f/cc.

2) To use lesser respirators, must have a Negative Initial Exposure assessment.

3) Supervised by competent person

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4) Negative pressure enclosures:

- a) **At least four air changes/ hour**
- b) **Negative pressure of at least 0.02 inches of water monitored daily.**
- c) Continued use through the job
- d) **Air flushing technique - ventilation placed to draw dust away from the worker.**
- e) Smoke tests before work begins and at start of each shift and any leaks sealed.
- f) Deactivate electricity or use GFCI. Ground fault circuit interrupter. A device designed to shut off the current in milliseconds before injury can occur

17. Notification to OSHA

- a. Required when controls other than specified are to be used in Class I jobs. Alternatives for Class I require a rigorous demonstration and advance notice to OSHA.
- b. When the employer intends to utilize controls other than a negative pressure enclosure for Class I jobs.
- c. In some circumstances, where modifications of glove bag or glove box systems and other control systems are to be made.

18. Exemptions:

- a. For use of a technology which is not referenced in the standard, must notify OSHA before the job including the basis for the project designer or CIH's decision. Daily perimeter monitoring must be implemented and a final clearance done. (Note: DPH regulations require the final anyway.)
- b. Glove bag Use: Applications extended without quantity limitations to TSI and surfacing. NOTE: State regulations will not permit this in interior work, so the OSHA change would only affect exterior work. Must be a 2 man glove bag. Negative pressure glove bags and boxes are also allowed for Class I work.
- c. Mini-enclosures are allowed for Class I work. (Note: must comply with DPH enclosure requirements.)

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

19. Flooring Work:

- a. Must assume floor tile and mastic contains asbestos unless proven otherwise as above.
- b. A CIH or a project designer must certify the PLM results.
- c. Must mist the snip point used for cutting sheet flooring.
- d. OSHA says can omit negative pressure enclosure if a Negative Initial Exposure assessment is developed. Note: DPH regulations require negative pressure enclosures anyway.
- e. OSHA allows containment to be omitted in some cases when the tiles are removed intact (non-aggressive method which does not break or dust tiles); CT would require an AWP (alternate work practice) approval by DPH.

20. Exterior work:

- a. "OSHA believes that outdoor Class I work may be safely done without (negative pressure) enclosures. Therefore 1926.1101 paragraph (g) allows all outdoor Class I work to be conducted using other control methods, such as a glove bag system...." Decontamination units are still required and including showers when feasible.
- b. Transite Panel and Siding Removal on Exteriors Other Than Roofs:
 - 1) OSHA is requiring a job by job evaluation by a competent person of Class II work including transite panel removal.
 - 2) OSHA says that: For rare cases when the evaluation of material, condition, crew and past exposure data do not support a Negative Initial Exposure assessment, additional precautions including critical barriers and a respirator must be used.
 - 3) No cutting, breaking or abrading unless other methods cannot be used.
 - 4) Each piece sprayed with amended water before removal.
 - 5) Unwrapped pieces lowered immediately to the ground using dust tight chute, crane or hoist. Wrapped pieces lowered by the end of the shift.
 - 6) Nails shall be cut with a flat, sharp instrument.
- c. Roofing Work:
 - 1) Keep intact to the extent feasible during removal
 - 2) When not intact, wet methods are required when feasible. Not required when there is a safety hazard.
 - 3) Cutting machine blades must be continuously misted during use unless a competent person determines that misting substantially decreases worker safety.

CHEM SCOPE PROJECT MONITOR TRAINING

Updated 4/2/10

- 4) For power roof cutter with an aggregate roof, collect dust with a HEPA vacuum or HEPA dust collector. For smooth roofs, a HEPA vacuum or HEPA dust collector or wet sweeping/wiping can be used to clean up debris. Immediately bag the dust.
- 5) Do not throw or drop ACM to the ground. It can be carried, passed by hand or lowered using a covered dust tight chute, crane or hoist.
- 6) If ACM is not intact, lower unbagged material as soon as practicable but always by the end of the shift. While the material is on the roof it shall either be wet, placed in an impermeable waste bag, or wrapped in plastic sheeting.
- 7) When ACM is intact, lower to the ground as soon as practicable by end of the shift.
- 8) Upon being lowered, unwrapped material shall be transferred to a closed receptacle.
- 9) Roof level HVAC must be isolated or HVAC must be shut down.
- 10) For repair or removal of less than 25 sq ft during a day involving intact sections, wet methods and HEPA vacuum can be omitted unless visible dust is generated.
- 11) For intact flashing or similar work, only the following need be done:
 - a) Competent person inspection determines that roofing will remain intact.
 - b) All employees trained
 - c) No sanding grinding or abrading.
 - d) Manual methods which keep the material intact must be used.
 - e) No dropping or throwing to the ground.
 - f) Remove from the roof by the end of the shift.
- 12) Areas of the roof will be a regulated area where dust or debris may accumulate.
- 13) Only necessary work should be done on the roof while asbestos materials are being removed and the locations of the work should be selected to minimize exposure, such as upwind of the asbestos work. OSHA said the 20 ft barrier approach has merit, but the exact determinations should be made on site and could vary according to working conditions.

21. Removing Gaskets

Note: For interior work, also check stricter DPH regulations.

- a. If deteriorated and unlikely to be removed intact, use glove bag.
- b. Thoroughly wetted with amended water before removal and immediately placed in the disposal container.
- c. Any scraping to remove loose residue must be performed wet.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

22. Additional Notes for Class III Work

- a. DPH standards for projects apply when repairs involve more than 3 ft.
- b. The incidental cutting away of ACM/PACM to access mechanical or structural components for repair or maintenance is considered Class III work.
- c. Remember: Respirators, protective clothing, personal monitoring, Isolation with signs, protection of HVAC, HEPA vacuums, training, wet methods and proper disposal are required.
- d. Local exhaust ventilation is required if feasible.
- e. For TSI and surfacing work which involves drilling, cutting, abrasion, sanding, chipping, breaking or sawing, isolation such as mini-enclosures must be used and respirators must be worn, and where a Negative Initial Exposure assessment has not been made, tenting must be used.

23. Training requirements:

Training must be at no cost to the employee.

- a. All inspector work: 3 days AHERA Training

b. Class I and II work = AHERA Training

- 1) 40 hours for supervisors
- 2) 32 hours for workers

- c. **Class III work = 16 hours** equivalent to the EPA O&M worker training plus more training if the competent person so determines

d. Class IV work = 2 hours

- e. Competent Person Requirements:

AHERA training as contractor/supervisor, project designer or inspector management planner course. In addition to the following requirements in 1926.32: "one who is capable of identifying existing and predictable hazards in the surroundings or working conditions which are unsanitary, hazardous, or dangerous to employees, and who has authorization to take prompt corrective measures to eliminate them."

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

24. Floor Maintenance- Housekeeping requirements:

Practices for ACM/PACM floor: sanding prohibited, stripping done with low abrasive pads below 300 RPM plus wet methods, burnishing and dry buffing done only over enough wax to prevent contact with the floor.

25. Appendices:

- a. Appendices A,C,D,E and F of the General Industry Std are binding.
- b. Appendices A,C,D and E of the construction Industry Std are binding. B,F,H,I and K are not binding.
- c. Appendix A changed the same for all standards:
 - 1) In para 1 "such as the NIOSH 7400 method" is replaced: with: "the most current version of the OSHA ID-160 Method or the NIOSH 7400 method". Recommended flow rate for personal samples increased; now 0.5- 5 liters/ minute.
 - 2) In para 2 add "Do not reuse or reload cassettes for asbestos sample collection"
 - 3) Para 11 : "Each set of samples taken will include 10% field blanks or a minimum of 2 field blanks....from the same set of cassettes as used for the samples..".Any blanks representing counts higher than the detection limit shall be rejected.
 - 4) In the quality control section, inter-lab participation is required.
- d. Appendix J was added: OSHA Method ID 191 for bulk identification of asbestos.

C. OSHA HAZARD COMMUNICATION PROGRAM FOR THE CONSTRUCTION INDUSTRY (CFR 29 1926.59)

1. General:

- a. Deals with chemical hazards in the work place such as:
 - 1) Coatings
 - 2) **Spray Glues usually flammable**
 - 3) Solvents/ Mastic Removers may be combustible, **check MSDS for fire hazard, irritation and health effects of vapors**
 - 4) Reinsulation Materials
 - 5) Encapsulants
 - 6) Spray poly
 - 7) Surfactants
- b. Employees have a right to know if working with a dangerous material and must be trained in how to work with it safely.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Key Elements:

- a. Comprehensive written hazard communication program.
- b. Material safety data sheets (MSDS)
- c. Labels
- d. Employee Training

3. MSDS's and how to read them:

- a. MSDS's are the key to the hazard communication standard.
- b. Manufacturers must provide and employer must obtain MSDS's for all hazardous materials which are accessible to all exposed employees.
- c. Employees must be trained on how to use a MSDS
- d. Employers must have MSDS on the job site for each chemical:
- e. Employers on the job site must share MSDS's and other hazard communication with other employers and their employees; the GC (general contractor) is responsible for coordinating this effort for the entire project.
- f. MSDS's must include:

Section I

Product identity and ingredients

Must be the same as on the container label

Must have the manufacturer's name, address and emergency phone number.

Section II Hazardous Ingredients

Must list hazardous ingredients greater than 1% including: chemical name, synonyms and the CAS # (Chemical Abstracts Service). If carcinogens are present at more than 0.1% they must be identified as carcinogens.

In case of trade secrets, the manufacturer can withhold the name of the chemical but must give a more complete description of the hazards and the properties.

Legal exposure limits

PEL (OSHA)

TLV (ACGIH, AMERICAN CONFERENCE OF GOVERNMENTAL INDUSTRIAL HYGIENISTS)

NIOSH LIMITS OR MANUFACTURER ESTABLISHED LIMITS

CHEM SCOPE PROJECT MONITOR TRAINING

Updated 4/2/10

Section III

Physical and chemical characteristics

Boiling point

Vapor Pressure

Vapor density

Appearance and odor

Specific gravity

Evaporation rate

Miscibility with water

Section IV

Fire, Explosion and reactivity hazards

Flash point

< 100 deg F is flammable like gasoline, acetone, gases like methane and acetylene 100-200 deg F is combustible like lighter fluid, mineral spirits, fuel oil.

Extinguishing Media:

Class A for paper and wood

Class B for liquids or greases

Class C for electrical fires

Class D for metals such as magnesium or metal alloys

Firefighting procedures and unusual explosion hazards

Here you will see instructions like "do not use water" and any special manufacturer's instructions for handling fires with this chemical.

Section V Reactivity Data

Incompatibility with other chemicals. For example if you mix chlorine bleach and ammonia, poisonous phosgene gas is released.

Section VI Health Hazard Data

Health hazards, risk of cancer

Acute (short term) effects

Chronic (long term) effects

Routes of entry (ingestion, inhalation, skin)

Target organs such as heart, liver, etc

Signs or symptoms of exposure

Medical conditions generally aggravated by exposure

What to do if someone is exposed

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section VII Precautions for safe handling and use

Spill and leak procedures, Waste disposal method and other special precautions for handling and storing

Section VIII Control measures

How to eliminate or minimize the hazard including:

Ventilation and other engineering controls

Personal protective equipment requirements

Emergency and first aid measures

Spill and Leak procedures

Each MSDS may use different formats but all must contain the above information.

D. RESPIRATORY PROTECTION STANDARD OSHA 29 CFR 1910.134

1. Written Program See F. Below

2. Respirator Assignment and Maintenance

- a. Respirators should be assigned to individual workers for their exclusive use.
- b. Fit testing must be checked after repair or replacement of component parts.
- c. Inspection for defects
- d. Maintenance and storage procedures.

3. Employee Training Program

4. Respiratory Protection

See Section 6 starting on Page 119 for further details.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

E. OTHER IMPORTANT OSHA REGULATIONS AFFECTING ASBESTOS ABATEMENT

1. Fire safety OSHA 29 1910.38 and 1926.24 and 1926.150-155)
2. Ladder and Scaffold safety, OSHA 29 CFR 1926.450 et seq
3. Electrical safety OSHA CFR 29 1926.402 and .416-.417
4. Protective Clothing and Equipment See Section 6 starting on page 119.
5. Recording and Reporting of Injuries OSHA 29 CFR 1926.22
6. First Aid and Medical Attention OSHA 29 CFR 1926.23
7. Shower and Sanitation requirements OSHA 1910.141

F. REQUIRED WRITTEN SAFETY AND HEALTH PLANS/PROGRAMS:

The plans can be incorporated into a single Safety and Health Plan which always must be kept on the job sites. Usually the employer makes a number of copies of this plan which each supervisor brings to the job site.

1. Lead compliance plan (Required by OSHA, 1926.62)

a. Activities in which lead is emitted:

- 1) Equipment used.
- 2) Materials used:
- 3) Controls in place
- 4) Crew size
- 5) Employee job responsibilities
- 6) Operating Procedures
- 7) Maintenance Practices

b. A description of the specific means that will be employed to achieve compliance and where engineering controls are required, engineering plans and studies used to determine methods selected for controlling exposure to lead:

c. A report of technology considered in meeting the PEL

d. Air monitoring data which documents the source of lead emissions

e. A detailed schedule for implementation of the program including documentation such as copies of purchase orders for equipment, construction contracts, etc.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

f. A work practice program which includes items required under protective clothing housekeeping and hygiene facilities and a good work practice program such as described in Appendix B of 1926.62:

- 1) Adherence with the PEL
- 2) Exposure assessment
- 3) Respirator, protective clothing and equipment use
- 4) House keeping procedures.
- 5) Hygiene facilities and practices.
- 6) Medical surveillance and medical removal practices
- 7) Employee information and training
- 8) Signs
- 9) Record keeping procedures
- 10) Observation of monitoring.

g. An administrative control schedule, i.e. job rotation

h. Arrangements made among contractors on multi-employer sites with respect to informing affected employees of potential exposure to lead and with respect to responsibility for compliance with 1926.62 (e) and 1926.16.

i. Other Considerations.

- 1) Frequent and regular inspections of the job sites, materials and equipment are made by a competent person.
- 2) Employee access to company program and S.O.P.s (standard operating procedure)
- 3) Updating of the program at least every 6 months.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Written Respiratory Protection Program

- a. Procedures for selecting respirators for use in the workplace;
- b. Medical evaluations of employees required to use respirators;
- c. Fit testing procedures for tight-fitting respirators;
- d. Procedures for proper use of respirators in routine and reasonably foreseeable emergency situations;
- e. Procedures and schedules for cleaning, disinfecting, storing, inspecting, repairing, discarding, and otherwise maintaining respirators;
- f. Procedures to ensure adequate air quality, quantity, and flow of breathing air for atmosphere-supplying respirators;
- g. Training of employees in the respiratory hazards to which they are potentially exposed during routine and emergency situations;
- h. Training of employees in the proper use of respirators, including putting on and removing them, any limitations on their use, and their maintenance; and
- i. Procedures for regularly evaluating the effectiveness of the program.

3. Emergency response plan 29 CFR 1910.120 and other OSHA Regulations

(See also pages 116-117)

- a. An organizational structure showing personnel roles, lines of authority communications and training.
- b. Pre-emergency planning
- c. Safe distances and places of refuge
- d. Site security and control measures
- e. Evacuation routes and procedures
- f. Decontamination procedures
- g. Medical emergencies - treatment and first aid
- h. Emergency alerting and response
- i. Inspection for effectiveness of the plan
- j. Personal protective equipment
- k. Procedures for handling emergency response

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Hazard Communication/Right to Know Program (29 CFR 1926.59)

- a. Responsible individuals
- b. List of hazardous substances
- c. Labels
- d. MSDS's
- e. Non-routine tasks
- f. multi-employer worksites
- g. employee information and training
- h. Outside contractor policy

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

5. Medical Surveillance Program

- a. Monitoring the worker's ability to wear a respirator.
- b. Biological Monitoring and examinations specific for lead exposure including blood lead testing.
- c. In general this written program includes:
 - 1) Pre-employment, during employment and after employment medical examinations.
 - 2) Mechanism for emergency and other medical treatment
 - 3) Work practices
 - 4) Personal hygiene
 - 5) Symptoms of asbestos, lead or other toxicants
 - 6) Signs of adverse health effects
 - 7) Record keeping system
 - 8) For lead workers: Lead level vs effects at hire or placement
 - 9) Changes with time
 - 10) Occupational vs non occupational sources of asbestos/lead
 - 11) Information to physicians
 - 12) Employees right to see all test results
 - 13) Medical removal

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 2-3

DPH Regulations

A. DPH ASBESTOS STANDARD: 19A 332-1-16 (AMENDED 4/04)

1. Applicability:

- a. All Interior Work
- b. Includes all structures even single family homes and ships in dry dock.
- c. Applies to schools. (Plus reoccupancy criteria in DPH School regulations are stricter.)
- d. Notification needed for friable exterior work

2. Asbestos Project: \geq 3 sq ft or 3 linear ft of asbestos material

3. Notification: (new in 2004)

a. From:

- 1) Asbestos abatement contractor
- 2) Facility owner
- 3) OR ANY PERSON WHO WILL BE CONDUCTING DEMOLITION ACTIVITIES**

b. For:

- 1) Asbestos abatement involving more than ten linear feet or twenty five square feet of ACM**
- 2) OR BEFORE ENGAGING IN THE DEMOLITION OF ANY FACILITY.**

c. To:

- 1) DPH
Connecticut Dept of Public Health
410 CAPITOL AVE MS # 51 AIR
PO BOX 340308
HTFD CT 06134
(860) 509 7367

- 2) Facility owner, if notification made by asbestos contractor.

d. DPH Submittal:

- 1) On DPH forms
- 2) Postmark or hand deliver **10 calendar days before starting abatement or demolition**
- 3) For emergency,
 - within one (1) working day after the start of asbestos abatement **OR DEMOLITION.**
 - Must include **A COPY OF ANY WRITTEN ORDER REQUIRING DEMOLITION**

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

e. EPA Submittal:

An EPA submittal is no longer needed.

f. **Asbestos abatement notification** minimum information:

- 1) Name, address and phone number of Asbestos Abatement Contractor.
- 2) Name, address and phone number of Facility Owner.
- 4) Exact facility location (**site address, building name or number if applicable and exact room within the building**).
- 5) Nature of the asbestos abatement
- 6) Facility description including size, age and use.
- 7) Amount of ACM to be removed, enclosed or encapsulated or contained in the facility or part thereof to be demolished.
- 8) Scheduled start and completion dates. **(Fax any changes to the CT DPH. Notify the CT DPH especially if the project ends at an earlier date).**
- 9) Description of work practices to be followed to comply with 19a-332a-5-12
- 10) Name and address of Asbestos waste disposal site.

g. Prepare a separate **demolition notification** (using CT DPH Demolition/Notification Form, copy on Handout on W.W.W.Chem-scope.com) for each facility for which there is a proposed demolition with the following minimum information:

- 1) **Type of notification (new, emergency, revised)**
- 2) **The name, address, telephone number, and a contact person for the facility owner/operator.**
- 3) **The name, address, telephone number, and a contact person for the demolition contractor.**
- 4) **The name, address, telephone number, and DPH License number of the Asbestos Inspector who conducted the Pre-Demolition Asbestos Survey.**
- 5) **Start Date and Completion Date.**
- 6) **Name and address of the facility**
- 7) **Use of the Facility (School, Public Building, Manufacturing, Office, College, Commercial, Church/Synagogue, Residential, Other) and number of dwellings.**
- 8) **Building Data (Square Feet, Number of Floors, Age).**
- 9) **Name and address of the Demolition Disposal Facility.**
- 10) **Name and address of the Waste Hauler.**
- 11) **Name and address of the person completing the form.**

Note: An air clearance should be conducted even for buildings being demolished. Typically, for insurance reasons, the demolition contractor is going to have an employee check every space inside a building to be demolished to be certain that there are no vagrants or squatters hiding inside.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. DPH Required Records:

- a. The notification
- b. List of names and social security numbers of all staff related to the asbestos project.
- c. Log of control of access to the Work Area
- d. All records required by EPA, OSHA, AND DEP
- e. During work air sampling
- f. Post abatement reoccupancy **(Gave a copy of this document to the contractor, as he is required to keep one on file).**

5. General abatement requirements:

- a. Signs
- b. Critical Barriers: page 107.
- c. Objects in the Work Area:
 - 1) Movable objects decontaminated using HEPA vacuums and/or wet cleaning methods as appropriate and removed from Work Areas to a temporary location. Otherwise dispose of as contaminated waste.
 - 2) Fixed objects within the Work Area: cover with a minimum of 4-mil plastic sheeting and tape. The distinction between movable and fixed objects is made in the definitions. The rest is a matter of common sense. When fiberglass insulation is to remain, it is considered a fixed object and would have to be covered and sealed. Very often this is not practical so the fiberglass is often removed with the ACM.
- d. Floor and Wall Plasticization:

Cover flooring and wall surfaces with polyethylene sheeting sealed with tape. **Use a minimum of two layers of 4-mil polyethylene on walls and 6-mil polyethylene on floors.** Floor plastic must interleave under the wall plastic so that polyethylene extends **at least twelve inches up on walls**, then wall polyethylene sheeting is applied to the floor thus overlapping the first layer by at least 12 in. This keeps the water from leaking out.
- e. Restricted Access to Work Area:

All persons entering the Work Area must be properly authorized and equipped with proper respiratory protection and protective clothing.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- f. Cleaning using HEPA vacuum and amended water until there is no visible residue.
- g. Ventilation (Negative air): one air change every 15 minutes.
- h. Waste water filtered by best available technology. 5 microns or smaller porosity.
- i. Asbestos wastes wet and sealed in leak tight containers.
- j. Waste labeled per OSHA regulations:
- k. Disposal at authorized facility. **(There may be one landfill in Manchester accepting non-friable asbestos waste).**

6. Worker Decontamination System:

- a. Same as OSHA 1926-1101 reference to Hygiene Facilities and it applies for any asbestos project >3 sf or Lin ft.
- b. Clean room
- c. Shower room:
- d. Equipment room
- e. Each room separated by airlocks. An airlock is a special plastic barrier.
- f. Entry and exit- decontamination procedures are outlined on page 111.
- g. Contiguous decontamination system when feasible. (Must notify DPH and the facility owner when not feasible)

7. Asbestos Removal Practices:

- a. Wet Asbestos Material
- b. Remove intact or in large sections (as large as feasible) and carefully lower to the floor.
- c. Spray encapsulate all stripped surfaces
- d. Decontaminate or wrap equipment before removal from area
- e. Empty HEPA vacuum in the Work Area
- f. Negative air units:
 - 1) Remove all pre-filters and damp clean
 - 2) Change HEPA filters at start of next project after containment is established

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

8. Encapsulation:

- a. An abatement option involving full setup, repair and use of a spray called an Encapsulant.
- b. Spraying an encapsulant called "lock- down" is also required after asbestos abatement.

9. Enclosure

- a. First encapsulate as above (**Remember – Full Containment, followed by air clearance**).
- b. Construct barriers to isolate

10. Spot Repairs

- a. Isolate with barriers (glove bag permitted)
- b. Wet material
- c. HEPA and wet clean surfaces
- d. Use leak proof disposal containers
- e. OSHA labels and NESHAP labels if appropriate
- f. Filter waste water
- g. Same disposal practices as for asbestos projects above

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

11. Alternate Work Practices

- a. May apply if there is existing **gross contamination, only floor tile** or other situations such as the need to leave the HVAC running.
 - b. Licensed Project Designer must apply and get approval FROM DPH.
 - c. Use forms provided by DPH
 - d. \$ 200 fee. Request cannot be faxed.
- See handout on W.W.W.Chem-scope.com

12. Post abatement reoccupancy testing (finals):

No occupancy until test is satisfactorily completed
 (See pages 152-154.)

B. CHANGES IN DPH ASBESTOS REGULATIONS THIS DECADE:

1. Effective in January 1991:

- a. Friable Asbestos Material is redefined:
- b. Traditionally, friable means An Asbestos material that can be crumbled, pulverized or reduced to powder when dry by hand pressure and which releases Asbestos fibers into the environment.
- c. As additionally defined in the Connecticut regulations:
- d. Also includes any non friable ACM that potentially can be broken, crumbled, pulverized or reduced to powder as the result of asbestos abatement.
- e. Exterior asbestos excluded
- f. TEM limits changed to 500 lin ft and 1500 sq ft
- g. New lab requirements for final air samples: **AIHA accredited lab or AIHA registered analysts.**
 Note: Effective 12/31/04: 3) Lab analysis at AIHA Accredited lab or **for scope on site AIHA Registered analyst must be used.**

2. Effective October 1991:

- a. Portions of the state board of education regulations were repealed (sec 10-292-a and 10-292-b).
- b. Temporarily it was lawful to do abatement during school session. However, new DPH regulations for asbestos in schools restored the requirement to get DPH permission first.
- c. Annual school updates no longer required to be submitted to state.
- d. DPH is now doing many on site school inspections focusing on schools involved in abatement- past and in progress.
- e. EPA funded the DPH to add inspectors.

3. October 2009

- a. DPH charges fees for notifications of \$100 plus 1% of the project excluding reinsulation up to a max fee of \$5000. Jobs under 160 sq ft - flat \$100 fee only.
- b. Fee for alternate work practice is now \$200.
- c. New notification forms
- d. Reinspections (compliance inspections) \$100.

4. Dec 1, 1992 19a-333-1-13, June 2006

DPH came out with regulations to replace the repealed school regulations. The DPH regulations are nearly the same as AHERA and additionally restrict asbestos abatement while school is in session. In June 2006, DPH expanded the definition of "while school is in session" to include all times when students are in the building. If students will be in any part of the building, the LEA must submit a request for approval to DPH. The details are provided in the handout on W.W.W.Chem-scope.com.

5. Effective Fall of 1994, State licensure requirements 19a 332-17-23 rev

6. 1998-1999 - New State licensure requirements; copy handout on W.W.W.Chem-scope.com

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

C. LICENSING REQUIREMENTS (published 7/20/99 effective 7/20/00)

1. Sec. 20-440-2. Licensure of asbestos contractors.

- a. Stricter than 1994 regulations in many respects; fee is now \$625 per year.
- b. The licensed contractor will have to hire certified asbestos and supervisors.
- c. Additional submittals with license application:
 - 1) Medical monitoring
 - 2) Employee training
 - 3) Equipment specifications
 - 4) Air monitoring data
 - 5) Permits, violations, and any legal actions.

2. Sec. 20-440-3. Certification and licensure of asbestos consultants

- a. Existing licensing for consultants will continue for each discipline and will be considered "certification and licensing".
- b. Licenses will be offered in the following disciplines of asbestos consultation:
 - 1) Inspector
 - 2) Inspector/management planner
 - 3) Project designer
 - 4) Project Monitor.
- c. Applicants simultaneously apply for certification and licensure as asbestos consultants in the same application-
- d. Training requirements are the same with the exception of the new Project Monitor course and reduction of inspector refresher to 4 hours.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

e. Inspector

1) Scope of Licensure and Authorization:

- a) Review facilities records; perform visual inspection or surveillance of facilities
- b) Identify, document or inventory materials suspected of containing asbestos
- c) Collect bulk samples for asbestos analysis according to procedures established by applicable state or federal laws and, regulations and
- d) Provide direct supervision to non-certified individuals collecting bulk samples of materials suspected of containing asbestos.
- e) Inspectors shall apply current concepts and knowledge of best available technology to evaluate the conditions and accessibility ACM.

2) Qualifications.

- a) Either a bachelor's or an associate's degree in engineering, architecture, industrial hygiene or a scientific field determined by the commissioner to be closely related and
- b) Six months employment experience in an occupation determined by the commissioner to be closely related; or two (2) months field experience under the direct supervision of a licensed inspector or management planner.
- c) 3 day inspector approved training and required refreshers

3) Exempted activities:

- a) Periodic surveillance. However, no touching or taking of samples is permitted without a license as an inspector.
- b) Compliance inspections by federal or state agency.
- c) Visual inspections to determine whether a response action is complete (must be a licensed Project Monitor).

f. Management planner (Inspector/Management Planner)

1) Scope of Licensure and Authorization:

- a) Utilize information developed from facility inspections to assess potential hazards of ACM
- b) Develop abatement response actions, operations and maintenance plans, and select and recommend abatement actions.
- c) All the authorizations of an inspector.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2) Inspector Qualifications.

- a) Either a bachelor's or an associate's degree in engineering, architecture, industrial hygiene or a scientific field determined by the commissioner to be closely related and
- b) Applicants shall have minimum of six (6) months experience in asbestos abatement, including experience in asbestos management or three (3) months field experience under the supervision of a licensed management planner.
- c) 3 day inspector plus 2 day management planner approved training and required refreshers.

g. Project Designer

1) Scope of Licensure.

- a) Apply knowledge of facility construction, design and development of abatement projects; abatement specifications; bidding documents; architectural drawings; and schematic representations of material locations.
- b) May also determine how asbestos abatement should be conducted.

2) Qualifications.

- a) Bachelor's degree engineering, architecture, industrial hygiene or a scientific field determined by the commissioner to be closely related.
- b) One year experience in asbestos abatement, including experience in asbestos abatement design or six (6) months field experience under the supervision of a licensed project designer.
- c) 3 day approved project designer training and required refreshers.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

h. Project Monitor

1) Scope of Licensure.

- a) Function as on-site representative of the facility owner or other persons.
- b) Interpret project specifications or abatement management plans.
- c) Monitor and evaluate contractor or employee compliance with applicable regulations or specifications and
- d) Ensure that abatement projects are properly conducted and completed.
- e) The Project Monitor shall not function as the asbestos contractor, or as an employee of the asbestos contractor on the same asbestos abatement project.

2) Qualifications.

- a) Either bachelor's degree in engineering, architecture, industrial hygiene or a related scientific field or an associate's degree in biology, chemistry or a closely related field.
- b) Applicants shall have a minimum of one (1) year experience in asbestos abatement, including experience in asbestos abatement project monitoring or six (6) months field experience under the supervision of a licensed Project Monitor.

c) Training:

(1) Existing licensed project monitors must take the Project Monitor refresher course after 7/20/00 and may take the course after 7/20/99.

(2) New project monitors must take the five day Project Monitor initial course and the required annual Project Monitor refreshers.

3. Section 20-440-4. License and certification application for asbestos consultants.

a. Written application using prescribed forms.

- 1) Copies of training certificates.
- 2) Documentation demonstrating necessary educational and employment experience

b. Payment of a \$250 licensure fee by certified or bank check.

c. Annual Renewal of License during the month of birth with application and \$250 fee.

d. Certification expires simultaneously with training certificate. Any individual either seeking licensure or possessing licensure as an asbestos consultant shall maintain current certification in the appropriate discipline. (For those who become inactive, the longest lapse between courses is 24 months; otherwise initial training must be taken over.)

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

e. Exemption. An individual who between July 1, 1985 and November 1, 1994, has been employed for a minimum of two (2) years as an asbestos consultant may be licensed as an asbestos consultant without the bachelor's degree, provided the applicant has met all other requirements.

f. Asbestos consultants shall be in physical possession of initial and current license, certification and training accreditation at a job site when performing work requiring licensure, certification and accreditation.

g. Change of office or residence address. Notify DPH within thirty days.

4. Section 20-440-5. Requirements for certification and employment as an asbestos abatement site supervisor or asbestos abatement worker.

a. Individual Certification required for work with 3 sq ft or lin ft of ACM **or more**.

b. Must have initial and current certificates at the job location.

c. Certification is good for one year and expires on the same date as that of accreditation.

d. Each individual sends written application to DPH including:

1) Copies of training certificates.

2) List of all asbestos contractors and asbestos consultant employers over the last three years.

3.) Fees: \$100 for Supervisor / \$50 for Worker

5. Section 20-440-6: Denial of eligibility of applicants; Disciplinary action

a. Violation of the asbestos regulations

b. Violation of the standard of care of the profession;

c. Negligence in performing activities that require licensure or certification;

d. Aiding or abetting persons who engage in activities that require licensure or certification, but are not licensed or certified; and,

e. Fraud or deceit in the course of professional services or activities.

6. Section 20-440-7: Revised Training requirements

a. Asbestos Project Monitor Course:

1) Until 7/20/00, existing DPH Licensed Project Monitors may take either the Project Monitor or Supervisor refresher course to maintain their Connecticut Accreditation as a Project Monitor.

2) Initial Project Monitor course is of course needed for new Project Monitor licensing / certification applicants.

3) After 7/20/00, the Project Monitor refresher course is mandatory in Connecticut for maintaining or obtaining this Accreditation.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4) Those working out of State should always check with the particular state to verify the requirements. (We have been informed that those working as Project Monitors in Mass or NY should take the Project Monitor course since they do not accept the Supervisor refresher for licensing as an Monitor.)

b. Asbestos Inspector Refresher: This course is now four hours; and it can't be combined as a four hour course with the Inspector Management Planner refresher.

E. ASBESTOS IN SCHOOLS: Connecticut General Statutes Sections 19a-333-11b

Has all the requirements of AHERA But Stricter or more detailed in several respects:

- 1. Need permission to do abatement while school is in session.**
- 2. Final clearance clarification on not dividing areas in order to do only PCM finals.**
- 3. Procedures for fiber release episodes.**
- 4. Added Requirements for response action recordkeeping. See the check list with the handout on W.W.W.Chem-scope.com.**

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

F. OTHER STATES: Updated 5/12/04

1. Before considering working out of state, obtain the latest regulations from the state and determine if licensing is required.

2. CONES: Consortium of North East States:

a. The following states are members, require licensing and have training reciprocity:

State	Asbestos Contact/ Phone
CT	DPH/ (860) 509 7559 (860) 509 7367
MAINE	DEP ASB CERT COORDINATOR (207) 287 2651
NJ	DEPT OF HEALTH ENV HEALTH SVCES (609) 984 2193
NY	DEPT OF HEALTH ASB SAFETY TRAINING PROG. (518) 402 7940
MASS	DLI DIV ASB/LEAD LIC AND ENFORCEMENT (617) 727 9612
NEW HAMP.	BUR OF HEALTH RISK ASSESSMENT, (603) 271-5870 ASB MGMT CONTROL PROGRAM (603) 271 4609
RHODE IS.	OFFICE OF OCC. AND RADIOLOGICAL HEALTH DEPT OF HEALTH (401) 222 7795
VERMONT	DEPT OF HEALTH ASB AND LEAD REGULATORY PROGRAM (802) 863 7231

b. Remember One must pay a fee to any of these states and obtain a license before working there in the asbestos field.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 2-4

DOT Regulations

US Department of Transportation Regulations (DOT)
CFR 49 Parts 171-173

- 1. Research and Special Programs Administration is an arm of DOT which regulates hazardous material transportation including asbestos.**
- 2. Amended regulations were published in the Federal Register on 12/21/90 which became effective on October 1, 1991:**
- 3. Asbestos was divided in two categories which are now obsolete. See revisions below.**
- 4. On Oct 1, 1992 Editorial and Technical Revisions were published which simplified the rule:**
- 5. One shipping description of NA 2212.**
- 6. Up to 440 lbs of asbestos allowed on cargo aircraft.**
- 7. A placard is needed for shipments over 440 lbs.**
- 8. Drivers must have function specific training. OSHA hazard communication training EPA training is sufficient if it covers DOT topics.**
- 9. Small shipments such as samples are generally exempted unless they contain a pound or more of friable asbestos. Even so, the following exemptions apply:**
- 10. Less than 66 lb package with inner packages securely wrapped and not exceeding 11 lbs each are exempt from marking and labeling for ground transportation.**
- 11. If the entire package is less than 64 lbs and the inner packages are less than one ounce (30 grams) each and inner containers are at least 8 mil plastic, glass, metal or earthenware.**
- 12. Non-friable ACM is exempt.**
- 13. Manufactured products are exempt.**
- 14. Air samples are in practice exempt.**
- 15. For most abatement wastes, the shipping papers need to have the following information:**

RQ- 1 LB (REPORTABLE QUANTITY)
NAME: ASBESTOS NA 2212
HAZARD CLASS: 9
MIXTURE
PACKING GROUP III
TOTAL QUANTITY _____

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

16. DOT Labels:

Usual OSHA label may be used on the package unless it is over 66 lbs in which case the following added label is needed:

RQ- 1 LB (REPORTABLE QUANTITY)

NAME: ASBESTOS WASTE MIXTURE NA 2212

NAME OF THE CONSIGNEE OR CONSIGNOR

(EPA NESHAP also requires the container/truck be labeled during loading and unloading)

Section 2-5

DEP Disposal Regulations

Connecticut General Statutes Sec 22a-209-8 (i) (DEP Applies to Waste Disposal in Connecticut)

Connecticut DEP: Any disposal of Asbestos in the State of Connecticut must be authorized by the office of Solid Waste Management. To request a disposal permit, contact the Solid Waste Management Unit at 566-5847.

Twenty five day notification must be sent to:

State of Connecticut
Dept. of Environmental Protection
Solid Waste Management Unit
79 Elm St.
Hartford CT 06106

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

SECTION 3

UNDERSTANDING FACILITY CONSTRUCTION AND FACILITY SYSTEMS

A. PHYSICAL PLANT LAYOUT

1. Core Areas

- a. Corridors/ entries
- b. Stairwells
- c. Main Office
- d. Cafeteria- kitchen -break areas
- e. Athletic/Recreational
- f. Library- media - conference areas
- g. Mechanical areas
- h. Custodial areas
- i. Medical

2. Room Areas

- a. Offices
- b. Classrooms
- c. Production areas
- d. Storage areas

3. Exterior

- a. Under portion of Porticos (Outside covered walkways)
- b. Outside freezers
- c. Roof mechanical rooms and air intakes and exhausts
- d. Any outside buildings, garages or sheds
- e. Window caulk
- f. Roofing felts and tar
- g. Siding, signs and trim

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

B. BUILDING CONSTRUCTION

1. Drawings and Plans:

- a. Architectural Drawings: show the building structure or design.
- b. Building Drawings: contain structural details or blueprints.
- c. Floor Plans: Schematic layout of the building showing building spaces.
- d. Master Riser Plan: Three dimensional building layout.
- e. As Built Drawings: Locations of electrical or mechanical features as actually built.
- f. Mechanical Drawings:
 - 1) Plumbing
 - 2) Electrical
 - 3) HVAC
- g. Framing Plan: Shows vertical columns and supports of the building.
- h. Site Plan: Shows arrangement of buildings on the property and other details which may include roads, utilities, underground tunnels, and dimensions.

2. Consolidating Building Layout Information:

- a. Start with Floor Plans
- b. Interview of Building Staff Familiar with Building History:
- c. Personal Investigation:
 - 1) Walk the building exterior and the roof.
 - a) Look for building additions evident from different type, texture and colors of:
 - Brick
 - Block
 - Poured concrete
 - Other exterior building materials
 - b) Look for:
 - Partial building floors
 - Mechanical protrusions
 - Exterior entry to storerooms
 - Outbuildings
 - Suspect materials on underside of exterior porticos.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- c) Locate roof drains.
 - d) Gross measurement of building dimensions.
- 2) Walk corridors and representative rooms to obtain a sense of the building and the composition of the building materials.
- 3) Proceed to the mechanical areas of the building. How does building heat distribute to the room spaces? Is there a HVAC? Does for example, the system have steam or hot water heat.

C. FACILITY SYSTEMS, WHERE ACM IS FOUND:

1. Mechanical Systems and Areas

ACBM may be concentrated in mechanical areas. The following is a list of areas and key items.

a. Boiler Rooms:

1) Boiler:

- a) May be original or added with new wing construction.
- b) Usually more than one boiler:

Are they all the same? If not, you can expect different homogeneous areas of boiler and pipe insulation throughout the building.

- c) External: Is the boiler insulated with an exterior cement jacket, cast iron clad, aluminum or sheet metal clad over insulation?
- d) Internal: Always assume there is internal ACBM unless there is certification that the boiler is asbestos free.

e) Oil Fired units:

Most institutional boilers are oil fired with steam or hot water feed to room heat exchangers. Find out what grade of oil is used. Heavy grades of oil require heat tracing from outdoor tanks and usually asbestos insulated plumbing.

- f) Gas Fired Units: Gas inlet lines are usually not insulated.
Newer systems may be direct hot air or may circulate water or steam to air handlers which exchange heat into hot air ducts.

g) Boiler Exhaust System:

Fire box
 Manifold
 Breeching
 Chimney

More than one boiler may feed to the same breeching via individual exhaust headers which will be perhaps a third the size of the breeching diameter.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2) Pipes: Most pipes originate in the boiler room.

a) Pipes may have different insulation composition:

- Fuel feed
- Circulating water feed and return
- Water or steam take away and return lines
- Domestic hot and cold water lines
- Different diameters

Fittings vs runs

Pipe joints including T's, L's, flanges, I's and other transitions including sites where pipe hangers are attached are often of different composition than the pipe run insulation.

b) Types of Insulation on pipes:

- Air-cell - honeycomb paper, usually ACBM
- Cementitious - ACBM or other
- Wrapped paper - ACBM or other
- Black tar coated - ACBM or other
- Foam - ACBM or other

Wool types. - ACBM or other

Fibrous glass with asbestos - ACBM or other

Rock wool or mineral wool. - ACBM or other

Modern fiberglass insulation, usually pink or yellow- not ACBM. Sometimes fiberglass insulation is used for runs and asbestos or non-asbestos cement for fittings.

c) Pipe Paths through Building:

Protrusions of pipe from the boiler room determine the likely path of flow through the building. Does the pipe run overhead to perhaps above drop ceilings? Does the pipe run through a pipe tunnel system?

Are there crawl spaces and tunnels directly accessible from the boiler room?

Do risers run inside walls in pipe chases or protrude into rooms?

3) Hot water tank- condensate tank

4) Cooling Units: Central air conditioning compressors may be located in the boiler room. Here you will see another selection of insulated pipes and ducts. The ducts may be insulated outside and occasionally inside. Be watchful for interior duct insulation. Ducts usually have expansion and vibration joints which may be asbestos containing.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. HVAC: (heating, ventilation, and air conditioning system) Physical Organization:

1) Basic components:

- Fans
- Ducts
- Heat exchangers
- Heat source such as a boiler
- Compressor or other form of chiller.

2) Operation:

- Heat or cooling source
- Heat exchangers
- Air inlets
- Air returns
- Fresh make up air added- about 10%
- Humidity may be added.

3) Flow Path:

- Overhead
- Other
- Inlets: Ducted
- Returns:
 - Ducted or
 - Natural building space used for Return air

Many configurations are used for heating and air conditioning of buildings.

In particular, note where asbestos materials are near air intakes or may otherwise be distributed through the building.

4) Spreading Contamination by Air Transport:

Air transport is a major factor in spreading asbestos contamination; HVAC insulating materials and flex joints frequently contain asbestos.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

5) Where ACM is found on HVAC Components:

Exterior of air ducts may be a soft friable cement board which is glued and wired onto the duct

Troweled on cement may be used at joints.

All of this may be covered with canvas, foil or paper.

A gray white asbestos paper is sometimes glued directly on the ducts.

Exhaust ducts around kitchens may have a loose, fluffy spray on or troweled on amosite insulation.

Asbestos insulation is rarely used inside of ducts, but the inside must be accessed to be sure. Investigation inside air handlers is often the best way to determine the presence of interior duct insulation.

Fiberglass insulation with foil wrap is commonly used in air system ducts. Always watch out for asbestos cement tipping at hangers and joints.

Duct joints may be connected by flexible duct connectors. These may contain asbestos or not. A gray white fabric is almost always ACM. Black rubber may be asbestos or not. Vibration dampers connecting fan units to ducts may be of the same composition as the duct connectors.

c. Room Heat Exchangers and Duct Inlets and Returns

1) Piping path from the mechanical room to the room heat units:

Pipe tunnel?

Pipe travel over drop ceilings, inside walls, exposed?

Pipe risers to upper floors inside walls or accessible?

2) Duct path to the rooms:

Is space over the drop ceiling a **return air plenum**? This means that return air is not ducted back from the room to the air handler but at least partly travels in the space above the drop ceiling.

General path?

Type of insulation? (if none report bare metal)

3) Nature of the room heat exchangers:

Baseboard, radiator, blower units, etc?

Asbestos in the room heat exchangers?

Asbestos paper insulation on walls?

Asbestos pipe insulation?

Transite panel inside below or behind?

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

d. Electrical System:

1) Safety:

- a) Sampling and intrusion into electrical systems is generally not done for safety reasons.
- b) Visual observation of opened panels, exposed wires and other equipment: Suspect materials should be noted in the report. These should be more closely inspected before renovation or other disturbance and only when the electrical system is shut down.

2) Applications:

- a) Asbestos cloth insulation is used in older wiring service. This type of insulation is easily recognized by its woven or braided appearance, fibrous texture and gray color.
- b) Asbestos transite sheet may be used in panels transformers, motors or boxes and in any portion of the electrical system.
- c) Asbestos cement or paper may be used in older fluorescent fixtures and inside built-in spotlight fixtures and ceiling or wall protrusions.

2. Ceiling Construction

a. Surfacing Materials

1) Hard plaster construction:

Support of steel mesh or wood slat - metal or wood lathing.

Base plaster coat is usually a mixture of lime, sand and animal hair called "brown coat". The dried coating is hard cement and coarse textured.

Finish plaster "lime coat" is generally applied over the brown coat. This is a mixture of plaster of Paris and lime.

This coating when dry is very hard and smooth.

Asbestos may be added to either the brown or finish coat plaster usually by choice of the installer.

2) Softer white troweled on cement - frequently asbestos containing and may be applied directly on lathing or over concrete or plastered ceiling. Sounding the surface is a good practice since both hard non asbestos and soft asbestos surfacing may be used in the same building.

3) The ceiling is the more likely place to encounter asbestos surfacing as compared to walls. Hallways, stairwells, under stairs and above heat sources such as boilers are more likely to have asbestos surfacing for fireproofing than rooms.

4) Plaster board is a more modern preformed plaster section which is nailed onto studs and finished with a finish coat plaster. The latest version is called sheetrock. Any of these boards or the finish plaster or taping compound may contain asbestos.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. Ceiling tiles and panels:

- 1) Acoustical tiles, usually 12x12 inches may be glued onto ceilings or upper walls directly or glued onto furring strips.
- 2) Fixed Ceilings; In renovation, drop ceilings may be fixed ceilings of sheetrock, Acoustical tile on lathing or separate plaster ceilings. Typically in renovation such ceilings are usually more prevalent in rooms than in halls. Hall ceilings are more likely to be lay in drop ceiling panels because of the need to access mechanical components frequently found in halls.
- 3) The lay in drop ceiling, usually 2x4 or 2x2 ft panels laid on a metal grid afford easy access to inspect above. The metal "T" grid is typically suspended on wires.
- 4) Composition: Ceiling tiles and panels have various compositions both asbestos and non asbestos containing. Cellulose and mineral wool are commonly used with or without asbestos.

c. Miscellaneous:

- 1) Asbestos containing paint is more likely to be present in ceilings than elsewhere. Ceiling tiles or finished surfaces may be painted with asbestos containing paint for strength or noise control.
- 2) Concrete ceilings are sometimes the finished ceilings in lower floors and mechanical areas. Four x eight ft panels of various compositions may be attached to the ceilings.

3. Wall Construction:

- a. Plaster or sheetrock of the same type as used in ceilings may be used in the wall construction.
- b. Exterior and interior walls may be of different construction.
- c. Homosote and fiberboards are commonly used.
 - 1) Homosote is a gray fibrous, usually non asbestos board.
 - 2) Fiberboards are usually cellulose and rarely contain asbestos.
- d. Transite asbestos panels may be used in wall construction, especially on outside walls and behind radiators or as door or window panels.
- e. Halls and some rooms may not have finish wall construction and may be cement or cinder block or poured concrete.
- f. Frequently sheetrock is added in renovation to modify rooms. Taping compound more frequently contains asbestos than does the gypsum panels themselves. There may be many different types and vintages of sheetrock.
- g. Block walls behind finished walls occasionally have ACM tar.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Floor Construction:

- a. Substrate: usually concrete or board "hardwood" flooring.
- b. Vinyl tile.
 - 1) Older 9x9 inch type commonly called VAT (vinyl asbestos tile)
 - 2) Newer 12x12 inch tile, commonly called VCT (vinyl composition tile)
 - 3) Linoleum and its backing
 - 4) Mastic adhesive on any flooring is likely to be ACM. Even fairly recently installed mastics are frequently ACM.
 - 5) Multiple layers of floor tile or linoleum.
 - a) Plywood used to cover old vinyl flooring.
 - b) Flooring composition should be treated as unknown unless samples have been taken down to the slab" or to the wood plank substrate.
 - c) One should be able to distinguish a plywood layer from hardwood flooring. The easiest method is to expose at least a 6-inch area and look for the plank edges or grooving which is characteristic of hardwood floors.
- c. Carpet
 - 1) Mastic used to glue the carpet is sometimes ACM
 - 2) Other flooring including tile and mastic may be under the carpet.
- d. Baseboard with mastic or glue

Mastic or glue used to adhere the baseboard to the wall is frequently ACM.

5. Deck and Roof Underside:

- a. Spray on surfacing on steel decking and beams.
 - 1) Easy to recognize from the gray cotton candy like appearance.
 - 2) Detected quickly in areas with no drop ceilings or above lay in drop ceilings.
- b. Roof drains may be asbestos insulated steel or made of hard asbestos cement. These may be located from outside as mentioned above.
- c. Troweled on asbestos insulation may also be used in high rooms such as gyms and auditoriums. From a distance, these may appear to be concrete or plaster. It is essential to access these for close up observation.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

6. Exterior Considerations

a. Underside of porticos and covered walk ways:

- 1) Troweled on asbestos cement
- 2) Asbestos transite panels.

b. On the roof

- 1) Evaporative cooling units
- 2) Fan rooms,
- 3) Friable materials near air intakes.

D. EFFECT OF RENOVATION AND ASBESTOS ABATEMENT ON FACILITY SYSTEMS:

1. General

a. Scheduling

1) Building occupancy-

- a) Off hours when building is vacant
- b) Which areas are available first

2) Problems with Multiple Work Areas done at once. Cross contamination possibilities due to air flow and need for extra makeup air.

3) Notification and relocation of occupants

4) Testing turn around time accelerated

5) Is the scope of asbestos removal work adequate to protect against remaining ACM being disturbed?

If not, two or more stages of ACM removal may be needed, dovetailed with progressive demolition.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. Staging of Work

- 1) Disconnection and isolation of HVAC
- 2) Locations for Negative Air. Exhausts not near building air intakes or occupied areas.
- 3) Guarding the Work Area against unauthorized intrusion.
 - a) Posting additional demarcation.
 - b) Barriers
 - c) Supervisor person posted at entries
- 4) Ensuring proper decontamination procedures.
- 5) Extra Negative Air and strategic placement.
- 6) Ceiling Management above drop ceiling systems.
- 7) Maintenance of Enclosure Systems.
- 8) Special safety problems due to building contents.

c. Extra Monitoring Recommendations

- 1) Area samples outside the Work Area during removal
 - a) Approach corridors
 - b) Outside the Decon
- 2) Air samples in Negative air exhausts
- 3) Monitoring of Negative Air flow in addition to room pressure.

d. Education of Occupants

- 1) How the abatement enclosure and negative air systems work.
- 2) How decontamination procedures are followed
- 3) About the monitoring used
- 4) Keeping out of the area until final clearance is completed
- 5) Methods agreed on to notify occupants when clearance is completed.
- 6) Emergency access provisions such as:
 - a) Safe passage areas
 - b) Specialized trades needed for access to mechanical areas undergoing abatement.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

e. Other Considerations

- 1) Maintenance of escape routes
- 2) Privacy and locations of Decons and egresses
- 3) Special problems with waste storage facilities.
 - a) Labeling
 - b) Locked
- 4) Use of facilities
 - a) Bathroom
 - b) Staging area for equipment storage
 - c) Break area
 - d) Work Area Entrance
 - e) Waste Material Egress
 - f) Vehicle parking
- 5) Fire safety needs
 - a) Sprinkler and alarm management
 - b) Escape routes and evacuation plan
 - c) Notification to fire marshall
 - d) Fire fighting equipment
 - e) Training
 - f) Careful examination of electrical supply, equipment and outlets.
 - g) Need to avoid flammable and combustible liquids

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Boiler or HVAC Replacement:

- a. Boiler temporary shut down
- b. Insulation removed from nearby piping and vessels.
- c. Interior ACM removed
- d. Converting from Steam to Hot water
 - 1) Heating Pipes and heat exchangers replaced
 - 2) Insulation to be removed first
 - 3) Replacement of equipment
 - 4) Reinsulation
- e. Converting from Oil to Gas-Fired units:
 - 1) Fate of heat tracing from outdoor tanks and asbestos insulated plumbing.
 - 2) Gas inlet lines are usually not insulated.
- f. Converting from Pipes to Ducts or HVAC Replacement:
 - 1) Complete ceiling demolition is usually required, especially in corridors. All suspect materials to be identified and usually removed.
 - 2) Ducts need more room than pipes.
 - 3) Large wall and ceiling penetrations to make for ducts (plaster and sheetrock need to be checked).
 - 4) Cooling Unit replacement:

3. Electrical System Upgrade:

- a. Safety and need for shut down:
- b. Penetrations
- c. Asbestos insulation removal
- d. Asbestos panel and gasket removal.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Ceiling and Wall Demolition

- a. When can ceiling and wall demolition be done by demo contractor and when is a licensed asbestos contractor needed?
- b. Movement of ACM beyond demolished surfaces
 - 1) Need to provide for excess negative air and contamination control
 - 2) Need to provide for extra air monitoring
 - 3) Need to determine where fire stop walls exist vs mere partition walls.
- c. Advantage of removing skim coats when deep plaster is non-ACM.
 - 1) Need for close inspection for remaining skim coat
 - 2) Provision for bulk sampling of surfaces
- d. Ceiling tiles and panels:
 - 1) Extent of demolition usually includes all support systems.
 - 2) Glue dobbs
 - 3) Extension of containment walls above the drop ceiling
 - 4) The same considerations as for ceiling demolition are needed, extra negative air, etc.
- d. Fire doors
- e. Casework
- f. Window and potential asbestos caulking
- g. Is wall on top of ACM flooring?

5. Flooring Abatement:

- a. Substrate composition is critical. Mastic can't usually be removed from wood flooring without floor demolition.
- b. Multiple layers of vinyl flooring and mastic.
- c. Carpeting and carpeting mastic; VAT under the carpet.
- d. Cutting channels for utilities
- e. ACM flooring under cabinets or walls to remain?

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 4

Asbestos Abatement Contracts, Specifications and Drawings
Common Enforcement Responsibilities and Authority of Project Monitor;

Key Terms:

Addendum: A change in the work usually before the bid but always before the contract signing.

Add-Option: Optional work itemized in the bid form which may or not be done.

Base Bid: The price bid for work that is in the Scope of Work but not including any add options.

Bid Opening: The deadline for bids to arrive at a specified location, and the time the bids are to be opened after.

A.I.A. American Institute of Architects. A.I.A. sells blank contract forms for construction contracts.

Change order: A change in the work after the contract signing. This is the owner's acknowledgement of extra or less work to be done which differs from the original contract. "Add-on" or "extra".

Liquidated damages: A daily penalty the contractor pays when the completion of the job is not on schedule.

To waive formalities: The building owner may waive contract requirements at his discretion. For example, the contract calls for 2 million dollars insurance and the owner allows 1 million.

Waiver of lien: Building owner may require the contractor to get the subcontractors to fill out a document acknowledging that the contractor has paid the subcontractor and there will be no building owner liability as the result of subcontractor's claims in the future.

Unit price: The charge per given unit of work such as dollars per man hour, per square foot, etc.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

A. BASIC PROVISIONS OF THE CONTRACT

1. Invitation to bid

- a. Bidding Instructions
- b. Information for bidders
- c. Submittals
 - 1) Completed Bid Reply Documents
 - 2) Bid bond and performance bond
 - 3) Qualifications of Contractor AIA Form 305 or equivalent form.
 - 4) Insurance Coverage
 - 5) List of all subcontractors to be used

2. Technical Specifications

- a. Scope of work
- b. Principal Regulations
- c. Air Monitoring Program
- d. Notifications
- e. Submittals Prior to Commencement of Work
- f. Site Condition
- g. Personnel Protection
- h. General Work Sequence and Conditions
- i. Materials, Tools and Equipment
- j. Preparation and Maintenance of Work Areas
- k. Right to Stop Work
- l. Asbestos Removal and Cleanup
- m. Final Clearance and Restoration of the Work Area
- n. Disposal
- o. Terminology
- p. Drawings

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. Agreement portion of Contract

- a. Definitions
- b. Description of Work
- c. Payment
- d. Performance, Maintenance and Payment Bond
- e. Time of Completion
- f. Insurance
- g. Guarantee / Defective Work
- h. Compliance With Laws
- i. Indemnity
- j. Patents
- k. Changes/ Extra Work
- l. Liens and Claims
- m. Abandonment of the Work or Other Default
- n. Permits
- o. Not to Sublet or Assign
- p. Employ Competent Men and Sufficient Labor and Equipment
- q. Access to Work/ Examination of Work
- r. Retainage
- s. Special Conditions/ liquidated damages
- t. Addenda / Change Orders
- u. Submittals

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

B. KEY ISSUES

1. **Scope of work- list of the work to be done.**
2. **Unusual requirements in the execution of work which will cost more money to do.**
3. **What work is provided by others? For example: moving furniture, stored material and equipment out of the Work Area**
4. **Who provides and installs replacement materials?**
5. **Is water and electricity provided at the site?**
6. **Who pays for Air Monitoring Services? Who pays for personal air samples?**
7. **TEM vs PCM, optional daily monitoring requirements, etc.**
8. **Dates of administrative events especially the walkthrough, and bid opening**
9. **Who obtains building permits and gives notifications?**
10. **Any problems shutting down electric power including receptacles and lighting fixtures?**
11. **Any problems shutting down heating, cooling and ventilating air systems?**
12. **Disposition of movable objects within the Work Area. Disposition of items like ceiling tile and carpeting.**
13. **Provisions for building or fixture damage**
14. **Special problems with DPH notifications**
 - a. **Subcontractors**
 - b. **Demolition to take place after asbestos removal.**

C. RELATIONSHIPS BETWEEN PRINCIPAL PARTIES AND ESTABLISHING CHAIN OF COMMAND

1. **Owner**
 - a. **Pays for the work**
 - b. **Ultimately responsible for the hazards in the facility**
2. **Architect:**
 - a. **Designs the overall construction project**
 - b. **Usually coordinates all phases of construction.**

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. Asbestos Project Designer

- a. Design of the asbestos abatement portion of the construction project
- b. Usually conducts the bid walkthrough
- c. May help evaluate the bids for asbestos abatement.

4. The Engineer

- a. Structural and mechanical aspects of new installations or demolition
- b. Plumbing, HVAC, electrical or other specialized work.
- c. Structural Engineers deal with buildings
- d. Civil Engineers deal with building grounds
- e. Electrical engineers are involved with electrical requirements
- f. Mechanical engineers deal with various types of equipment.

5. Project Monitor

- a. Should be involved in the pre-abatement meeting with the asbestos contractor and obtain needed submittals at that time.
- b. Monitors the abatement response actions
- c. Enforces the specification (See Section 4 and Section 10-1)

6. General contractor

- a. Demolition
- b. New Construction

7. Abatement Contractor

- a. Abatement
- b. Restoration of the area

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

8. The Team

- a. The architect will turn over his demolition requirements and drawings to the asbestos project designer.
- b. The engineer will turn over his mechanical requirements and drawings to the asbestos project designer as well as to the architect.
- c. The designer will develop the drawings for his use and write the technical portion of the asbestos abatement specifications.
- d. The designer, the architect or sometimes the Owner will produce the agreement portion of the contract documents.
- e. The Project Monitor is usually the individual (or firm) who does the enforcement of the asbestos technical specifications.

D. TYPES OF SPECIFICATIONS

1. Means and Methods Approach:

- a. The means and methods specification delineates how to accomplish the work. They typically specify proprietary or non-proprietary materials and procedures.
- b. More uniform bid results biased by the specification and may be higher bids or lower bids than really needed to accomplish the work.
- c. More liability on the part of the designer:
 - 1) Contractor may fail to accomplish the desired result.
 - 2) Injury or damage may result.
 - 3) The product specified may not be adequate.
 - 4) The contractor can always blame the designer's choice of methods or materials as an excuse for poor application.
 - 5) May be required by regulations.

2. Performance Specification:

- a. The performance specification defines the final result and generally indicate the type of material and methods to be used.
- b. Allows the contractor flexibility of using his particular expertise.
- c. Clearly puts the burden on the contractor who has accepted the task.
- d. Complies with government policies to avoid endorsement of proprietary materials.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

E. READING AND INTERPRETING RECORDS AND ABATEMENT DRAWINGS

1. Significance and Need for Drawings

- a. Avoiding disputes on how the Work Area is to be set up- diagramming of containment barriers.
- b. For the future, avoiding disputes on how the Work Area was set up, for example residue found in supposedly adjacent areas.

2. Types of Drawings:

a. As built drawings:

- 1) Often referred to as existing drawings
- 2) Supposedly show the way a facility was actually built.

b. Architectural Drawings:

- 1) Show finished surfaces and materials.
- 2) Floor plans: Schematic layout of the building showing building spaces as viewed from above i.e top view.
- 3) Demolition plan: shows items to be demolished
wall sections
- 4) Elevations: layout as viewed horizontally - i.e. side view
- 5) Finish schedules

c. Structural Drawings:

- 1) Foundation plans
- 2) Framing plans show vertical columns and supports of the building.
- 3) Structural elevations
- 4) Details of columns and beams or girders (column lines)

d. Site Plan:

Shows arrangement of buildings on the property and other details which may include roads, utilities, underground tunnels, and dimensions.

e. Mechanical Drawings

- 1) Plumbing
- 2) Electrical
- 3) HVAC
- 4) Equipment

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. Reconciling the Drawings and Specifications with the Building:

- a. Obtain the cleanest possible copies of the specification floor plans and reproduce extra copies for marking up with sample locations and other details.
- b. Verify plans during initial site walk through.
- c. Identify spaces on the drawings by the same name and/ or number as in the specification.
- d. Verify the Scope of Work for asbestos abatement by comparing the building with the specification and drawings.

F. CHANGE ORDERS;

1. Change in the scope of the work, schedule or other substantive work item.

2. Usually costs owner more money

3. Try to determine the reason for the change order

- a. Was change initiated by owner.
- b. Error or omission on the part of designer or architect or marginal inspection work.
- c. Unforeseen / concealed materials
- d. Change in the schedule

4. Should be written change orders.

G. DISAGREEMENTS

1. Between plans and specifications -

- a. Specifications and drawings should "say" the same thing, only in a different way and level of detail.
- b. Specifications take precedence over drawings (plans).

2. Between specifications and regulations:

The more stringent requirement takes precedence.

3. Between plans and specifications vs what is actually on the site:

For example, if more ACM is found than specified, or a type of ACM not specified, then a change order would be appropriate. This can be a far reaching problem. Suppose for example that only floor tile removal was specified in the area but removal of the drop ceiling also showed up pipe insulation that needs to be removed. If there was an AWP (alternate work practice approval) for floor tile only with single layer of poly, then you have to add the extra poly or make a full mini containment for the pipe insulation and a separate work area and clearance for the pipe insulation area and the floor tile area. You should notify the DPH of the change. It also may be possible to modify the AWP to allow glove bagging the pipe insulation (if in small enough amounts) within the floor tile containment). This could delay the project by 10 days for AWP approval.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

H. COMMON ENFORCEMENT RESPONSIBILITIES AND AUTHORITY OF PROJECT MONITOR;

(See Sections 1-1 and 10-1)

- 1. All authority over others on the job must be delegated by the owner.**
- 2. The Project Monitor is generally responsible for compliance by others on the job and can be cited if others he is watching are out of compliance.**
 - a. Enforcement of specifications and regulations
 - b. Interpretation of specifications vs any disputes or questions
- 3. The Project Monitor is directly responsible for his own work as well.**

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 5

ASBESTOS ABATEMENT EQUIPMENT

RESPONSE ACTIONS AND ABATEMENT PRACTICES

Section 5-1

Equipment

A. EQUIPMENT AND SUPPLIES OVERVIEW:

1. HEPA Filtration

- a. HEPA Filter: high efficiency particulate air filter.
- b. Designed to trap **99.97% of particles** >0.3 microns.

2. Negative Air Units:

- a. Machines that must produce at least four air changes/ hour in each Work Area.
- b. 0.02 inches of water negative pressure in Work Area
- c. Air monitoring of the HEPA unit exhaust is very important to ensure that filters are properly working.
- d. Accessories include exhaust and intake ducts and flanges and adapters to connect the duct work, and spare filters.
- e. True flow with some units may be 75% of stated flow.
- f. Flow drops as filters plug and with longer duct runs.
- g. Can't assume theoretical flow is correct. Flow should be monitored and pressure must be monitored.
- h. Calculated flow needed for an area is: room volume in cubic ft divided by 15 to obtain a theory of 4 air changes/hour.

3. HEPA Vacuums

- a. A vacuum cleaner with a HEPA filter.
- b. Air sucked into the cleaner first goes to a vacuum bag, then to a secondary filter and finally to the HEPA filter.
- c. Never use an ordinary vacuum cleaner since it will blow out fine ACM dust.
- d. Most HEPA vacuums move about 200 CFM (cubic ft/min) of air through the filter.
- e. Used for cleaning surfaces before, during and after abatement
- f. Used for cleaning self before leaving Work Area

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- g. Operating instructions provided by the manufacturer of the machine are to be followed.
- h. See that attachments are available which are appropriate for use on each type of surfaces including brushes of various sizes, crevice tools, and angular tools.
- 1) Brush tool for walls, fixtures and woodwork.
 - 2) Wheeled floor nozzle for bare floors
 - 3) Carpet beater for carpets
 - 4) Rubber cone where the floor meets the wall and other cracks.
 - 5) Slender and long plastic fitting for between radiator sections.
- i. Filter change:
- 1) When machine flow begins to get restricted.
 - 2) In a contained area.
 - 3) Full set of protective clothing including appropriate respirator.
 - 4) Usually change bag and prefilter first and see if the flow is OK.
 - 5) Hose must be checked for blockage and cleaned by suction from a second HEPA unit. Do not blow out the hose since this will contaminate the area.
 - 6) Check gaskets, filters and vacuum bag for tears.
 - 7) A second HEPA unit can be used to advantage to clean out the unit being serviced.
 - 8) Use extreme caution to avoid release of asbestos dust into the environment.
 - 9) Used HEPA filters and vacuumed debris are to be included with the asbestos waste.
 - 10) After the servicing, the machine should be turned on to check the operation.
 - 11) Room surfaces near the filter change must be cleaned up.
- j. Check daily for damage, especially power cords and switches.
- k. At the end of the job before the cleaner is to be taken out of the Work Area, it is to be sealed in leak proof wrapping after doing the following:
- 1) Clean each attachment by sucking through the vacuum while tapping and wet wipe each attachment. Place the cleaned parts in a sealable plastic bag.
 - 2) Suck out and seal the end of the hose with duct tape to prevent dust from leaking.
 - 3) Unplug and damp wipe the unit clean.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. The Decontamination Unit (See drawings in the handout on W.W.W.Chem-scope.com.)

See OSHA regulations on pages 30-47 and DPH regulations on page 56-67.

- a. Equipment Room: contaminated area next to Work Area
- b. Shower Room: contiguous to and between equipment room and clean room.
 - 1) Hot and cold or warm running water
 - 2) Non-transparent Polyethylene
 - 3) **Waste from the shower filtered with finest filter porosity before discharge to a sewer**
 - 4) For each sex: one shower per 10 employees and soap.
- c. Clean Room:
 - 1) Storage of street clothes
 - 2) Change area
- d. Each room separated by an airlock

5. Airless Sprayers

- a. Used to spray encapsulant and surfactant.
- b. Airless sprayers really use air but the air is not mixed with the spray.
- c. Fine spray is important
- d. Critical to clean nozzle after use

6. Chemicals

- a. Amended Water
- b. Encapsulant (sealant)
- c. Spray Glue
- d. Mastic remover

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

7. Waste Disposal Containers

- a. Water and air tight.
- b. Must be labeled in large legible letter:
 - DANGER
 - CONTAINS ASBESTOS FIBERS
 - AVOID CREATING DUST
 - CANCER AND LUNG DISEASE HAZARD
- c. Double 6-mil polyethylene bags or special drums
- d. Bulk storage and transportation vessels must be air and dust tight
- e. May be specially lined dumpsters or trucks.
- f. Vacuum transfer devices and receptacles may be used provided the transfer and storage is contained to permit no dust evolved to the building or outside air.

8. Wet Cleaning Equipment:

Cloths, mops, rags, towels and sponges or other cleaning tools which have been dampened with amended water. See page 112.

9. Personal Protective Equipment (PPE):

Protective clothing, respirators, etc. Details will be discussed on pages 129-131.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

B. DETERMINING THE EFFECTIVENESS OF AIR FILTRATION EQUIPMENT;

Air velocity = Distance air travels in a unit of time. (e.g. ft/minute, or fpm).

Volume flow = air velocity times the cross sectional area of a duct, e.g. (fpm) (f^2) = CFM (cubic ft / minute).

1. Air Filtration Devices and Vacuum Systems: Design and Construction of HEPA Filtration Units

a. Theory of air filtration and HEPA filter design,

- 1) Air filtration is a process by which particles are trapped by a medium and air and very fine particulates are allowed to pass through.
- 2) Force is needed to push or pull the air through the filter medium, consisting of pressure or vacuum. Pressure is defined as force per unit area.
- 3) If we make a fine porosity filter, this creates resistance to flow so a lot of pressure or vacuum is needed to move the air through the filter medium. This creates a back pressure at the filter inlet. The difference between the pressure at the inlet and outlet of a filter is called a pressure drop. Pressure drop increases as filters become loaded with particulates.
- 4) HEPA filters are specially designed with a lot of surface area to compensate for the resistance of the filter. They are tested with aerosols such as dioctyl phthalate atomized into the air to determine the retentivity in microns. (99.97% of particles >0.3 microns.)
- 5) Larger particles are more easily trapped and can be captured simply by a change in direction or by more porous openings. Pre-filters in front of the HEPA filter are used to take load off and to delay plugging the fine HEPA filters. The HEPA element is pleated into a honeycomb pattern many times to increase the surface area and arranged in a housing to allow the flow to access all pleats.
- 6) Humidity, temperature and vibration all have effects upon filtration efficiency. Particle shape, mass and size are also important.
- 7) As filters are used, particles trapped block the pores or holes of the filter and create more resistance to flow (more back-pressure).

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. Negative Pressure Differential Monitoring: Measurement of Differential Pressure and Flow Rate of air

- 1) The differential pressure is the difference in pressure between one location and another- as inside vs outside the containment.
- 2) The pressure has two components: static pressure and velocity pressure. When air is forced to move by a fan, the moving air acquires a force or pressure component in the direction it is moving due to its weight and inertia. This force is called velocity pressure. In operating a duct system, a second pressure is also always present; it is independent of air velocity or movement and is called static pressure. In a system, static pressure will be positive on the discharge side of the fan and negative on the inlet side. Total pressure is the combination of static and velocity pressure and is expressed in the same units. Manometers can be used to separately measure the static pressure and total pressure and calculate the velocity pressure by difference. If there is no flow, then all the pressure is static. In practice, on asbestos projects we will use "total pickup sensors" which combines the results of static and velocity pressures.
- 3) Manometers. The U tube manometer is a basic primary standard air gauge. Mercury, water or other liquid is placed in a hollow graduated glass U tube. When pressure is applied to one end of the tube, the column of liquid moves. The liquid displacement is measured in inches. One can't accurately see 0.02 inches directly with any precision, so although this instrument very accurate, it is not sensitive enough to measure 0.02 inches of water. It is useful for checking higher pressures.
- 4) MagnahelicR Gauges. Air pressure exerted upon a diaphragm causes motion which is transferred to an indicating pointer. With the pointer at zero, the pressure is the same on both sides of the diaphragm. The diaphragm is linked to the end of a leaf spring. The free end of the spring is attached to a magnet. The magnet is kept at a measured distance from a helix. (The helix has a high magnetic permeability and aligns itself according to a fixed magnetic field, maintaining a set distance from the helix). When air pressure is exerted on the diaphragm and the spring moves. The helix moves to maintain the set distance. Motion of the spring also moves the pointer. This apparatus is calibrated against primary standards and the spring position can be adjusted to set the correct pressure. A variation of this device can be used in the range of 0 -0.5 inches of water and could be used to measure 0.02 ".
- 5) PhotohelicR gauges are variations of the magnahelic type where infrared radiation detected by a phototransistor is used to sense the closing of a shutter activated by the diaphragm's movement.
- 6) Inclined vertical manometers are a variation of the U tube manometers. A red dyed gauge oil is used in a clear plastic housing calibrated in inches of pressure. By placing the calibrated tube at an angle, the sensitivity is improved but still not good enough to measure 0.02 inches of water. These are used with specially designed probes called Pitot tubes. These are used for measuring flow very accurately by taking readings within a duct at specified distances through the duct cross section. A hole is needed in the duct to fit the Pitot tube. Readings across the duct cross section are called traverse readings. The manometer section is placed on the ground or other stable surface and leveled with a bubble. Tubing is connected to the manometer and to the Pitot tube which is inserted in the duct hole. For those who are interested in more detail an article is attached and a conversion chart to convert velocity pressure to air velocity. For example: at room temperature of 70 degrees F, 0.02 inches of water = 580 ft/min.

CHEM SCOPE PROJECT MONITOR TRAINING**Updated 4/2/10**

7) Ball rotometers are used to measure very low air flow, typically in liters/minute, applied by an air sampling pump. The force of the air moves the ball upward against gravity in the tapered bore of a graduated plastic housing. The ball stops moving when it reaches a wide enough point in the taper for the air to pass by the ball. The distance the ball is raised is directly proportional to the flow rate. These rotometers are calibrated against a primary standard such as a soap bubble buret. (We will discuss soap bubble burets, ball rotometers and primary and secondary standards in a later section on page 135-139.) One special ball rotometer model is ideal for differential room pressure applications or by changing scales, for direct measurement of negative air flow. This is a Dwyer Model 460 air gauge. Dwyer (215 957-0355). We will demonstrate its use and do some Hands-on applications with this gauge. This gauge reads in inches of water and in air velocity at the same time.

8) Vaneometer. This is the most sensitive air flow measuring device known. A thin steel sheet is suspended on a knife edge in a calibrated housing. The faintest draft causes motion of the steel sheet and the reading in ft/min can be directly taken from the scale. We will demonstrate and use a Model 480 vaneometer.

9) Thermal Anemometers are very practical for measuring negative air flow. The temperature change due to the velocity of air passing through a sensor is picked up by a thermocouple and transmitted to a needle or digital output. These are not usually sensitive enough for the room differential of 0.02 inches, however.

c. Temperature and pressure correction:

1) Temperature and barometric pressure affect the density of air. The temperature and barometric pressure must be measured and corrected for if SCFM (Standard CFM are to be reported.)

2) Atmospheric conditions, especially temperature, affect air density and contribute to errors unless accounted for.

3) When air is colder, it is more dense and at a given observed velocity, more air is actually moved than indicated. As an exercise, calculate the temperature correction for air at 15 deg C (40 degrees F) compared to 21 deg C (70 degrees F).

4) As the atmospheric pressure increases, air becomes denser and more air is actually moved than indicated. Pressure does not change the volume flow as much as temperature but still needs to be considered.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

5) Atmospheric conditions are corrected according to the equation:

$$\text{actual flow} = \text{indicated flow} \sqrt{\frac{P_{\text{cal}} T_{\text{act}}}{P_{\text{act}} T_{\text{cal}}}}$$

where:

P_{cal} is the observed pressure in mm of mercury during calibration

P_{act} is the observed pressure in mm of mercury during measurement

T_{act} is the observed temperature in deg. C +273 during measurement (degrees K).

T_{cal} is the observed temperature in deg. C +273 during calibration.

Note: typical atmospheric pressure is 760 mm of mercury (which is about 30 inches of mercury).

d. Practical Application of HEPA Filtration Units.

- 1) No regulated standards for system design (other than the filter rating 99.97%, etc.
- 2) Some manufacturer's take short cuts and use lower horse power motors and filters with higher back pressure under use. The result is that some brands plug more quickly than others. Surplus negative air, constant monitoring and filter change are critical.
- 3) A 2000 CFM unit operates at a static pressure anywhere from 1.75 to 2.3 inches of water, depending on the brand and the loading. The static pressure is a function of the power of the blower. As the filter gets loaded with particles, the flow goes down drastically.
- 4) The flow rate in CFM also decreases as the length of duct increases, bends, is restricted or as a function of the friction of the duct system.
- 5) A 20 Amp circuit may be needed for one 2000 CFM unit. Check the manufacturers label for electrical requirements.
- 6) Provide adequate makeup air from upstream of the Decon.
- 7) Check the gasket between the HEPA filter and housing each time the filter is changed or after the unit has been transported.
- 8) Filter Replacement
 - a) Outer 1/2 inch prefilter may last only 2 hours in heavy removal and inner 2 inch prefilter may last 24 hours.
 - b) HEPA filter may last about 700 hours.
 - c) Changing the 1/2 inch prefilter more often prolongs the life of the HEPA filter.
 - d) All filters must be accessible from the Work Area.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- e) When pressure drop exceeds manufacturer's specs, change the prefilters first and if the condition persists, change HEPA filter. The maximum pressure drop should be 1 inch of water for a clean filter.
- f) Excess moisture will cause the HEPA filter to fail.
- g) Each HEPA filter should have a UL586 label.

2. Use of Negative Pressure Exhaust Ventilation Equipment; Qualitative and Quantitative Performance of HEPA Filtration Units,

- a. Negative air: HEPA filtered blower sucks air from the Work Area and discharges it outside.
- b. One air change required every 15 minutes.
- c. Quantitative measurements of negative pressure of at least 0.02 inches of water and of CFM of each machine.
- d. Qualitative observations of flow and pressure:
 - 1) Decon tent flaps sucked in
 - 2) Cloth streamer at discharge
 - 3) Visible bending in of containment walls.

3. Calculation and Measurement of Negative Air Flow: Sizing the Ventilation Requirements,

- a. **The total air flow must be at least 4 air changes per hour.**
- b. **Determine the room volume in cubic ft** (length X width X height)
- c. **Divide the cubic ft by 15** to obtain the CFM needed.
- d. Provide enough negative air machines to meet or exceed this need.
- e. True flow is usually 75% or less of rated flow.
- f. Consult the negative air machine manufacturer for specifications on machines under real life conditions.
- g. For successful abatement, use more negative air than needed, as a rule of thumb, double the theoretical amount.

Example:

A room is 150 ft long, 40 ft wide and 10 ft high = 60,000 cu ft 60,000 divided by 15= 4000 CFM needed.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Location of HEPA Filtration Units:

- a. Required Flushing Technique: Place Negative air machines to provide a flow across the Work Area and position to draw air away from workers. To accomplish this, place the main negative air machine intake at the furthest feasible point from the Decon as illustrated in the lecture. Portable air intakes are needed to move contaminated air flow away from the workers.
- b. Exhausts must go outside if possible and must never discharge near building air intakes, open windows or any area where exposure is possible.
- c. Be extremely watchful of adjacent non- Work Areas where there is strong negative air pressures which may suck contaminated air into clean areas. A fan room, outside wind pressure, strong interior drafts and adjacent asbestos abatement areas are examples of possible strong negative pressure areas. Be sure to smoke test all these possible areas.
- d. Accessories include exhaust and intake ducts and flanges and adapters to connect the duct work, and spare filters.

5. Monitoring of Negative Air:

- a. Flow and pressure must be monitored and recorded daily
- b. At least four air changes/ hour in each Work Area.
- c. At least 0.02 inches of water negative pressure in Work Area
- d. Many Negative air units have Pressure indicators or alarms:
- e. Too low a back pressure may also indicate a leaking filter.
- f. Too high a back pressure (pressure drop) indicates the filter needs to be changed.
- g. Flow and pressure drops with longer duct runs
- h. PCM Air monitoring of the HEPA unit exhaust is very important to ensure that filters are properly working.
- i. Watch for new filters going on line especially. Note: sometimes fibers come off the filter itself for the first hour of use. These can be recognized as very large ribbon-like fibers. If they are seen, repeat the sampling and they should go away.

6. Qualitative and Quantitative Tests of Containment Barrier Integrity and Best Available Technology:

- a. Smoke tests with negative air temporarily shut off before abatement.
- b. Frequent monitoring of differential pressure.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 5-2

Abatement Operations

A. ASBESTOS REMOVAL

1. An asbestos abatement option which means stripping 3 sq ft or 3 lin ft of ACM or more from surfaces and disposal.
2. Containment barriers, Decontamination Units, Negative Air, Decontamination Unit, other preparations and final clearance are needed. See section 5-2 starting on page 104 and the Index for further references.

B. ABATEMENT METHODS OTHER THAN REMOVAL:

1. General:

Encapsulation or enclosure involving 3 linear or 3 square feet or more of Asbestos Material is considered an Abatement project and subject to all the procedures specified for Asbestos Removal.

2. Encapsulation:

- a. Treating ACBM with an encapsulant material that surrounds or embeds asbestos fibers in an adhesive matrix to prevent fiber release.
- b. The encapsulant is a liquid material applied to the surface of ACM using airless spray equipment at low pressure in order to reduce fiber release during applications.
 - 1) Types of encapsulant:
 - a) Penetrating encapsulant - penetrates and hardens the asbestos material
 - b) Bridging encapsulant - covers the surface of the material with a protective coating.
 - 2) **Not to be used on friable surfacing or wet-water damaged materials.**
 - 3) **Ideal for strongly bound materials such as transite to prevent surface dusting or erosion.**
 - 4) Asbestos source remains and must be removed later.
 - 5) Not suitable when severe damage such as delamination or water damage is evident.
 - 6) For ceilings not suitable if material is fluffy or is weakly adhered since the weight of encapsulant may cause material to fall.
 - 7) Spraying water damaged, loose, or hanging ACM is not considered proper Encapsulation.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

8) Process:

- a) Same preparations as for Removal are still needed.
 - b) Remove damaged, loose, or hanging areas of existing Asbestos material and place in sealable plastic bags for transport.
 - c) Repair damaged and missing areas to obtain a suitable base for sealing using Asbestos free replacement material in accordance with manufacturer's instructions.
 - d) Encapsulation disturbing 3 linear or 3 square feet **or more** of Asbestos Material is considered an Abatement project and subject to all the procedures for Asbestos Removal.
 - e) Apply a final spray with Encapsulant. Only an airless sprayer may be used. If an airless sprayer cannot be used, permission to use an alternate is needed from DPH.
 - f) Final Clearance
- c. Apply a final spray with Encapsulant to the repaired area.
- d. Any asbestos areas must be spray encapsulated after any disturbance of the asbestos including moving or adding pipe hangers, brackets and the like.

3. Enclosure:

- a. Building a permanent air tight barrier around ACM
- b. Same setup as for removal, but maybe could modify if DPH would allow an AWP.
- c. Ideal for isolated areas such as crawl spaces which do not need to be accessed.
- d. Not suitable for ceilings when severe damage or water damage is evident
- e. Some treatment such as encapsulation may be done first.
- f. Rigid materials such as sheetrock, wood, metal or heavy plastic sheet which can be mechanically sealed.
- g. Fiber release can continue behind enclosure.
- h. A drop ceiling is not an enclosure.
- i. The abatement method of "Enclosure" is not to be confused with plasticized areas called "Enclosures, or the Enclosure", such as decontamination enclosure, etc.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

C. OTHER CONTROL METHODS

1. O&M

Operations and Maintenance Program: (O&M) means an ongoing program of work practices to maintain friable ACBM in good condition, ensure clean up of asbestos fibers previously released, and prevent further release by minimizing and controlling friable ACBM disturbance or damage. Includes repair which is discussed below.

2. Isolation

A temporary response option which generally includes sealing off openings and keeping an area vacant until funds are available to conduct abatement.

3. Repair

A response option which returns ACBM to intact state so as to prevent fiber release.

D. PREWORK CONSIDERATIONS: (FOR REMOVAL, ENCAPSULATION OR ENCLOSURE)

1. Pework Inspections: Refer to the pre-abatement check list in the handout on W.W.W.Chem-scope.com.

2. Precleaning of the Work Area,

a. General

- 1) If hired for full-time monitoring, Project Monitor should witness the pre-cleaning operation. Poor pre-cleaning leads to failed finals and to embarrassment after floor poly is removed.
- 2) Personal samples taken.
- 3) Decon and negative air in use.
- 4) Full protective gear used.

b. Movable Objects:

- 1) Remove what can be moved - furniture, stored material & movable Equipment.
- 2) Wet clean or HEPA Vacuum objects as appropriate before taking out of Work Area.
- 3) Remove objects from Work Area to a temporary location or wrap as waste what is not to be cleaned and dispose of as contaminated waste.

c. Fixed objects and other surfaces:

- 1) HEPA vacuum and/or Wet Clean objects to remain in Work Area.
- 2) Enclose cleaned objects with a minimum of 4-mil plastic sheeting and tape.
- 3) Clean the remaining Work Area surfaces using HEPA vacuums and/or Wet Cleaning methods as appropriate.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. Construction of Critical Barriers:

- a. Work area separated from non Work Areas by air tight barriers.
- b. Seal off all openings, with polyethylene sheeting 6-mil thick including:
 - 1) Windows
 - 2) Corridors
 - 3) Doorways
 - 4) Skylights
 - 5) Duct vents and diffusers
 - 6) Any other penetrations into the Work Area
- c. Do not seal off sprinkler heads, smoke/heat detectors or other safety equipment.
- d. Ceiling Management:
 - 1) Any ceiling protrusions, panels, porous surfaces, or irregularities which may become contaminated, interfere with the work or permit contamination beyond the confines of the Work Area must be managed to prevent contamination or release of fibers. This is usually done by critical barriers, but there are special cases when not feasible, such as active sprinklers and alarm detectors.
 - 2) If work is required above drop ceilings, a decision is needed to demolish or preserve the drop ceilings.
 - 3) If all work is below drop ceilings:
 - a) The ceiling is protected with plastic or
 - b) The work is done in small plastic enveloped containments called "mini-containments" or
 - c) Ceiling mounted objects that interfere with Asbestos Abatement, such as lights and other items not sealed off, are cleaned and removed.

4. Construction of Floor and Wall Plasticization:

- a. Cover flooring and wall surfaces with polyethylene sheeting sealed with tape.
- b. Use a minimum of two layers of 4-mil polyethylene on walls and 6-mil polyethylene on floors.
- c. Floor plastic must interleave under the wall plastic so that polyethylene extends at least twelve inches up on walls. This keeps the water from leaking out.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

5. Worker Decontamination System:

a. Configuration:

- 1) At least 3 compartments separated by airlocks
- 2) Equipment room contiguous to the Work Area
- 3) Shower Room
- 4) Clean Room
- 5) Contiguous to the Work Area when feasible. **(Must notify DPH and the facility owner when a remote decontamination unit is used.)**

b. Equipment Room:

A contaminated area or room which is part of the Worker Decontamination Enclosure with provisions for storage of contaminated clothing and equipment.

c. Shower Room:

- 1) Pass through shower that does not restrict passage: hot and cold or warm running water, one shower per 10 employees or fraction thereof of each sex, soap (See OSHA 1910.141)
- 2) Polyethylene on Shower Room and adjoining Equipment and Clean Rooms must be non-transparent.
- 3) Waste from the shower must be filtered with best available technology (less than 5 microns filter porosity).

d. Clean Room:

- 1) Storage of street clothes
- 2) Change area
- 3) Next to non- Regulated area.

e. Equipment Decontamination Unit

- 1) When feasible, provide a second decontamination unit for equipment and waste containers. This unit is sometimes called the "bag-out".
- 2) Can be attached to the Worker Decontamination Unit or be at a separate opening to the Work Area. Provisions for cleaning Equipment and waste containers and transferring out of the Work Area.
- 3) Can be a separate two chambered unit at a separate opening to the Work Area.
- 4) Workers cannot leave by this route, they must go through the shower, etc. To move bags from the clean end of the bag-out, workers in clean suits must get them.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- a. Post OSHA signs (see page 31) at all potential entries to Work Areas including decontamination unit entries.
- b. Barriers. Interior = critical barriers or negative pressure enclosures. Roofing could be saw horses or warning tape.
- c. OSHA signs must be on waste container at least during loading and unloading of wastes.

7. Shutdown/Modification of Facility Systems;

- a. Electrical and ventilation system lock-out:

- 1) Lockout and tagging applies to all HVAC and to any portion of the electrical system which is de-energized for safety or other reasons.
- 2) HVAC (heating ventilation and air conditioning) systems which interact with the Work Area must be turned off.
- 3) Electrical breakers or fuses which control power to the above equipment must have tags attached at all points where such equipment or circuits can be energized and access to these points must be locked. Breaker and fuse boxes may usually be secured with a padlock. Tags must be clearly marked to identify the equipment which has been deactivated.
- 4) The chain of command and circumstances for re-energizing must be clearly delineated to avoid premature activation.
- 5) Where lighting is affected, lock and tag out and provide temporary Lighting consisting of low voltage lights.

- b. HVAC Shutdown

- 1) HVAC shutdown in the area
- 2) Lockout-tag out as above- be very sure that this is done.

E. TECHNIQUES FOR MINIMIZING FIBER RELEASE:

1. Maintenance of Containment Barriers and Decontamination Enclosure Systems:

- a. Check for leaks daily
- b. Smoke tests and visual examination
- c. Manometric tests daily
- d. Repair leaks promptly

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Work Practices:

a. Methods Used:

- 1) Wet methods (page 112)
- 2) Decontamination procedures (entry and exit-OSHA pages 35-6, DPH page 58)
- 3) Material drop restrictions (page 113)
- 4) HEPA vacuuming (pages 94-95)
- 5) Disposal practices (pages 114-117)
- 6) The aerodynamics of fiber dispersal must be clearly understood by the Contractor/Supervisor (page 12).

b. Coordination of Methods:

- 1) The appropriate method must be employed at the right time in the work sequence for each material being abated.
- 2) The Contractor/Supervisor should consider the material and the conditions of the Work Area such as high elevation which will affect the exact work operations.
- 3) The following are some general guidelines:

Wet

Wait

Cut

Disassemble

Package

Wet package contents further as needed

Wet clean substrate surfaces

HEPA vacuum when dry

Lock-down (page 115)

Take down of containment other than critical barriers, negative air and decontamination units

HEPA vacuum again

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. Personal Hygiene

a. Entry and Exit Procedures for the Work Area;

1) Restricted Access to Work Area:

- a) Signs to restrict access.
- b) Barriers
- c) Guard(s) at entries

2) Entry Procedure:

- a) All persons entering the Work Area must be properly authorized and equipped with proper respiratory protection and protective clothing.
- b) Enter the decontamination area through the clean room.
- c) Remove and deposit street clothing in locker.
- d) Put on protective clothing and respiratory protection in the clean room.
- e) Before entering the regulated area, employees pass through the equipment room.

3) Exit Procedure and Use of Showers:

- a) In Work Area, HEPA vacuum contamination (from self and protective clothing) to remove gross contamination.
- b) Proceed to the Equipment Room and remove all clothing (except respirator and deposit the clothing in labeled impermeable bags or containers.
- c) Do not remove respirators in the equipment room; remove in shower and clean the respirator.
- d) Still wearing the respirator) proceed to the shower and clean self using soap and water.
- e) After showering and drying off, enter the clean room and then change into street clothes or suits identified by different color than suits worn in the Work Area.

b. Other personal hygiene requirements:

Eating, smoking, chewing gum or tobacco and drinking prohibited in the Work Area.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Use of Wet Methods and Continuous Cleaning; Abatement Area Clean-up Procedures

a. Wetting ACM: The first step in asbestos stripping is to wet the material by spraying of ACM with amended water and then continue wetting during abatement.

NESHAP (and other regulations) require adequate wetting during stripping and maintaining the asbestos material in a wet condition in preparation for transport and disposal.

b. Wet cleaning surfaces:

Use cloths, mops, rags and towels and sponges or other cleaning tools which have been dampened with amended water, and by afterwards disposing of these cleaning items as Asbestos contaminated waste.

c. When Water Use is Not Feasible:

1) DPH/EPA: When it is not feasible to use water for reason of unavoidable equipment damage or for safety reasons, obtain prior written approval from EPA and/or the State DPH. (NOTE for NESHAP sized jobs): ALL ACM MUST BE KEPT WET until sealed in a leak tight container. Subject to such approval, water may be omitted during stripping but must still be added to the wastes as packaged.

2) OSHA: OSHA will allow employers to claim infeasibility if they cannot use wet methods due to conditions such as electrical hazards, hot surfaces, and the presence of technical equipment which cannot tolerate moisture.

d. Gross Removal:

1) Wet Asbestos Material freshly.

2) Remove intact or in manageably sized sections.

3) Carefully lower to the floor.

4) Drop restrictions.

a) For heights greater than 15 ft, use an inclined chute or scaffolding or containerize the material at the elevated level.

b) For materials removed at a height greater than 50 ft from the floor, a dust-tight, enclosed chute must be used to transport material to containers on the floor unless a raised scaffold is used to bag the wastes.

3) Do not let Asbestos materials dry out once disturbed during the work.

4) Repeat all cleaning operations constantly during the work to avoid any accumulations of debris.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

e. Bagging:

- 1) Bag the wet Asbestos waste freshly. Perform bagging at frequent intervals to prevent drying and to prevent possible tracking of Asbestos wastes. You can't drop ACM from more than 10' without bagging first.
- 2) Seal filled containers with the wet Asbestos waste in the Work Area. Wet clean the outside of the sealed bag and move to the Holding Area (bagout) for double bagging by workers who have entered from uncontaminated areas dressed in clean disposable suits. Only the double sealed bags and other cleaned materials should exit via the bagout. Persons should leave only via the Decon- shower route.
- 3) Before taping the bag closed you must **suck out the air using a HEPA vacuum.**
- 4) The Asbestos materials must be packaged in impermeable dust tight containers (i.e., heavy duty six (6) mil polyethylene bags or sealed fiber pack drums):
- 5) All containers including the Asbestos waste storage unit must be labeled in large legible letter:

DANGER
CONTAINS ASBESTOS FIBERS
AVOID CREATING DUST
CANCER AND LUNG DISEASE HAZARD

f. Cleaning Surfaces:

- 1) Remove visible accumulations of Asbestos Material and debris.
- 2) HEPA or Wet clean all surfaces within the Work Area.
- 3) Constantly change to fresh wipers, mops, brushes etc. Used wipers will only smear. Use clean water each time.

g. Lock-down **Must be done after the visual inspection.**

- 1) After all visible residue has been removed, spray apply a thin coat of Encapsulant to cleaned surfaces and to plastic barriers after cleaning.
- 2) Lock-down spray is usually a skin irritant and tends to plug respirator cartridges and air samples, so avoid contact with the liquid and mist.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

F. WASTE TRANSPORT AND DISPOSAL PROCEDURES INCLUDING PROPER CLEAN-UP

1. Cleanup

a. Equipment and Container Clean-up:

Note: Gross contamination may still exist inside the HEPA vacuums and negative air machines. These are changed in the Work Area if the filter becomes full.

1) Empty HEPA vacuum in the Work Area according to instructions above on page 95.

2) Negative air unit:

a) Outer filters on negative air units must be disposed of in the asbestos wastes, and the outside of the units thoroughly wet cleaned before removal from the Work Area.

b) Inner filters on negative air units must be changed at the beginning of the next abatement job inside the contained Work Area. Remove all pre-filters and damp clean

c) Change HEPA filters in the Work Area during early stages of abatement including gross removal if the filter becomes full. Otherwise change the inner filters at the start of next project after containment is established. Outer filters on negative air units must be moistened and disposed of in the asbestos wastes at any time when loaded or before taking from the site.

3) Sealed waste containers and all equipment used in the Work Area must be included in the clean-up and must be removed from Work Areas.

4) When decontamination is not possible or feasible, the object must be wrapped in two air tight layers of 6 mil polyethylene and the outside thoroughly cleaned before removal or placed in an airtight metal drum with a locking lid. Includes:

a) HEPA vacuums and accessories

b) Asbestos insulated or coated materials removed intact without stripping

c) Construction materials

d) Tools

e) Electrical equipment

f) Decon and shower components

g) Negative air units, and

h) Anything else.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. Lock-down: **after the visual inspection**

- 1) **Lock-down is a spray encapsulant.** Spray encapsulate (lock-down) all stripped surfaces using a fine spray mist. Follow manufacturer's instructions for the airless sprayer and encapsulant.
- 2) After all visible residue has been removed, spray apply a thin coat of Encapsulant to cleaned surfaces and to plastic barriers after cleaning.
- 3) Lock-down spray is usually a skin irritant and tends to plug respirator cartridges and air samples, so avoid contact with the liquid and mist.
- 4) Since the lock-down is invisible on most surfaces, monitor the process to ensure complete work.

2. Transportation and Disposal:

- a. Asbestos wastes must be wet.
- b. No visible emissions.
- c. Must be sealed in water and air tight containers.
- d. Double 6-mil polyethylene bags.
- e. Commercial fiber drums designed for asbestos wastes.
- f. Bulk storage and transportation vessels must be lined, air and dust tight.
- g. Outer containers must be clean and tightly sealed.
- h. May be specially lined dumpsters or trucks. Contained "Suck trucks" may be used provided the transfer is HEPA filtered and emissions monitored.
- i. Waste must not be liquid.
- j. Must be labeled per OSHA regulations in large legible letters:

DANGER
 CONTAINS ASBESTOS FIBERS
 AVOID CREATING DUST
 CANCER AND LUNG DISEASE HAZARD
- k. The waste must go to an EPA approved landfill for asbestos wastes.
- l. Disposal in Connecticut - DEP permit is needed.
- m. For NESHAP covered jobs: Also label each container with the name of the generator and the name of the work site.
- n. Waste manifest completed. One copy goes with the shipment and one copy is kept by the contractor.
- o. Disposal in EPA approved landfill or approved waste processing site.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

G. CONTINGENCY PLANNING FOR EMERGENCY RESPONSE;

(See also page 53)

1. Emergency Exits:

- a. Exits clear of equipment and materials at all times to permit emergency exit without interference.
- b. Brightly colored markings on the floor tracing the escape route and clearly mark the safe ways out of the containment. Each worker must be specifically instructed as to the emergency evacuation procedure. Make sure emergency lighting will operate.
- c. When fire or other such emergency threatens safety, it is acceptable to cut or break barriers to get out.

2. Power Failure:

- a. Prior training on procedures including escape.
- b. Suspend work.
- c. Prior setup to provide emergency lighting.
- d. Back-up generators.
- e. Decontaminate as best can do. Don't shake out suits; roll them up. Keep respirator on.
- f. Limit area of tracking until power is back on and then finish decontamination and clean up of any tracked dust.

3. Emergency Response to Asbestos Fiber Releases

- a. Isolate area with barriers and signs and keep material wet.
- b. Limit access to the area to trained personnel with respirator and a disposable suit.
- c. HVAC shutdown in the area if possible.
- d. Seal air vents especially return vents.
- e. Use a mini-enclosure or a glove bag as appropriate to address damaged ACM.
- f. HEPA vacuum any visible residue and cover the floor under the damaged ACM with 6- mil polyethylene.
- g. Use properly labeled leak-proof disposal containers.
- h. Patch the damaged area with appropriate asbestos free materials.
- i. Dispose of wastes in EPA approved landfill.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Occupant's Emergency Needs:

- a. Safe passage areas
- b. Specialized trades with asbestos training and protection needed for access to mechanical areas undergoing abatement.

5. For Supplied Air Respirators when in use

SCBA Self Contained breathing apparatus- (see page 121)

6. Medical Prevention and Response:

- a. Emergency plans must be ready in the event medical treatment is needed.
- b. See also Heat Related Disorders on page 163-164.
- c. Other Preparations:
 - 1) Emergency phone available
 - 2) First Aid Supplies and training
 - 3) CPR training
 - 4) Evacuation to designated medical facility
 - 5) For large projects involving physical and chemical hazards: arrangements made with local medical response units, can be coordinated with local hospital.

7. Fire Prevention and Response at Abatement Sites:

- a. Polyethylene burns similarly to candle wax. Fire resistant poly should be used but this is not much better than ordinary poly.
- b. Special precautions for containing hot surfaces
- c. Written emergency action plan and fire prevention plan
- d. OSHA Fire Protection and Prevention includes requirements for:
 - 1) Temporary or permanent water supply for fire protection
 - 2) A trained fire fighting brigade as the project warrants
 - 3) Portable fire extinguishers of a 2A rating for every 3000 sq ft of the Work Area. Point of travel to the nearest fire extinguisher must not exceed 100 ft.
 - 4) Where more 5 gal of flammable or combustible liquid exists, a 10B fire extinguisher must be located within 50 ft of the material. (This is likely to include gasoline used for generators.)

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- e. Ensure that the area allows a quick and easy escape route and all workers are briefed on escape.
- f. No smoking, no welding, no other ignition sources near flammable materials.
- g. Make sure outside contractors or other building occupants who may work near the area are aware of the safety requirements.
- h. Notify local fire marshall in advance.
- i. Emergency equipment on hand including fire extinguishers and first aid kits.
- j. Do not block exits

8. Training:

Workers must be instructed on fire, electrical, and other hazards peculiar to each job site. Instructions must include spill response, power failure and emergency evacuation procedures.

9. Sudden Releases Which May Result in Occupant and Worker Exposure:

a. Prevention

- 1) Planning ahead
- 2) Proper work practices
- 3) Housekeeping
- 4) Training

b. Detection

- 1) Visual monitoring of containment, adjacent areas and storage areas
- 2) Air monitoring showing changes from the baseline.
- 3) Drop in monitored containment pressure and flaps stop moving or move less.
- 4) Can see equipment failure
- 5) Unusual noises.
- 6) Odors of chemicals used in containment noticed outside containment.

c. Correction

- 1) Asbestos- provisions for emergency wetting, HEPA vacuums and isolation.
- 2) Chemicals - see MSDS for spill response.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

SECTION 6

PERSONAL PROTECTIVE EQUIPMENT

A. REGULATIONS COVERING RESPIRATORY PROTECTIVE EQUIPMENT IN THIS SECTION:

1. Construction Industry Asbestos Standard: CFR 29 1926.1101. See also Section 2-2.
2. Respirator Standard: CFR 1910.134 See also page 50.

B. CLASSES AND CHARACTERISTICS OF RESPIRATOR TYPES:

1. Air Purifying Respirators:

a. Negative Pressure:

HEPA filter/ NIOSH approved respirators used for asbestos. Half or Full Face. NIOSH = National Institute for Occupational Health and Safety.

b. Powered Air Purifying Respirator (PAPR):

- 1) Required with OSHA class I jobs unless a negative exposure assessment is obtained. Class I jobs are removal of TSI or surfacing.
- 2) Face piece can be a half-mask, full-face mask or helmet. **Note: If a helmet or other loose fitting PAPR is used and the person works less than 30 days / year with asbestos, then fit testing and medicals are not needed.**
- 3) At least 4 CFM to a tight fitting facepiece
- 4) At least seven CFM to a loose fitting helmet or hood.
- 5) Batteries need constant attention

2. Supplied Air Respirators: Breathing Air Systems

a. General

- 1) Deliver breathing air through a supply hose connected to the worker's facepiece.
- 2) Very high degree of protection
- 3) Can operate in oxygen deficient and toxic atmospheres.
- 4) Additional training is needed from the manufacturer to operate and maintain the individual system.

b. "Type C Air-Supplied" respirators- supplied by remote tanks or compressor.

- 1) Tanks: Continuous supply of grade D breathing air required
- 2) Compressor- typical 100 SCFM; 50 PSIG for a low pressure system.
 - a) Heats air- must be cooled before delivery
 - b) Carbon monoxide sources
 - c) Needs purification, temperature control and monitoring

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- 3) Distribution
 - a) Continuous and sufficient supply
 - b) Measure air pressure in the supply system
 - c) Hose lines maintained at 60-75 PSIG
 - d) Up to 300 ft of hose
 - e) Check pressure with all respirators in use
 - 4) Adequate reserve air and escape time of 5 minutes
 - 5) Temperature control of breathing air
 - 6) Continuous carbon monoxide monitor and alarm
 - 7) Cautions in the use of breathing air systems
 - a) Locate compressor to take in clean air from outside the work zone, at least 8 ft above ground away from vehicles and the compressor exhaust. Best location is 15-20 ft up a tree.
 - b) Monitor carbon monoxide every 4 hours of use.
 - b) Compressor oil must be compatible with system
 - c) Purifying system required with compressors; must not be overloaded.
 - d) Never use pure oxygen for asbestos abatement
 - e) Inspect all components for damage
 - f) Explosion possible. Inspect safety relief valves carefully.
- c. High Pressure Versus Low Pressure Systems:
- 1) High pressure = greater than 200 PSIG (lbs/sq inch gauge pressure).
 - a) Air may go directly into a storage tank.
 - b) A pressure regulator reduces the pressure to 125 PSIG for distribution to a manifold from which 2-6 masks may be supplied through low pressure airlines.
 - 2) Low pressure = less than 200 PSIG (lbs/sq inch gauge pressure).
 - a) Air comes directly from a compressor with a purifying train.
 - b) Air is distributed to a manifold as above.
 - c) Emergency tank air supply is required per 1910.134.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

d. Testing for Grade D Air:

- 1) Carbon Monoxide (CO) 20 PPM max. Use an MSA Passport Monitor or similar device to test at least every 4 hours in addition to any automated tests on the equipment. Critical to test CO.
- 2) Oxygen must be **19.5- 23.5%**. (Tested simultaneously with the CO)
- 3) Carbon Dioxide (1000 PPM max). Can be tested with Draeger or Sensidyne tubes or with an infrared detection meter.
- 4) Condensed Hydrocarbons 5 milligrams/cubic meter. Collect samples in a gas bag and take to the lab for GC gas chromatographic analysis.
- 5) Objectionable odors none.
- 6) Water vapor 66 PPM (parts per million) max. This is to prevent interference with the CO scrubbing devices. Water indicating tubes are used in the purifying train.

e. Determining Proper Backup Air Volumes:

- 1) Allow a clean reservoir with 30 minutes of air for each mask connection. Figure 15 CFM at each connection. Therefore 450 cubic ft of air (at atmospheric pressure) is needed for each worker. A typical 80 cubic ft size cylinder when fresh has about 2000 PSIG of air. PSIG DIVIDED BY 14 = THE NUMBER OF ATMOSPHERES. So this cylinder has about 140 atmospheres of pressure and therefore 140 times 80 = 11,200 cubic ft of air at atmospheric pressure. 11,200 divided by 450 = 24.88, leaving enough air for about 24 workers to escape.
- 2) If the hose is cut, the above calculations are meaningless, so make sure each worker has his SCBA.

3. SCBA Self Contained breathing apparatus-

- a. Portable tank with fresh air
- b. Short term or emergency escape use

NOTE: THE ABOVE IS ONLY A PRIMER. PROJECT MONITORS WHO ARE GOING TO MONITOR SUPPLIED AIR MUST GET DETAILED INFORMATION FROM THE SUPPLIER AND THE MANUFACTURER OF THE PARTICULAR EQUIPMENT.

C. LIMITATIONS OF RESPIRATORS:

1. Oxygen Deficiency:

- a. Normal air contains about 20.9% oxygen.
- b. Work area air must contain 19.5 to 23.5 % oxygen.
- c. Only supplied air or SCBA apparatus is acceptable in oxygen deficient atmospheres.
- d. HEPA or other air purifying respirators do NOT protect against oxygen deficiency.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Toxic Contaminants:

- a. HEPA filters do NOT protect against toxic vapors.
- b. Special cartridges are needed for each class of vapors.
- c. Always request a material safety data sheet (MSDS) when dealing with strange contaminants. The MSDS must say what type of respirator is needed.
- d. Consult respirator or chemical suppliers on specific problems.

D. PROPER RESPIRATOR SELECTION

1. By OSHA requirements Discussed Above on page 33

2. According to limitations Discussed Above on pages 121-122.

3. By Technical Agencies: Select the respirator for any substance which provides the required protection factor based on personal air monitoring vs the exposure limits:

ACGIH- American Conference of Governmental Industrial Hygienists
NIOSH- National Institute for Occupational Safety and Health.

4. Protection or Fit Factors:

- a. A protection or Fit factor is a value obtained by dividing the concentration outside by the concentration inside the mask.

$$\text{Protection Factor (PF)} = \frac{\text{Conc. outside mask}}{\text{Conc. inside mask}}$$

- b. Protection factors are not used to determine the TWA and PEL exposures; these are determined outside the mask.

c. Protection factors presented in Table 1 of 1926.1101

1) Negative pressure HEPA filtered:

- a) Half-mask air purifying "not in excess of 1 f/cc (10 X PEL)
- b) Full face mask air purifying "not in excess of 5 f/cc (50 X PEL) (if the mask is quantitatively fit tested; but if qualitatively fit tested, the PF is only 10.

2) PAPR: "not in excess of 10 f/cc (*100 X PEL)

***PROTECTION FACTORS FOR TIGHT FITTING PAPRS:**

AGENCY	PROTECTION FACTOR	MASK	FIT TESTING METHOD
OSHA	100	FULL FACE	QUALITATIVE
OSHA	50	½ FACE	QUALITATIVE
OSHA	1000	FULL FACE	QUANTITATIVE
NIOSH	50	½ OR FULL FACE	ANY

3) Supplied air types: (1000 X PEL or more)

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

E. RESPIRATOR DONNING, USE, MAINTENANCE, INSPECTION AND STORAGE PROCEDURES:

1. Donning:

- a. Medical approval needed
- b. Only use the respirator for which fit tests were made.
- c. Inspect for defects as detailed below. (Repair or replace any defective parts using only correct parts of the same brand.)
- d. Install new cartridges as needed.
- e. Adjust straps. Over-tightening the straps will sometimes reduce facepiece leakage, but the wearer may be unable to tolerate the respirator during the work period.
- f. Respirator straps go under protective hood
- g. **Seal Check. Each time the respirator is donned.** If fit is unsatisfactory, check for loose cartridges, missing gaskets and other defects (below) and adjust as needed or obtain new fitted respirator or parts.

2. Use and Daily Maintenance:

- a. Trouble
 - 1) Negative Pressure Respirators:
 - a) **Increased breathing resistance indicates filters are full.** Leave Work Area immediately and change the filters.
 - b) Decreased breathing resistance indicates leak. Correct at once.
 - 2) PAPR
 - a) Reduced air flow can be detected by feel and sound and indicates weak battery or plugged filters. Leave Work Area immediately and correct before re-entry.
 - b) If battery goes, tight fitting PAPR becomes temporary negative pressure respirator.
- b. Taking off
 - 1) HEPA vacuum off any gross contamination.
 - 2) Proceed to the shower with respirator still on.
 - 3) Clean the respirator using soap and water and rinse.
 - 4) Remove the cartridges and wash the respirator with detergent (disinfectant if needed) in warm water using a brush and wiping with a clean paper towel.
 - 5) Wash the cartridge gaskets separately. Never use solvents other than water since they are likely to attack the rubber facepiece.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- 6) Rinse thoroughly in warm tap water to remove all traces of detergent and disinfectant.
- 7) Dispose of the wet respirator cartridges in a receptacle for Asbestos waste.
- 8) Proceed to the Clean (change) Room and dress

3. Storage:

Allow to dry on a clean paper towel for the next days use. When dry, reassemble with the cartridges and package the unit in a 1-2 gallon zip loc bag with the exhalation valve up. Store free of overlaying material and equipment to avoid distorting the rubber.

4. Maintenance of Air Purifying Respirators: Checking for Defects:

a. Rubber facepiece:

- 1) Dirt- Clean .
- 2) Permanent distortion, cracks, tears, or holes - Issue new facepiece.
- 3) Loose fitting valves or other parts- Replace or issue new facepiece.
- 4) Warped, cracked, torn or missing gaskets- Replace.

b. Headstraps:

- 1) Breaks, loss of elasticity or tears- Replace headstraps.
- 2) Broken or malfunctioning buckles or keepers- Replace.

c. Valves:

- 1) Loose- Tighten or replace.
- 2) Dirt or residue- Clean or replace.
- 3) Rupture, missing cover or other defect- Replace.

d. Filter element:

- a) Proper filter.
- b) Missing or worn gaskets- Replace.
- c) Worn, Cracked, dented or contaminated- Replace filter.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

F. QUALITATIVE FIT TESTING PROTOCOL USING IRRITANT SMOKE (STANNIC CHLORIDE):

- 1. Prior to initial use of a respirator, whenever a change in conditions such as a different respirator facepiece type is used, and at least annually thereafter.**
- 2. Test subject clean shaven at facepiece sealing surface.**
- 3. Fit-testing of tight-fitting PAPR's in the negative pressure mode. This is accomplished by shutting off the power.**
- 4. Selection of respirators available and mirror available to evaluate the fit.**
- 5. Test subject informed about the selection process and trained in putting on respirators.**
- 6. Assessment of comfort shall include the following points:**
 - a. Position of the mask on the nose
 - b. Room for eye protection
 - c. Room to talk
 - d. Position of mask on face and cheeks
- 7. The following criteria shall be used to help determine the adequacy of the respirator fit:**
 - a. Chin properly placed;
 - b. Adequate strap tension, not overly tightened;
 - c. Fit across nose bridge;
 - d. Respirator of proper size to span distance from nose to chin;
 - e. Tendency of respirator to slip;
 - f. Self-observation in mirror to evaluate fit and respirator position.
- 8. Test subject conducts a seal check). See page 128-9.**
- 9. If a test subject exhibits difficulty in breathing during the tests, she or he shall be referred back to the doctor who approved this individual for respirator use.**
- 10. If the employee finds the fit of the respirator unacceptable, the test subject shall be given the opportunity to select a different respirator and to be retested.**
- 11. To be discussed with test subject prior to the commencement of the fit test:**
 - a. Description of the fit test and test exercises that the subject will be performing.
 - b. Test subject's responsibilities during the test procedure.
- 12. The respirator shall be worn for at least 5 minutes before the start of the fit test.**
- 13. The fit test shall be performed while the test subject is wearing any safety equipment that may be worn during actual respirator use which could interfere with respirator fit.**
- 14. Test Substance delivery: The test substance is an irritant smoke (stannic chloride). Sealed glass and plastic tubes with substances to generate this smoke are available from IPCO safety supply company. When the tube ends are broken and air passed through them with an aspirator (squeeze bulb), a dense irritating smoke is emitted. The squeeze bulbs used are Sensodyne kits calibrated to deliver 20 cc of air per squeeze using the thumb and index finger to compress the bulb until the opposite walls are touching. By squeezing gradually over 6 seconds, 20 cc is delivered and using 10 squeezes/per minute, a rate of 200 cc/min of smoke is delivered.**

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

15. No form of test enclosure or hood over the test subject shall be used.

16. The smoke can be irritating to the eyes, lungs, and nasal passages. The test conductor shall take precautions to minimize the test subject's exposure to irritant smoke. Sensitivity varies, and certain individuals may respond to a greater degree to irritant smoke. Care shall be taken when performing the sensitivity screening checks that determine whether the test subject can detect irritant smoke to use only the minimum amount of smoke necessary to elicit a response from the test subject.

17. The fit test shall be performed in an area with adequate ventilation.

18. Sensitivity Screening Check:

- a. Break both ends of a smoke tube
- b. Attach one end of the smoke tube to a 1/2 ounce aspirator squeeze bulb calibrated to deliver 20-cc per squeeze.
- c. Cover the other end of the smoke tube with a short piece of open rubber tubing to prevent potential injury from the jagged end of the smoke tube.
- d. Advise the test subject that the smoke can be irritating to the eyes, lungs, and nasal passages and instruct the subject to keep his/her eyes closed while the test is performed.
- e. Carefully direct one squeeze of the irritant smoke in the test subject's direction to determine that he/she can detect it.

19. Irritant Smoke Fit Test Procedure

- a. Test subject dons the respirator without assistance, and performs seal checks.
- b. The test subject instructed to keep eyes closed.
- c. Respirator not adjusted once the fit test exercises begin. Any adjustment voids the test.
- d. The test operator directs the stream of irritant smoke from the smoke tube toward the face seal area of the test subject, using the low flow pump or the squeeze bulb. The test operator shall begin at least 12 inches from the facepiece and move the smoke stream around the whole perimeter of the mask. The operator shall gradually make two more passes around the perimeter of the mask, moving to within six inches of the respirator.
- e. If the person being tested has not had an involuntary response and/or detected the irritant smoke, proceed with the test exercises.

20. Test Exercises

During the following exercises challenge the respirator seal continually with the smoke, directed around the perimeter of the respirator at a distance of six inches at a rate of 10 gradual squeezes per minute (200 cc/min). Withdraw the tube and stop pumping at once if the test subject should exhibit a characteristic cough reaction to the smoke. In this case the test has failed and the procedure needs to be repeated with another facepiece.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- a. 1 Minute Normal breathing. In a normal standing position, without talking, the subject shall breathe normally.
- b. 1 Minute Deep breathing. In a normal standing position, the subject shall breathe slowly and deeply, taking caution so as not to hyperventilate.
- c. 1 Minute Turning head side to side. Standing in place, the subject shall slowly turn his/her head from side to side between the extreme positions on each side. The head shall be held at each extreme momentarily so the subject can inhale at each side.
- d. 1 Minute Moving head up and down. Standing in place, the subject shall slowly move his/her head up and down. The subject shall be instructed to inhale in the up position (i.e., when looking toward the ceiling).
- e. 1 Minute Talking. The subject shall talk out loud slowly and loud enough so as to be heard clearly by the test conductor. The subject can read from the Rainbow Passage or count backward from 100.

Rainbow Passage

When the sunlight strikes raindrops in the air, they act like a prism and form a rainbow. The rainbow is a division of white light into many beautiful colors. These take the shape of a long round arch, with its path high above, and its two ends apparently beyond the horizon. There is, according to legend, a boiling pot of gold at one end. People look, but no one ever finds it. When a man looks for something beyond reach, his friends say he is looking for the pot of gold at the end of the rainbow.

- f. 1 Minute Bending over. The test subject shall bend at the waist as if he/she were to touch his/her toes.
- g. Normal breathing. Same as exercise (1).

21. Follow-up

- a. Question the test subject regarding the comfort of the respirator upon completion of the protocol. If it has become unacceptable, another model of respirator shall be tried.
- b. If the subject reports detecting the irritant smoke at any time, the test is failed; repeat the entire sensitivity check and fit test procedure.
- c. Each test subject passing the irritant smoke test without evidence of a response (involuntary cough, irritation) shall be given a second sensitivity screening check, with the smoke from the same smoke tube used during the fit test, once the respirator has been removed, to determine whether he/she still reacts to the smoke. Failure to evoke a response shall void the fit test.
- d. If a response is produced during this second sensitivity check, then the fit test is passed.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

G. OTHER QUALITATIVE METHODS

1. Banana Oil and Saccharin Qualitative Tests:

- a. The same general procedure is used.
- b. Depend on the wearer's response, and thus are not entirely reliable. (Irritant Smoke eliminates this variable.)
- c. Details can be found in 1910.134 attached.

2. Quantitative Fit Tests:

- a. Quantitative fit testing uses a non-hazardous test aerosol (such as corn oil, polyethylene glycol 400 [PEG 400], di-2-ethyl hexyl sebacate [DEHS], or sodium chloride) generated in a test chamber, and employing instrumentation to quantify the fit of the respirator; Quantitative fit testing using ambient aerosol as the test agent and appropriate instrumentation (condensation nuclei counter) to quantify the respirator fit. A device called a Portacount TM quantitatively fit tests respirators with the use of a probe. The probed respirator is only used for quantitative fit tests. A probed respirator has special sampling fittings installed on the respirator that allows the probe to sample the air from inside the mask. A probed respirator is required for each make, style and model.
- b. Quantitative fit testing also uses controlled negative pressure (CNP) and appropriate instrumentation to measure the volumetric leak rate of a facepiece to quantify the respirator fit. The CNP instrument manufacturer Dynatech Nevada also provides attachments (sampling manifolds) that replace the filter cartridges to permit fit testing in an employee's own respirator.

H. SEAL CHECK)

Before conducting the negative and positive pressure checks, the subject shall be told to seat the mask on the face by moving the head from side-to-side and up and down slowly while taking in a few slow deep breaths. Another facepiece shall be selected and retested if the test subject fails the user seal check tests.

1. Negative Pressure Test

- a. Cover air inlets with the palms to restrict air flow and inhale gently so the facepiece collapses slightly.
- b. Hold breath for about 10 seconds. If the facepiece remains slightly collapsed and no inward leakage is detected, the respirator probably fits tightly enough.
- c. This Seal Check has potential drawbacks, such as the hand pressure modifying the facepiece seal and causing false results.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Positive Pressure Test:

- a. Close the exhalation valve and exhale gently into the facepiece. (For some respirators, this test requires that the wearer remove the exhalation valve cover before the respirator is put on and then replace the valve before use.) The test is easy for respirators whose valve cover has a single small port that can be closed by the palm or a finger.
- b. Should have slight positive pressure inside the facepiece without any evidence of outward leakage around the facepiece.
- c. When exerting enough exhalation pressure, the facepiece should lift off the face rather than have air blow by the face only.

I. FACTORS THAT ALTER RESPIRATOR FIT AND CAUSE VARIABILITY BETWEEN FIELD AND LABORATORY PROTECTION FACTORS:

1. Active field conditions
2. Length of time since lab test
3. Wear on equipment
4. Dust build up in HEPA filters
5. Reproducibility of mask adjustment
6. Growth of facial hair
7. Change in weight

J. PERSONAL PROTECTIVE CLOTHING:

1. Selection and Use of Protective Clothing

- a. Must be worn in the asbestos Work Area.
- b. The suit is needed to keep gross asbestos contamination off the body, thus making decontamination easier and minimizing the chance of tracking to other areas of the building or bringing asbestos contamination home.
- c. Disposable coveralls usually with attached "feet" and hooded head covering.
- d. Disposable vs re-useable
- e. Tight fitting vs heat stress
- f. Loose vs catching in equipment and fall hazards
- g. Disposable suits are used which are made of Tyvek, or spun breathable fabrics.
- h. Selection of sizes: Most popular Suit sizes: triple (xxx) and double (xx).

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Other equipment:

a. Each abatement worker should have a full range of protective equipment available for use as may be needed at the work site including:

- 1) Hard or bump hats
- 2) Safety goggles
- 3) Boots
- 4) Protective gloves
- 5) Safety shoes
- 6) Knee pads
- 7) Rubber soled shoes for high places
- 8) Hearing protection.

b. Keep these items HEPA vacuumed and stored in plastic bags between jobs.

3. Donning the suit:

- a. In clean area outside the Work Area or in clean change area of the Decontamination unit
- b. Zip the suit down to the crotch
- c. Place street clothes in locker stripping naked or at least to undergarments or swim suit.
- d. Step into the suit and zip up
- e. Use duct tape if necessary to blouse or adjust fit
- f. Use duct tape to make a belt for personal air sampling pump.
- g. Don and seal check respirator
- h. Pull hood over head
- i. Don any other needed safety equipment
- j. Ready to enter Work Area
- k. Enter via the shower Decon.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Taking off the Suit, Decontamination Procedure:

- a. In the Work Area near the equipment room of the Decon Unit, HEPA vacuum off gross contamination paying attention to the respirator itself.
- b. Proceed to the Equipment Room
- c. If wearing a sampler, place personal air sample cassette in clean zip loc pouch and HEPA vacuum or wet wipe the pump. A plastic baggie secured with an elastic may be used to protect the pump while in the Work Area.
- d. Remove all clothing except respirator and dispose of suit in asbestos waste receptacle.
- e. Proceed to the shower with respirator still on. Still wearing the respirator, clean the respirator and self using soap and water and rinse self in the shower. Dispose of the wet respirator cartridges in a receptacle for Asbestos waste.
- f. Following showering and drying off, proceed directly to the Clean (change) Room and dress in street clothes or one may don disposable clothing of a different color or otherwise distinctively different, for use outside the Work Area, than suits used inside the Work Area.

5. Storage and Handling of Non-Disposable Clothing Used in Asbestos Abatement: (1910.1001, 85; 1926.1101,97)

- a. HEPA vacuum before leaving the Work Area to decontaminate.
- b. Take off in the equipment room of the change area and leave there in containers with the same OSHA labels specified for wastes.
- c. Must launder so as to prevent the release of airborne asbestos in excess of the PEL or EL.
- d. Commercial laundries or cleaning establishments: If given to another person for laundering: must inform such persons of the requirements to launder the clothing so as to prevent exceeding of the PEL and EL.
- e. Contaminated clothing shall be transported in sealed impermeable bags, or other closed impermeable containers and be labeled:

DANGER
CONTAINS ASBESTOS FIBERS
AVOID CREATING DUST
CANCER AND LUNG DISEASE HAZARD

- f. Must be periodically examined for rips or tears and repaired or replaced as needed.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

SECTION 7

AIR MONITORING STRATEGIES

A. SAMPLING EQUIPMENT

1. Low Volume Sampling Pumps and Equipment

(Used for personal sampling)

a. Battery powered personal sampling pump

1) The pump should be able to operate for eight hours starting on a fully charged battery at a flow rate of at least 1.7 L/M (liters/minute) against a resistance of six inches of water measured at the pump inlet.

2) Commercial battery operated-rechargeable sampling pumps are available from MSA, Bendix, Sensidyne and elsewhere.

3) The pump should have an external means of adjusting the flow rate and a rotometer to indicate the flow rate.

4) Allowed flow rate of 0.5 - 5 liters per minute

5) Pumps should be recharged routinely overnight at the end of each days work.

b. Field calibration device

1) Usually a ball rotometer with a range of 0-4 liters/min. since most personal pumps will not pull more than 3 liters/min through a cassette. (Cassette = air monitoring filter assembly. pages 132-135; 146-147; see index for further references.)

2) Higher range rotometers are available.

c. Tubing

Laboratory tubing such as rubber or plastic with 6- mm bore and about 100 cm length. Tygon or medium wall rubber tubing are commonly used.

d. Clothing spring clip

Since the pump will usually be installed on a worker, it must have a belt clip. The clip should be designed to prevent slippage from the belt even if its position becomes inverted.

e. Tubing-to-field monitor metal adaptor

A short plastic or metal adaptor with ridges on one end to grip the inside of the tubing. The other end is designed for a pressure fit into the field monitor. Modern cassettes are equipped with this built-in adaptor.

f. Field monitor or "cassette" (filter and holder)

g. Sealable plastic bag such as a Zip-Loc bag to contain sample cassettes and parts

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. High Volume Sampling Equipment

(Used for collection of area samples and finals.)

a. High volume pump.

- 1) This is basically a vacuum pump which can exert a vacuum of > 20 inches of mercury.
- 2) High Volume Sampling Pumps are available from Gast, Dawson, Allegro and other sources.
- 3) The pump should have an external means of adjusting the flow rate such as a valve.
- 4) Flow regulating devices Constant flow orifices critical and limiting orifices are also available which control the pump flow to a constant rate.

The design depends on a surplus of pressure exerted by the pump motor and under these conditions, a constant flow rate is obtained which is not very sensitive to pressure changes. Even so, there are many things that can go wrong with this type of device, such as leakage, and it is still necessary to calibrate the pump externally.

b. The same tubing, adaptors and sealable plastic bags as for personal sampling above.

c. For PCM analysis, the same cassette is used as for personal samples.

d. Special cassettes are described below for TEM samples.

e. Rotometer 0-20 liters/minute: (maximum use 16 liters/minute for PCM and 10 liters/min for TEM)

f. Tripod to mount cassettes about 30 inches above the floor.

3. Use of Fibrous Aerosol Monitors (FAM) on Abatement Projects;

a. FAM uses laser light and electrical field technologies to instantaneously analyze the fiber content of the air.

b. The instrument provides a continuous measurement, with direct readout of the number or concentration of asbestos fibers.

c. FAM can be used with a strip chart recorder to provide a record of air quality conditions.

d. FAM is typically used as a barometer rather than a precision testing device, it serves to alert personnel of any change in the fiber count.

e. If FAM is used it should be used in conjunction with an approved method such as PCM or TEM.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Sampling media, types of filters, types of cassettes:

a. Field Monitor (Cassette = Filter and Holder). Millipore or equivalent. The unit consists of:

1) Conductive plastic case for Aerosol monitoring, consisting of a filter holder, and a 50-mm conductive cowling with an end cap.

2) **25 mm diameter plain white mixed cellulose ester (MCE) membrane filter, (pore size of 0.8-1.2 micrometers for PCM and 0.4 micrometer for TEM.)**

3) Support pad. The pad is a stiff, thick, lint-free and porous disc that rests on a rim or on studs in the cassette bottom.

4) Two plastic sealing caps.

5) The outside mating surfaces of the field monitors may be covered with a "shrink-fit" band to provide proper sealing and a writing surface for filter identification.

6) The OD of the filter is 25 mm, but since part of the housing covers the filter, the true effective diameter is roughly 22 mm.

7) Manufacturer's specification requires an effective filter area of 385 sq mm.

b. Filter Orientation:

1) MCE filters are cellulose strands bound together in a web called "tortuous pore" and display a very irregular surface when observed under magnification.

2) Filters are always placed facing at a 45 degree angle down toward the ground during sample collection and sampling is done "open faced" with the plug and the end cap off the inlet.

c. Storage and Shipment of Filters;

1) The field monitors in which the samples are collected should be shipped in a clean and rigid container with sufficient dust- free packing material to prevent jarring and crushing.

2) Never transport loose samples.

3) Never use dusty packing materials.

4) Always inspect cassettes for gross contamination after sampling and before shipment. Repeat the sampling as needed or take any corrective action needed.

5) Make sure cassettes are sealed with conductive cowlings in place.

6) Do not use plastic packing such as polystyrene foam which generates static electricity.

7) Sealable containers with sample silos and cover to avoid contamination or shock which may dislodge fibers from the surface.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- 8) Security seal to learn if package has been opened in transit.
- 9) Each sample labeled

B. CALIBRATION TECHNIQUES AND CALCULATIONS:

1. General:

- a. OSHA Regulations require calibration of the sampling pump with a representative filter between the pump and the calibration device at the start and end of each sample.
- b. Frequency of Calibration: We recommend the following:
 - 1) Lab calibrate all rotometers with a soap bubble buret when new. The procedure is on pages 137-139.
 - 2) In addition, lab check the rotometers vs soap bubble buret if:
 - a) Any rotometers disagree with each other
 - b) If there is any unexplained change in flow rate of any pump, or
 - c) If they have just been repaired, misused, or received from the manufacturer.
 - d) If the equipment receives hard usage at least every six months.
 - 3) In the field, do external rotometer checks upstream of the filter at the beginning and end of each sample. Record these data on the sample worksheet.

2. Primary Calibration Standards:

- a. A primary standard is a device to measure the actual volume drawn by a pump in a specified time. The volume must be measurable by some direct and independent means, independent of the gas or air involved.
- b. The standard is volumetric by nature. A soap bubble burette is the primary standard commonly used for sampling pump calibration.
- c. A soap bubble burette is a primary standard including timed passage of bubbles through an inverted buret. This procedure is described on page 137 below.
- d. True calibration is done with primary standards in the laboratory.
- e. Other standard calibrating instruments, such as a spirometer, Marriott's bottle, or dry gas meter can be used. The calibration should be of sufficient precision such that the 95% confidence limits on the flow rate are + or - 10% (95% of the flow rates will fall within + or - 10% of the calibrated value).

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. Intermediate Standard:

- a. An intermediate standard is one that cannot be primary by definition, but is just as accurate if maintained and must be calibrated (and periodically recalibrated) by a primary standard.
- b. A wet-test meter is a common example of an intermediate standard. This is basically a drum half filled with water. A rotor inside the drum is attached to an indicating pointer on the outside of the meter.
- c. When a pump is connected to the outlet and turned on, air comes through the inlet and rises, causing the rotor to turn. The amount of turning is related to the quantity of air passing through. The indicating needle reads volume.
- d. There are several disadvantages to the wet-test meter, including possible corrosion, and friction and inertia problems respectively at high and low flow rates.

4. Secondary Calibration Standards - Rotometers:

a. General:

- 1) A secondary standard is any air flow measuring instrument that does not fit the definitions of a primary or intermediate standard and has been calibrated by a primary standard.
- 2) The rotometer is the principal secondary standard.
- 3) A rotometer is a transparent tapered tube containing a float which is typically a round ball.
- 4) The theory of operation is that air passing up through the tube must push around the ball to get out. As the ball rises, its sides get further from the wall of the tube and eventually there is not enough pressure drop to cause a further rise. The ball will then remain suspended at a pressure proportional to the flow rate indicated.
- 5) Take the ball reading at the center of the ball and look straight across the face plate. Always make sure the rotometer is vertical, since canting it will cause errors.

b. Pump Rotometer:

- 1) The low flow sampling pump usually has a ball rotometer which typically indicates a flow rate from 0-4 l/min.
- 2) The pump rotometer is usually wrong; assume it to be so. Usually the actual flow is lower than the flow indicated by the rotometer.
- 3) The pump rotometer is useful in quickly detecting large increases in the reading signaling a leak or a ruptured cassette or large decreases in the reading indicating overloading of filters, crimped tubing or a dying battery. Internal leaks are checked by turning the pump on to full flow and plugging the inlet. If no leaks are present, the pump should nearly stop and the pump rotometer should read zero.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- 4) Use of the secondary standard rotometer in the field upstream of the filter is strongly recommended to detect leaks and other problems.
- 5) The actual flow rate is said to be the reading of the reference calibration device in liters/min (l/min). The true value of the flow rate should be $\pm 5\%$ of the observed value.
- 6) It is possible to calibrate the pump rotometer against a primary standard (usually the soap bubble buret) and prepare a calibration chart for the apparent vs actual readings. However this approach is subject to large errors due to possible leakage and pressure changes in the field unless rigorous control of conditions is maintained.

c. External Rotometer:

- 1) In the field, the external rotometer is much more reliable than the pump rotometer. The pump flow should be determined from an external rotometer attached upstream of the cassette (where air enters the cassette).
- 2) The external rotometer is calibrated at the lab vs a soap bubble buret.
- 3) Each external rotometer should be given a serial number and the calibration data recorded in a log book and in a field worksheet.

5. Temperature and Pressure Effects

- a. Temperature and barometric pressure affect the density of air. The temperature and barometric pressure must be measured and corrected for in the calibration process.
- b. Make corrections as shown on page 100-101 above.

6. Calibration with the Soap Bubble Buret:

a. Apparatus

1000-cc dispensing buret inverted
sampling pump
rubber tubing
beaker with 1:5 liquid soap: water mixture
U tube manometer, 0-8 inches of water
bubble trap (a fritted plastic sampling impinger may be used)
representative cassette
thermometer
barometer
assorted clamps
stop watch
rotometers to be calibrated

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. Procedure

Note: Pump rotometers and external rotometers may be calibrated simultaneously. Make sure the serial number of each unit is recorded vs the calibration data.

- 1) Before the soap bubble buret is used, wet the buret inside with soap. Avoid excessive foam and suds. Unclamp the burette, remove the tubing, and pour soap down the wall while simultaneously rotating the burette. Collect the drainage in the soap reservoir. Continue to rotate the burette tilting it so the soap slowly runs down the wall until the wall is uniformly wet. Invert and re-clamp the buret in a level position and attach the tubing.
- 2) Make a fresh liquid soap water mixture without any foam. A 1:5 mixture of detergent to water is mixed by stirring.
- 3) Make sure the battery is charged to manufacturer's specifications.
- 4) Connect the filter cassette inlet to the top of the buret with a length of hose.
- 5) Connect the rotometer to the cassette outlet. Mount the rotometer level.
- 6) Check all connections and start the pump.
- 7) Adjust the pump so that rotometer indicates the first setting to be calibrated between 0.5 and 5 l/min.
- 8) Zero the stop watch.
- 9) Raise the beaker with soap solution to touch the inverted buret to the liquid surface. Evenly break the surface of the liquid to start a bubble up the buret. A number of bubbles may be drawn up successively to condition the surface of the buret. Perform this task until the bubbles are able to travel the entire length of the buret without breaking.
- 10) Wait for an even bubble (free of bubble clusters) and time the efflux time between two marks on the buret, usually between 0 ml to the 1000 ml mark for a volume of 1 liter.
- 11) Record the pump pressure for reference in inches of water. The pressure drop across the filter must be less than 13 inches of water (about 1 inch of mercury). Record the atmospheric pressure (mm of mercury), and the room temperature (degrees Celsius converted to degrees Rankin). Record the pump and rotometer serial number, date, and name of person performing the calibration.
- 12) Repeat the process in triplicate for each of three pump settings and average the data for each pump setting.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

13) Calculate the calibrated flow rate in liters/ min. by dividing the volume traveled by the soap bubble by the elapsed time.

NOTE: Field corrections to the flow rate for pumps with rotometers may be necessary if the pressure (elevation) or temperature where the samples are collected (actual flow rate) differs significantly from that where the calibration was performed (indicated flow rate). Actual flow rates at time of sampling may be calculated for a linear scale rotometer by using the following correction formula:

$$Q_{\text{actual}} = Q_{\text{indicated}} \left[\frac{P_{\text{cal}} \cdot T_{\text{actual}}}{P_{\text{actual}} \cdot T_{\text{cal}}} \right]^{1/2}$$

where both pressure (P) and temperature (T) are in absolute units:

P = mm of mercury

T = deg Kelvin = deg Celsius + 273

C. AIR MONITORING RECORDKEEPING AND FIELD WORK DOCUMENTATION AND CALCULATIONS:

REMEMBER THE PROJECT MONITOR MUST ALWAYS INSPECT THE CASSETTES WITH A FLASHLIGHT AFTER SAMPLING AND IF THE CASSETTES ARE VISUALLY CONTAMINATED OR THE FILTER IS RUPTURED, THEN REJECT THE SAMPLES AND REPEAT THE TESTS.

1. See Section 10-2 for Records needed

2. Completing Air Sampling Records and Calculations

a. PCM: (See sample of form FL 22 in the handout on W.W.W.Chem-scope.com.)

1) Complete the heading and sign the entry "sampled by" ____.

2) Record the sample number and description.

3) Enter the starting and end time of sampling that you measured with the rotometer. Average the two readings.

4) Determine the difference in minutes between the starting and end time in minutes.

5) Multiply the average flow rate in liters per minute times the minutes and enter the result in liters on the next column.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

6) The analyst which may also be the Project Monitor, will complete the next four columns: Data below is for the Chem Scope WB optics and 25-mm cassettes. Other optics may vary slightly.

(.00785 = Walton Beckett field area, mm²)
 (385 = Effective filter area, mm)

a) f/flds direct from the count

b) $f/\text{mm}^2 = \frac{f/\text{flds}}{0.00785}$

c) $f/\text{cc} = \frac{f/\text{mm}^2 \times 385}{(\text{liters})(1000)}$

d) LOD = $\frac{2.69}{\text{liters}}$

Example: For a sample of 1200 liters, 17 fibers were counted for 100 fields, then:

a) $f/\text{flds} = 17/100 = 0.17$

b) $f/\text{mm}^2 = \frac{0.17}{0.00785} = 21.7$

c) $f/\text{cc} = \frac{21.7 \times 385}{(1200)(1000)} = 0.0069$

d) LOD (f/cc) = $\frac{2.69}{\text{liters}}$

7) **For finals, the job fails if any of the five samples are 0.01 f/cc or greater by NIOSH 7400.**

8) OSHA ID-160: In general, for personal samples which are above 1 f/cc or for background samples (excluding finals) which are over 0.01 f/cc: immediately notify your supervisor to obtain further instructions.

If you are instructed to submit for OSHA-ID-160: Submit the samples (filters and slides) to the PLM laboratory for analysis by OSHA Method ID-160. Complete worksheet Form FL-22-160 up to the column titled % asb PLM, and enclose this worksheet with the samples. Other specs besides 1 f/cc and 0.01 f/cc may be established for particular jobs. **REMEMBER, OSHA ID-160 CANNOT BE USED FOR FINALS, for PCM FINALS NIOSH 7400 MUST BE USED.**

9) Record the data in f/flds for the two required field blanks at the bottom of the page. Blanks are subtracted from the sample values, except blanks > 3f/100 fields are rejected and the set must be repeated.

10) Complete the information at the bottom of the page.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. TEM samples:

- 1) Use Air Sample Record for TEM samples (See sample of form FL 22 T in handout on W.W.W.Chem-scope.com).
- 2) Make sure you take a minimum of 1200 liters after temperature and barometric pressure correction using the calculations above on page 100-101.
- 3) Calculations are done by the TEM laboratory. **Average of all inside samples must be below 70 s/mm² for the area to pass** or the TEM lab must run the outside samples and statistically compare with the inside samples.

3. Measuring Negative air Flow

- a. Determine the f/min of air passing through the duct by placing the manometer probe at intervals of every 2 inches across the duct and averaging these readings.
- b. For the pre-abatement inspection, record this average value on form FL 12a.
- c. Measure the diameter of the duct with a ruler and record the diameter (d in inches). The radius in inches = 1/2 the diameter.
- d. Convert the radius to ft by dividing by 12.
- e. Then: calculate the duct area = 3.14 (radius)(radius). (Pi r²).
- f. Another, method is to use a tape measure and find the circumference of the duct then find the diameter from the equation $C = 3.14 \times d$, $d = C/3.14$.

$$\text{CFM (f}^3/\text{min)} = \text{observed Ft/min} \times \text{duct Area (f}^2\text{)}$$

Example: the diameter is 14 inches and therefore = radius = 7 inches or 0.58 ft. Area = (.58)(.58)(3.14) = 1.06 f². Then, if the observed flow averaged 2300 f/min:

$$\text{CFM (f}^3/\text{min)} = \text{observed Ft/min } 2300 \times \text{duct Area (f}^2\text{)} 1.06 = 2443 \text{ CFM. Rounded off to 2 significant figures} = 2400 \text{ CFM.}$$

(Note: SCFM could be calculated using pressure and temperature corrections, but this is not normally done for this particular measurement.)

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

D. AIR SAMPLE ANALYSIS, Techniques Available and Limitations of AHERA on Their Use,

1. Transmission Electron Microscopy (TEM)

a. Background

TEM is a technique which focuses an electron beam onto a thin sample mounted in the microscope column under vacuum. As the beam transmits through the sample, an image resulting from varying density of the sample is projected onto a fluorescent screen.

b. Sample Preparation and Analysis (EPA's recommended technique for analysis of final air clearance samples)

- 1) Air samples for TEM analysis are now collected on MCE filters but an older technique employs polycarbonate filters.
- 2) A direct transfer method is used for the transfer of a carbon-coated replica of the filter material (with embedded fibers and particulates, etc) right onto a copper grid suitable for TEM analysis.
- 3) Indirect transfer techniques require an intermediate step that may break-up fiber bundles, resulting in an increased fiber count.
- 4) Mandatory and non-mandatory methods are in the appendices to 40 CFR part 763 of the AHERA Regulations. These methods are to be used for AHERA TEM protocol in schools for final clearance.
- 5) The entire analysis must be done in a positive pressure clean room.

c. What TEM Measures

- 1) TEM has the advantage of being able to detect very small asbestos particles, but is by itself, not specific. TEM can see fibers as thin as 0.0002 micron diameter and counts fibers as short as 0.05 microns in length. (By comparison, PCM can only see fibers about 0.1 micron diameter and counts fibers longer than 5 microns in length.
- 2) TEM can detect the likely presence of asbestos in a population of fibers by its fiber shape and configuration.
- 3) XRD, x-ray diffraction instruments are used in conjunction with TEM to identify the crystal structure and confirm the identification.
- 4) The combined use of TEM with XRD gives a powerful tool for analysis of small asbestos fibers in the air. Even so, the TEM/XRD analyst must be very careful to avoid false positives since there are many look-alike minerals. In addition, a few problems have been observed where TEM XRD identification has mistaken fibrous talc for anthophyllite asbestos.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

d. Air Sample Conditions Which Prohibit Analysis

- 1) Overloading with particulates
- 2) Blinding with lock-down
- 3) Ruptured filters
- 4) Sample volume of less than 1200 liters

e. EPA Recommendation for Clearance (TEM)

- 1) EPA Requires that for schools, TEM must be used when asbestos quantities exceed **160 sq ft and 260 lin ft.**

Note: DPH as of 12/31/04 will require a NIST Accredited lab for all TEM finals. (19a 332a 12)

- 2) EPA Recommends that TEM be used for all finals.

2. Phase Contrast Microscopy (PCM)

a. Background

- 1) The filter membrane method was used in 1964 in conjunction with the U.S. Public Health Service Division of Occupational Health as part of an epidemiological study of the asbestos products industry.
- 2) The method was evolved as NIOSH Analytical Method # P&CAM 239, Asbestos Fibers in Air. The P&CAM 239 method used 37-mm cassettes, liquid phthalate-oxalate reagent, B counting rules and a Porton reticle compared to the current 25-mm cassettes, acetone triacetin, a Walton Beckett Graticule, and "A" counting rules.
- 3) NIOSH 7400 and OSHA ORM retained the P&CAM 239 variations as options until 1990 when the use of those options became obsolete.
- 4) The OSHA asbestos standard of June 1986 lowered the 8-hour TWA permissible exposure limit (PEL) from the previous value of 2 fibers/cc to 0.2 fiber/cc.
- 5) OSHA promulgated new regulations in 1989 establishing an Excursion Limit EL of 1 f/cc for a 30 min sampling period at the expected time of highest exposure which is still in effect. The standard requires employers to conduct asbestos exposure monitoring of employees. The purpose of monitoring is to determine the amount of respiratory protection needed. This is done by measuring accurately the airborne concentrations of asbestos fibers in a workplace to which employees would be exposed if they were not wearing respirators.
- 6) In 1994, OSHA 1926.1101 replaced 1926.58. With this revision, the OSHA reference method of Appendix B OSHA, Method ID-160 or NIOSH 7400 Method may be used for personal air samples. Note: Only NIOSH 7400 may be used for finals if PCM is used. A new PEL of 0.1 f/cc became effective in 1994.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. Sample Preparation

1) Overview:

The sample is collected by drawing air through a cellulose ester membrane filter by means of a suction pump. (The initial filter on which sample is collected is opaque. The PCM analysis depends on having an optically transparent slide.) The filter is transformed from an opaque solid membrane to a transparent optically homogeneous gel using acetone vapor and triacetin. A "hot block" is used to vaporize acetone. The fibers are sized and counted using a phase-contrast microscope at 400X magnification.

2) Procedure:

- a) Clean slides are pre-labeled with the sample ID.
- b) A wedge of about 1/4 of the filter area is cut from the filter with a scalpel and laid on the slide.
- c) The slide with the wedge is placed in the hot block.
- d) About 300 microliters of acetone is dispensed into the hot block with a syringe and the heat vaporizes the acetone and "clears" the slide.
- e) The slide is removed from the hot block and the outline of the wedge is marked with an indelible pen on the back of the slide.
- f) A drop of triacetin is placed on the cleared wedge.
- g) A glass cover slip is placed over the triacetin.
- h) The edges of the cover slip are sealed with clear nail polish.
- i) The slides are then heated for several minutes to aid in the final clearing.
- j) The slides are now ready for examination on the microscope.

c. What PCM Measures

- 1) PCM has the advantage of being inexpensive and rapid compared to TEM and by itself is not specific. PLM may be used in conjunction with PCM for asbestos identification in air samples. PLM is the classical method for building materials.
- 2) PCM can only see fibers about 0.1 micron diameter and counts fibers longer than 5 microns in length.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

d. Types of Air Samples

1) Personal Breathing Zone Samples:

a) Battery operated pump 2-5 liters/min.

b) NIOSH 7400, OSHA Reference Method, or OSHA Method ID-160 may be used.

(1) All 3 methods count fibers greater than 5 microns in length.

(2) NIOSH 7400 counts all fibers whether they look like asbestos or not.

(3) OSHA reference method (ORM) 1926.1101 Appendix B does not count fibers which are obviously non-asbestos or fibers which can be ruled out as being possible asbestos fibers. PLM is usually used in conjunction with PCM to make the identification of fibers.

(4) OSHA Method ID-160 is identical to ORM.

2) Fixed-Station Area Samples (High Volume Pumps)

a) Final Samples- Only TEM or NIOSH 7400 may be used

b) Other Area samples besides finals- NIOSH 7400, OSHA Reference Method, OSHA Method ID-160 or TEM may be used.

e. AHERA's Limits on the Use of Phase Contrast Microscopy for Post Abatement Testing

1) PCM may only be used for smaller size Work Areas.

2) Schools:

TEM analysis is required for projects disturbing **260 lin ft or 160 sq ft**.

3) For NON-SCHOOL sites in Connecticut

TEM analysis is required for projects disturbing **500 lin ft or 1500 sq ft**

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

F. SAMPLING STRATEGIES

1. Collection of Samples

a. Field Calibration:

- 1) Remove the two end plugs and Calibrate the sampling pump with a representative cassette in line.
- 2) Check the pump flow rate vs a rotometer connected to the intake of the cassette. A tapered hose barb is used to adapt the rotometer to the cassette opening.
- 3) Store the end plugs in the plastic bag. Keep the bag sealed unless adding or removing cassettes or parts.
- 4) A representative filter is always used in the sampling and calibration process. Filters of different resistances or a given filter changing resistance while sampling affects the pressure and therefore the actual flow rate.

b. Blanks:

Two Field Blanks or 10% of sample set, whichever is greater: Momentarily open the end caps on the field blanks and re-seal

c. Labeling and Sample Records:

- 1) Label the sample cassette and blanks with unique ID #s.
- 2) Store the field blanks in the plastic bag.
- 3) Record the following information on a sample worksheet vs the sample ID #:
 - a) Date and site identification
 - b) Type of sample: personal, pre-abatement, during work, final, or general background sample.
 - c) Pump start and ending times
 - d) Starting and ending flow rates
 - e) Temperature and Barometric pressure
 - f) Name and signature of person collecting the sample
 - g) Additional Requirements for area samples:
 - (1) Description of the sample; e.g. in negative air exhaust, outside decon, etc.
 - (2) Location of the sample including a drawing.
- h) Additional Requirements for personal samples:
 - (1) Description of the sample; e.g. Excursion or TWA.
 - (2) Location of the Work Area.
 - (3) Employee name, job title and social security number

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- (4) Type of job activity during sampling
- (5) Type of respirator (NIOSH- approved for asbestos)

d. Calculation:

Sample volume (liters) = flow rate (liters/min) X time (min.)

The entire purpose of calibrating the sampling train is to find out what volume, expressed as cc or liters of air were collected.

(One liter = 1000 cc.) The volume is one of the components needed to calculate the concentration of fibers in air.

("Concentration" is the amount of something relative to the medium that something exists in. Percent (%) is a common expression of concentration that we are familiar with. The concentration of a substance in air is usually expressed as weight, number of particulates, or parts per unit volume of the air sampled.)

In the case of asbestos, the concentration units are fibers per cubic centimeter of air or f/cc.

In order to know how many cc have been collected, we must know the flow rate which is usually expressed in liters/min (l/min). This is part of the information needed to later determine the concentration which is calculated after the PCM analysis of the air sample filter.

The sample volume is obtained by multiplying the sample time by the corrected flow rate as read from the standard used.

2. Personal Sample Techniques:

a. Mounting the Personal Sample:

- 1) Mount the Sampling Pump on the Worker and remove the end cap in order to collect an "open faced" sample.
- 2) Fasten the sampling pump to the worker's belt and fasten the cassette near the worker's mouth,
- 3) Then invert the monitor making certain the exposed filter is facing downward.
- 4) Turn the pump on to the calibrated flow rate (0.5 to 5 lpm).
- 5) Pumps must be mounted in a position which is comfortable for the worker and which provides a secure installation out of the way. In most cases the pump may be mounted at the worker's rear and the tubing strung over the shoulder so the cassette points downward at about 45 degrees.
- 6) Always tape the cassette to the tubing to prevent the cassette from falling off. The resulting dust suck-up can plug a pump and at the least the sample must be discarded.
- 7) Adjust the position of the sample so that the tubing does not pinch.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. Follow up Checking of Sampler:

- 1) Check the sampler position and pump flow rate periodically during the sampling period and record each reading in the worksheet.
- 2) Always check the flow at the end of the sample and record the final reading and time the sample ends in the log book.

c. 8-hour TWA Samples:

Samples taken to determine the 8-hour, time-weighted concentration may have to be changed several times to prevent overloading.

d. "Excursion Limit" (EL) Samples:

- 1) Separate daily sampling must be conducted for the "Excursion Limit" (EL) of 1.0 f/cc over a 30 minute sampling period.
- 2) The EL sample may be taken as one increment of the 8 hour time weighted average PEL. (see discussion below on the EL.

e. Recharging of Pumps:

- 1) Follow manufacturer's instructions. Check the voltage of the pump battery with a voltmeter both with the pump off and while it is operating to assure adequate voltage for operation.
- 2) If necessary, charge the battery to manufacturer's specifications.
- 3) Pump batteries that are repeatedly used for short times and then prematurely recharged will develop a "memory" and eventually the battery will run down at the time it remembers.
- 4) One approach is to fully discharge the battery by running until the battery is depleted and then recharge at the end of each days work.
- 5) Another approach is to keep a log of operating and charging times and follow the manufacturer's recommendation for hours of operation before recharging.

f. Pump records:

Keep an operating log of each pump including the serial number, date put into service, and dates of use and calibration data.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. Review of Strategy for Collection of Personal Samples to Determine EL and PEL Compliance:

a. Objective:

Personal testing is needed for the required assessment.

b. Method: NIOSH METHOD 7400 (PCM) OR ORM OR ID-160

c. Samples Must Include Daily:

30 min excursion limit samples and

8 hour time-weighted average concentration samples.

d. Personal air sampling results must be at the work site within 24 hours

e. Monitoring must be performed on at least 25% of the work force involved in the project. The sampling must cover each type of work operation.

f. Excursion limit monitoring be conducted for each shift, each job classification, and each Work Area in which operations are most likely to produce exposures above the EL.

g. Sampling and calibration for the excursion limit is conducted by the same procedure as that used for monitoring the PEL. One or more samples collected from the breathing zone over the 30 minute period are analyzed, and the results used to determine the 30-minute exposure.

h. The table on the next page shows the optimum flow rates and sampling times required to reach a limit of detection which reliably falls under the 1.0 f/cc EL. **Maximum flow rate allowed is 5 l/min and the minimum is 0.5 l/min**

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

QUANTITATION LIMITS FOR EXCURSION LIMIT ASBESTOS SAMPLING

<u>FLOW RATE</u>	<u>SAMPLING TIME</u>	<u>LIMIT OF LOWER QUANTITATION, LOQ</u> <u>F/CC</u>
5.0 lpm	30 min.	0.0323
2.5 lpm	30 min.	0.065
2.0 lpm	30 min.	0.081
1.6 lpm	30 min.	0.102
1.0 lpm	30 min.	0.163
0.5 lpm	30 min.	0.336

Using 25 mm cassette filters, Based on 10 fibers/100 fields

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

G. COLLECTION OF AREA SAMPLES (Fixed Station Samplers)

1. General:

An area sample differs from the personal sample in several ways:

- a. High volume pumps are used for area samples capable of much higher flow rates.
- b. The area sample is collected at a fixed location
- c. The area sample may not be used for monitoring employee exposure but only for other purposes:
 - 1) "Background" Samples: Various methods may be used.
 - a) Pre-Abatement
 - b) During Abatement
 - c) General information
 - 2) Final Reoccupancy Clearance NIOSH method 7400 (PCM) or Transmission Electron Microscopy (TEM) must be used.
 - 3) Ambient sampling ("background samples") not required by regulatory protocol but is recommended or specified for many purposes

d. Daily monitoring including background sampling is optional and not required by regulations.

2. Sampling Procedure:

a. Electrical:

If the pump is not equipped with an on-off switch, use an external switching device. A five plug receptacle equipped with a circuit breaker and switch is convenient for taking multiple samples. Make sure all power cords are grounded and equipped with a **ground fault circuit interrupter (GFCI)**.

b. Tripod:

Set up the tripod so that the cassette may be secured about 30 inches from the floor.

c. Starting the Sample:

- 1) Place the sample cassette on the tripod
- 2) Remove the end caps
- 3) Collect an "open faced" sample with the cassette pointing downward at about 45 degrees
- 4) Place the end caps in the plastic bag.
- 5) Turn on the pump, making sure to record the time. Timers are useful for unattended samplers to ensure full running time.

d. Check the pump operation and flow rate periodically

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. Pre-Abatement Air Sampling:

a. Objective:

- 1) Determine prevalent airborne fiber concentration at key locations.
- 2) Why is this important?
 - a) Head off problems with getting clean make-up air and failing later finals.
 - b) Liability and disputes which may arise if the building is later found to be contaminated.
 - c) Determine the baseline for future comparison during work and thereby detect an increase in fiber concentrations in key areas.

b. Sampling locations:

Pre-Abatement air samples should be collected at strategic locations inside and outside the planned asbestos Work Area to establish prevalent ambient air concentrations under normal building activity before the asbestos abatement work begins. Strategic locations are those where later problems are commonly encountered or where concentrations are critical:

- 1) Outside the Decon clean room/ Waste Bag-out area
- 2) Negative air exhausts
- 3) Closest approach corridors

4. Final Reoccupancy Testing after asbestos abatement

a. Objective:

In addition to the visual inspection, determine if area is acceptable for reoccupancy by deliberately blowing up any possible asbestos dust into the air and collecting this airborne dust for analysis.

b. Selection of Sample Locations:

- 1) For symmetrical Work Areas take middle and near four corners.
- 2) For irregular Work Areas, include at least one sample in each extension.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

c. NIOSH Method 7400: (PCM)

1) **Five samples required in each work area.**

2) We recommend to collect 1200 liters for each sample. (The minimum volume specified in the NIOSH 7400 method is 400 liters, however few, if any, professionals take the minimum amount for the sake of reliability.)

3) **Maximum flow rate is 16 liters/min.**

(Calculation of theoretical volumes Air Monitoring volumes must be sufficient to provide a lower detection limit (LOD) of 0.010 fibers/cc. The minimum sample volume needed is theoretically 270 liters based on the LOD of 5.5 f/cc or 7 f/mm² for NIOSH 7400. To attain the lower limit of quantitation (LOQ) of 10 fibers/100 fields, a volume of 500 liters is needed. To obtain samples in the preferred filter loading range of 100-500 f/mm², an infinitely large sample would be needed which would most likely be blinded by ambient dust before the desired loading is reached.

4) Each of 5 aggressive air samples in the Work Area must have a concentration of 0.010 fibers/cc or less according to EPA regulations for schools or according to Connecticut Regulations.

d. TEM Final Sampling:

1) **Collect 5 or more samples of at least 1200 liters aggressively in the Work Area, and the same number of samples non-aggressively at the same time outside the Work Area. For multi-level areas, take 5 samples on each level.** For areas over 5000 sq ft take one added sample for each additional 5000 sq ft.

2) Use a 0.4 micrometer porosity MCE or polycarbonate filter.

3) Calibrate pump flow rate using a rotometer at beginning and end of sampling and a representative filter.

4) Between 1 and 10 liters/min must be used.

5) A typical strategy for rapid sampling is 10 l/min for 120 + minutes to produce a volume of 1200 + liters.

6) Prepare two field blanks and also reserve one sealed blank.

7) Make very sure to have at least 1200 liters since a smaller sample will be rejected.

8) Be especially careful not to contaminate the sample cassettes. Use a separate filter of the same lot to calibrate. Keep all the parts in the plastic bag and in a clean location.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

e. Aggressive Sampling:

- 1) Thorough visual inspection of the Work Area
- 2) Critical barriers remain in place
- 3) Air filtration units remain on
- 4) Use a minimum 1 horsepower leaf blower directed at floors, walls, and ceilings five minutes before sample collection.
- 5) Note: ASTM E-1368 (**American Society for Testing and Materials**) specifies use of sweeping or brushing, leaf blower or 20 inch stationary fans directed at the ceiling, 1 per 10,000 ft³ to keep the air agitated. (EPA 560/5-85-024).

5. During Abatement Monitoring

a. Objective:

- 1) Determine if there has been an increase above baseline values so that corrective action may be taken.

b. Sampling locations:

- 1) Collect samples at the same locations as for pre-abatement sampling.
- 2) Usually, area sampling is not done inside the asbestos Work Area. (Personal sampling is required inside the Work Area.)
- 3) If samples exceed the baseline or if they exceed 0.01 f/cc, then corrective action is needed.

H. SPECIAL SAMPLING PROBLEMS

1. Crawl Spaces and Tunnels

- a. Distributing the sampling pumps requires several multi-plug GFCI receptacles from which various length power cords may be run to cover the entire space.
- b. Have the pumps placed and ready to turn on before using the leaf blower.

2. Occupied Areas for Barrier Monitoring:

- a. In occupied areas, close supervision of the sampling is essential since onlookers will often disturb the pumps.
- b. Try to locate pumps out of traffic patterns
- c. Make sure to duct tape extension cords to avoid trip hazards.
- d. When possible, use a barrier tape or other set-back to keep traffic out of the sampling area.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. Dusty Areas and Acceptable Samples for Laboratory Analysis

- a. The Monitor is required to flashlight and look at the filter face for gross amounts of dust. Samples with excess dust must be rejected.
- b. Construction areas and some types of manufacturing operations are dusty by nature. For heavy particulate levels, it may be necessary to limit the sample volume for each sample and take successive samples until the lab has a chance to characterize the site conditions.
- c. The next consideration is to obtain a high enough fiber count on the filter to get a reasonable level of precision. At the least, an adequate fiber density is desired to obtain a minimum count of 10 fibers in 100 fields, which is the least total fiber count that yields an acceptable count precision. This filter loading is known as the lower quantitation limit (LOQ).
- d. When an agglomerate (mass of material) covers more than 25% of the field of view, reject the field and select another. Do not include it in the number of fields counted.
- e. If one has very little idea of airborne fiber and particulate levels, the best procedure is to take several long samples (as one 8 hour or two consecutive 4 hour samples) in conjunction with several short samples (as four consecutive 2 hour or eight consecutive 1 hour samples. If the longer samples prove very difficult to count, the microscopist will have the shorter samples to fall back on.
- f. The nature of the sampling environment and visible observation of dust are good indicators of when to shorten the samples.
- g. After the first day at a steady state site, the sampling strategy can be optimized.
- h. During an asbestos abatement project, the fine mist created by spraying encapsulant (Lock-Down Spray) frequently blinds air samples. This will be seen by the microscopist as white spheres on the filter. It is best to have the sample cassette changed before and after this operation and wait at least one hour before starting final samples.
- i. Final Air Samples:
 - 1) In clean atmospheres with little dust, very large samples may be taken. Hopefully, the final area is dust free.
 - 2) One problem is entry of dust from outside the Work Area which contaminates the Work Area and of course the samples. In this case the area is likely to fail and the contractor should be encouraged to bring fresh make up air in from a clean area or from the outside by means of extra ducting.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

I. INTERPRETATION OF RESULTS AND CALCULATIONS:

1. Personal Samples TWA:

- a. Compare the time weighted average with the PEL and the 30 min excursion result with the EL:
- b. Calculate the time weighted average (TWA) exposure for each employee as in the following example:
- c. Divide the sampling periods into decimal fractions of the working day and multiply that fraction times the concentration for that portion of the day: Then add the products of the multiplication to get the TWA.

Example:

The first sample is 1/2 hr with a concentration of 2.0 f/cc.

The second sample is 3 1/2 hrs including lunch and breaks with a concentration of 0.6 f/cc.

The last sample is 4 hrs including breaks with a concentration of 0.2 f/cc.

<u>hrs</u>	<u>dec fract of day</u>	<u>x</u>	<u>f/cc</u>	<u>=</u>	
.5	0.063		2.0	=	0.126
3.5	0.437		0.6	=	0.262
4	0.5		0.2	=	0.100
					0.488= TWA f/cc

The TWA is above the PEL but less than 1 f/cc and therefore supplied air respirators are not needed, but all work practices including respirators must be followed as for a regulated area.

- d. Another method is to use the equation:

TWA =

$$\frac{C_1T_1 + C_2T_2 + C_3T_3 \dots}{T_1 + T_2 + T_3 + \dots}$$

where C is the fiber concentration expressed as f/cc
T is the duration of the sample (in hours)

Using the above Example:

$$\frac{(2)(0.5) + (0.6)(3.5) + (0.2)(4)}{.5 + 3.5 + 4}$$

$$= 1.0 + 2.1 + .8 / 8 = .488 \text{ f/cc (TWA)}$$

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Excursion Limit (EL)

1.0 f/cc over a 30 minute sampling period.

The EL sample may be taken as one increment of the 8 hour time weighted average PEL.

Example:

A Work Area has 6 workers; 4 removing pipe insulation and 2 bagging.

Worker 1 is removing in an area with much prior damage and likely to have the highest exposure of the group and especially when he begins.

The following should be done:

- a) Take a 30 min excursion sample for the first half hour for worker 1.
- b) Take a TWA sample for the balance of the work day for worker 1.

If the Work Area is dusty, split the remaining 7 1/2 hours between two samples to avoid blinding filters.

- c. Take an 8 hour TWA sample or two 4 hour samples for one of the workers bagging.

3. During Abatement Monitoring:

If readings increase above the baseline:

- 1) Re-run the during work and baseline samples by OSHA Method ID-160 to see if the increase is due to asbestos fibers.
- 2) Reason: determine whether the work is causing asbestos contamination outside the containment including the negative air exhausts and detect and correct problems early in the process; or prove the asbestos fibers did not escape to avoid liability and disputes which may arise.

4. Final Clearance Testing

Compare values to regulated standards cited above and if the observed values exceed the standards one of the following common reasons should be checked out:

- 1) Visual missed something? Reclean
- 2) One negative air unit not running and fibers getting sucked into containment by other machines?
- 3) Dirty air entering? Check outside samples.
- 4) Final run too soon after abatement? Wait overnight and re-test.
- 5) Other sources of asbestos in the Work Area not in scope of work? May need abatement.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

J. QUALITY ASSURANCE

1. Objective:

Establish and maintain high standards of performance, quality control, and produce accurate and precise analytical results.

2. Sample Collection:

- a. Calibrate all sampling equipment as described above.
- b. All labels on filters should be coded to prevent bias by lab personnel.
- c. 2 Field blanks as described above.
- d. Recheck visual while pumps are running.
- e. Check filters visually for dust
- f. Double check labels on samples vs site work sheets before leaving site.

3. PCM Analysis

- a. Training: **NIOSH 582 or equivalent course** for sampling and evaluating airborne fibers.
- b. Reference slides: Permanently mounted field control slides to be used on a daily basis.
- c. Blind Recounts:

At a rate of 10%, the analyst will recount previously run samples at random from the completed sample storage containers. Analysts re-run these slides blind.

- d. AIHA-AAR Proficiency Testing:

To be a registered analyst, one must pass the NIOSH 582 course or equivalent. At a frequency of at least every 4 months, each analyst is required to run a set of 4 AAR samples and must maintain AAR (Asbestos Analysts Registry, American Industrial Hygiene Association) proficiency. This program requires submittals to AIHA, analyst training, participation in the AAR proficiency testing program, an adequate quality assurance program, training of analysts. There is no site visit by AIHA.

- e. Comparison with another Operator Outside the laboratory:

At a frequency of at least every 6 months, four previously run samples are exchanged (our samples submitted to outside laboratories for analysis and a similar number received from the same laboratories).

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

f. Calibration Procedures:

Alignment of the microscope is checked at each sitting for each analyst: after focusing on a PAT (Proficiency Analytical Testing) program slide, the condenser centration is checked using a centering telescope and adjusted as needed as detailed in the analytical method.

At least daily: The microscope is checked with a phase test slide (Align the phase annulus and phase plate).

The Walton Beckett Graticule is checked when new with a stage micrometer.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

SECTION 8

SAFETY AND HEALTH ISSUES OTHER THAN ASBESTOS

A. ELECTRICAL SAFETY

(See OSHA CFR 29 1926.402 and .416-.417)

1. Construction electrical installations must comply with 1984 National Electric Code and meet additional requirements.
2. Check existing power for proper grounding, exposed wires and panels and safe access.
3. Determine whether electrical equipment in the Work Area which may get wet or be contacted by workers can be safely shut down.
4. Do not interfere with existing alarms and sensors.
5. Use lock out/tag out procedures.
6. Use only grounded outlets and 3-wire heavy duty cords with GFCI protection (Ground Fault Circuit Interrupter).
7. Power cords must not be hung by staples or nails.
8. Check all electrical equipment daily for damage, especially power cords and including HEPA vacuums, HEPA negative air units, temporary lighting, and power tools. Grounding continuity tests of equipment must be made at least every 3 months.
9. Use non-metallic tools as applicable. Do not use metal ladders.
10. Lamps for general illumination must be protected from breakage and metal shells grounded.
11. Temporary lighting must not exceed 12 volts and must be CFCI protected. Temporary lights must not be suspended from their cords unless they are designed to be hung this way.
12. For high work including exterior abatement, plan carefully for overhead wires and other electrical equipment.
13. Do not lay electrical cords over wet surfaces.

B. LADDER SAFETY (SEE OSHA 29 CFR 1926.450)

1. Regular inspection for defects- cracks, splits, missing or weak rungs.
2. Use correct ladder for the job. No jury-rigged ladders
3. No metal ladders where electrical hazards exist
4. Keep rungs free of residue during work

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

5. 4:1 lean ratio for ladders

6. Do not paint rungs or rails

7. No ladders in passages or doorways unless protected by barriers.

8. Ladders tied off at top to prevent dislodging.

C. SCAFFOLD SAFETY (See OSHA CFR 29 1926.450-454 Amended 8/30/96)

1. General Requirements:

- a. Scaffold must support at least 4 times the intended load.
- b. Designed by a qualified person.
- c. Platform fully planked at all levels and no space more than 1 inch between the platform and uprights.
- d. Platform or walkway must be at least 18 inches wide (with some exceptions).
- e. Front edge of all platforms not more than 14 inches from the face of the work (when work face is to the side) unless guard rails or personal fall arrest measures are used. Except: Outrigger scaffolds: front edge not more than 3 inches from the face of the work.
- f. Secure platform or use required overhang of at least 6 inches. Overhang can't be more than 12" for a <10 ft platform; no more than 18" for a >10 ft platform with some exceptions.
- g. Each end of abutted plank must rest on it's own support.
- h. No opaque finishes used for wood platforms.
- i. No mixing of different component brands with some exceptions.
- j. No mixing of different metals unless competent person determines there will be no galvanic action.
- k. No more than 4:1 height : base ratio for supported scaffolds.

2. See Special Requirements for Specific Scaffolds in the regulations cited:

3. Highlights of other requirements:

- a. Regular inspection
- b. Dimensions conform to standards
- c. Maintenance of wheels or castors in good condition
- d. Properly secured components
- e. Practices to keep clean during work

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- f. Guard Railings 42 inches high required for work over 10 ft off ground
- g. Stringing of electrical wires for electrical and trip safety
- h. Proper lighting where scaffolds are used
- i. Fall protection screen required under scaffold where workers may walk under
- j. Condition of flooring for movable units
- k. Maximum spans for 2x10 ft planking full dressed lumber:
 - 25 pounds/sq ft maximum 10 ft span
 - 50 pounds/sq ft maximum 6 ft span
- l. Safe access requirements including secured ladder or stair tower.
- m. Reinforcement includes diagonal and cross bracing
- n. Safety considerations for riding mobile units
- o. Competent Person must oversee construction and take-down.

D. FIRE (AND EXPLOSION) Safety (see OSHA 29 1910.38 and 1926.24 and 1926.150-155)

Key Points for Fire Prevention and Response at Abatement Sites:

1. Polyethylene burns similarly to candle wax. Fire resistant poly should be used but not much better in some cases than ordinary poly.

- a. Special precautions for containing hot surfaces
- b. Written emergency action plan and fire prevention plan
- c. OSHA Fire Protection and Prevention includes requirements for:
 - 1) Temporary or permanent water supply for fire protection.
 - 2) A trained fire fighting brigade as the project warrants.
 - 3) Portable fire extinguishers of a 2A rating for every 3000 sq ft of the Work Area. Point of travel to the nearest fire extinguisher must not exceed 100 ft. Where more 5 gal of flammable or combustible liquid exists, a 10B fire extinguisher must be located within 50 ft of the material. (This is likely to include gasoline used for generators.)
- d. Ensure that the area allows a quick and easy escape route and all workers are briefed on escape.
- e. No smoking, no welding, no other ignition sources near flammable materials.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- f. Make sure outside contractors or other building occupants who may work near the area are aware of the safety requirements.
- g. Notify local fire marshall
- h. Emergency equipment on hand including fire extinguishers and first aid kits.
- i. Do not block exits

E. HEAT RELATED DISORDERS

1. Be watchful in summer and in work in hot areas.

2. High Work Area temperatures, extended work in hot environments with protective suits, insufficient salt and fluids will cause these disorders.

3. Progressive in nature becoming more severe as exposure continues and can lead to a fatal condition resulting from heat stroke:

4. Prevention:

- a. Drinking water, fruit juice, Gator Aid,
- b. Frequent breaks, cooling, ventilation, breathable suits.
- c. Salt on an individual basis
- d. PAPR's and other forced air respirators are preferred

5. Emergency plans must be ready in the event medical treatment is needed.

6. Heat Fatigue:

- a. Profuse perspiration and tiredness always precedes the more serious disorders below. May also have heat cramps which are severe intermittent abdominal and arm and leg muscle pains.
- b. Give about 1/4 teaspoon of salt in a glass of water.

7. Heat exhaustion:

- a. A state of very definite weakness.
- b. Pale cool clammy skin, weak and rapid pulse, tense muscles.
- c. Remove from hot area and lay down with feet elevated higher than head; keep quiet.
- d. Get medical help. If conscious give salt tablets and fluids such as fruit juice. Keep warm to avoid shock.
- e. Lack of prompt detection and care can result in heat stroke.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

8. Heat stroke:

- a. High body temperature (over 105 degrees), dry skin (no perspiration), headache, numbness or tingling and confusion prior to sudden delirium or coma.
- b. Needs immediate emergency medical treatment with initial injection of normal saline (salt water).
- c. While awaiting help, place in cold water or ice bath if available. Wrap naked in wet sheets while awaiting help or during transport. Do not let body temperature get below 103. Victim usually cannot take fluids or salt orally at this point of the progressive illness. Lack of prompt care can result in uncontrolled increase of body temperature and death. Will be fatal if salt water is not administered in time.

F. CHEMICAL AND BIOLOGICAL HAZARDS / Dust and Air Contaminants other than Asbestos:**1. Building Material Sources:**

- a. Building owner must provide list of hazardous materials already at the site and information about these materials. Always refer to MSDS's. (Material Safety Data Sheets).
- b. Lead and Cadmium dust from paint and plumbing and demolition.
- c. Watch out for PCB'S in transformer areas and fluorescent ballasts.
- d. Mercury: toxic, has appreciable vapor pressure- inhalation hazard
Mercury in instrument areas and laboratories may be present in flooring. Mercury may be present in latex paint; usually present in florescent fixtures.
- e. Mold and bacterial contamination around HVAC systems- slime and Legionnaires disease
- f. Hospitals: viral and bacterial contamination and carcinogenic chemicals such as ethylene oxide and formaldehyde.
- g. The employer is responsible to provide appropriate employee protection for all hazards at the work site.

2. Substances used in or Introduced into Facilities

- a. Always refer to MSDS's. (Material Safety Data Sheets).
- b. Conform to "Right to Know" Program
- c. Building owner must provide list of hazardous materials already at the site and information about these materials.
- d. Spray glue: fire and inhalation hazard.
- e. Surfactants: see MSDS

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- f. Cleaners: see MSDS
- g. Gasoline: flammable, inhalation, skin absorption, toxic
- h. Encapsulants: usually irritants
- i. Other Flammable materials
- j. Bird droppings
- k. Other sanitation problems such as old toilets

G. SLIPS TRIPS AND FALLS

- 1. Stairs: Covering non-slip and free of objects and debris**
- 2. Extension cords: out of path or secured under walkable surface.**
- 3. Lock-down Spray problems**
- 4. Proper ladder and scaffold use**
- 5. Roofing safety**
- 6. Housecleaning and Storage Practices**
- 7. Airlines used with supplied air units**

H. POWER TOOLS (see 29 CFR 1926.302 for electric and pneumatic power tools)

I. CONTROL OF HAZARDOUS ENERGY LOCKOUT/TAGOUT (see CFR 29 1910.147) Pertains to unexpected energization of a piece of equipment which may cause injury. Employer must have a standard operating procedure and training.

J. SUPPLIED AIR RESPIRATORS- carbon monoxide

K. GENERAL CONSTRUCTION HAZARDS FROM FALLING OBJECTS-

Hard hats and other prescribed equipment including safety goggles and steel tipped shoes.

L. CONFINED SPACES:

See OSHA CFR 29 1910.46 if a confined space is to be entered;

1. A space:

- a. Large enough for entry and work but restricted entry and exit and
- b. Not intended for continuous occupancy.

2. May contain hazardous atmosphere: Must test for: Oxygen, combustibles, carbon monoxide, hydrogen sulfide and any other suspected air contaminant.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

3. Must have separate training and specialized equipment for confined space entry.

M. OTHER HAZARDS.

1. Exterior work in inclement weather frost bite and exposure protection
2. Cuts- infections
3. Drinking and drugs- effect on coordination and thinking
4. Sanitation- personal hygiene practices for disease protection in the field

N. LEAD DUST ON ASBESTOS JOBS:

1. Most dangerous when in the form of dust or fumes
2. Lead dust settles on flat surfaces. Hand to Mouth contact results in exposure
3. Can breathe lead dust resulting in exposure
4. Lead Sources on the Asbestos Job

- a. Paint and dust and soil, largely from paint
- b. Lead solder in pipes and fixtures
- c. Demolition
 - 1) Plumbing
 - 2) Painted surfaces, walls and ceilings
 - 3) Lead containing mortar
 - 4) Ceramic glazed materials
 - 5) Floor tile
 - 6) Baseboards
 - 7) Welding and cutting steel work with lead primer
- d. Lead abatement
- e. Preparation for painting (sanding, etc)
- f. Metal stripping and refinishing
- g. Lead containing sites
 - 1) Lead mining, smelting and refining
 - 2) Lead crystal makers
 - 3) Ceramic glaze manufacturers
 - 4) Plastic manufacturers
 - 5) Wire and cable manufacturers
 - 6) Electronics manufacturers
 - 7) Firing ranges
 - 8) Artists
 - 9) Metal fabricators

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- 10) Car mechanics
- 11) Printers
- 12) Scrap / recycling yards

j. Industrial Uses

- 1) Tank linings and Radiation shielding
- 2) Piping for corrosive gases and liquids
- 3) Bearings
- 4) Storage batteries
- 5) Ceramics or Plastics
- 6) Electronic devices
- 7) Specialty alloys for corrosion resistance including solder
- 8) Corrosion resistant coating on steel cable
- 9) Pigment in rubber
- 10) Laboratory
- 11) Ammunition

10. Health Effects

- a. Central and Peripheral Nervous System
- b. Reproductive Effects
- c. Gastrointestinal Effects
- d. Renal (Kidney) Toxicity
- e. A cumulative poison:
- f. Dose-Response Relationship
- g. Symptoms usually don't develop until some damage is done
- h. Slow rate of discharge from the body

11. Blood Lead OSHA Standard

- a. 40 micrograms/ deciliter (ug/dl) or higher, testing every two months
- b. 50 ug/dl or higher, medical removal

12. Typical Adult Blood Lead Reactions

15- 25 ug/dl: Increase in blood pressure; harmful effects on fetus, joint and muscle aches Reproductive problems

40 ug/dl: Kidney damage; damage to blood formation.

60 ug/dl: Anemia; nerve damage; constipation; stomach pains; irritability and fatigue; memory and concentration problems; clumsiness; drowsiness and sleep problems.

80 ug/dl and higher: Blue line on gums; uncontrollable shaking of hands; wrist and foot drop; hallucinations; brain damage; coma; death.

12. Prevention

- a. Have suspect materials tested
- b. Wear protective gear (same as for asbestos)
- c. Use good personal hygiene (same as for asbestos)

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

SECTION 9

CONDUCTING VISUAL INSPECTIONS

The ASTM E1368 Document "Standard Practice for visual Inspection of Asbestos Abatement Projects" procedures are incorporated into this text.

Full protective gear is needed by the Project Monitor for entry throughout the inspection.

A. INSPECTIONS DURING ABATEMENT:

1. Determine the Scope of the Abatement Work

- a. Obtain this from the job specification
- b. Locate the materials to be abated and note any discrepancies between the stated work and what is actually there.

2. Monitor Performance During the Abatement Work

Obtain requirements from the job specification and the regulations cited. See During Work Check List already mentioned.

B. INSPECTIONS AFTER ABATEMENT:

1. Enter All Spaces in the Containment

- a. Verify Scope of the Abatement Work has been completed.
- b. Go with supervisor and worker equipped with HEPA vac and cleanup materials.
- c. Get close enough to touch and flashlight surfaces
- d. Ladders or other equipment may be needed to reach all areas.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. Completeness of Abatement/Removal

- a. Verify Scope of the Abatement Work has been completed.
- b. Touch surfaces to check for residue - white glove inspection.
- c. **Illuminate surfaces with a powerful narrow-beamed flashlight aimed along the surface. Hold the flashlight close to the surface and parallel to the surfaces so residue is readily seen. Block off room light glare while flashlighting.**
- d. Filter cassette and sampling pump to collect and check for residue.
- e. Pay special attention to difficult to reach areas early in the inspection process.
 - 1) Spaces between steel beams.
 - 2) Corners
 - 3) Remote areas above drop ceilings.
 - 4) T-grid if it remains
 - 5) Under baseboards
 - 6) Behind doors and equipment remaining.
 - 7) Elbows, valves and T's
 - 8) Inside boiler section openings
 - 9) Under equipment with legs
 - 10) At edge of critical barriers
 - 11) In decon area
 - 12) Furthest point of any crawl space.
- f. Contractor must repeat cleaning and complete any work missed.
- g. Sealer (lock-down) may be applied only after a successful visual.
- h. Note the presence of any ACM which remains in the Work Areas and which is not in the scope of the work.
- i. Verify equipment cleaned and bags removed
- j. Inspect again after lock-down (tinted lock-down to verify coverage).
- k. It is a good idea to leaf blow around the baseboards, ceiling beams and other places where crevices may exist since the blower may pick up dust that can't be seen otherwise. If the blower picks up visible dust at any time, then reject the area which needs further cleaning.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

C. HOW CLEAN IS CLEAN:

1. No loose residue or debris of any kind which can be seen without the aid of magnification (other than eye glasses). This applies even if the residue or debris is known not to be ACM.

2. No build up of ACM material should remain on surfaces where ACM was removed.

3. Flooring on concrete substrates:

a. With floor tile mastic removal, a black stain usually remains.

b. If floor tile mastic removal is in the scope of the work, no mastic buildup is allowed. Buildup may be detected by:

1) Flashlighting, Side-lighted (Shine light along the floor.)

2) Knife penetration

a) Soft, easily penetrated layer indicates mastic buildup is still present which is probably wet with mastic remover.

b) Hard build up which chips off with the knife and shows black cross-section indicates mastic buildup is still present.

3) By touch, ridges are felt.

c. If leveling cement has been used under the floor tile, then both removal and inspection are difficult since these leveling compounds do have the appearance of edge build up but are not known to contain ACM. If not covered in the specs, the best method is to bulk sample the levelastic. Also the levelastic can be distinguished from mastic because it is white or off-white and hard while mastic is brown or black and softer to the knife's touch. Levelastic may remain unless the spec calls for it's removal as well. If levelastic is removed, the floor may need to be re-leveled at extra cost.

4. Flooring on wood substrates:

a. Floor tile mastic removal is never satisfactory when the floor has cracks or planking spaces since the mastic is between the cracks. If the spec does not handle this, there are several options:

1) Get concurrence of owner to remove wood entirely if he wants the mastic gone or to reduce scope of work to allow mastic to remain in cracks provided that no buildup remains to interfere with new flooring.

2) If the floor is to be demolished, then the abatement contractor should get off the wood with the mastic. It is cheaper than trying to clean the mastic between the cracks.

3) Usually, the finish wood floor is 3/4 inch and there is a 3/4 inch sheathing below. If the floor is not being demolished, get the concurrence of owner/and a structural engineer if the finish flooring is to be removed to replace with 3/4 inch plywood.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

5. Dirt Floors

- a. No pieces of ACM
- b. No visible debris
- c. Thoroughly locked-down. Core samples should have a definite cohesion near the surface to the depth specified by the Project Designer. If core samples do not have this property, then insufficient or the wrong type of lock-down was probably used.
- d. If a definite depth of soil was to be removed, then a reference mark is needed at several locations before the removal, so that the removal depth can be measured accurately. A transit or plumb level may be needed to evaluate the excavation.

6. Spray-on

Not only the ceiling beams and surfaces need to be inspected but the walls inspected for overspray using a flashlight directed along the wall and by touching.

D. COMPLETENESS OF ENCAPSULATION

- 1. Core samples may be needed to determine the thickness of a bridging encapsulant or the depth of penetration of a penetrating encapsulant, if the thickness is specified in the specifications. The core samples may be examined using a stereo microscope at about 10X.**
- 2. A tint should be used with the encapsulant to be able to verify complete coverage.**
- 3. There must be no loose or hanging pieces of encapsulated ACM and the installation should be neat.**
- 4. Other surfaces in the Work Area must comply with the same non-visible residue criterion as for removal described above.**

E. COMPLETENESS OF ENCLOSURE

- 1. Visually confirm that the enclosure installation is air tight and meets the required specifications.**
- 2. Enclosure secured to fixed building components.**
- 3. ACM inaccessible from outside the enclosure.**
- 4. Before enclosure, the ACM material is usually first encapsulated and inspected as above.**

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

F. REVIEW OF FINAL CLEARANCE PROCESS:

- 1. Initial visual inspection**
- 2. Flashlight and touch surfaces**
- 3. Equipment not in use cleaned or sealed and removed.**
- 4. Bags removed**
- 5. Change HEPA unit filters**
- 6. First layer of plastic removed and the area HEPA vacuumed and wet wiped**
- 7. Lock-down spray applied to cleaned surfaces and to plastic barriers.**
- 8. All remaining plastic other than critical barriers may be removed.**
- 9. Touch-up cleaning with Optional leaf blowing**
- 10. Dry at least overnight.**
- 11. Critical Barriers must remain sealed**
- 12. Negative Air Units and Decons remain in operation**
- 13. Floor plastic should be removed before final testing unless the floor plastic is a Critical Barrier such as over a grate or other open surface. In this case, the person making the final inspection should so note in his report and another visual made after the criticals are removed.**
- 14. Shower must remain operational until after successful final air test.**
- 15. The final air samples MUST be collected aggressively.**
- 16. Analysis conducted by TEM or PCM as specified in the regulations: TEM may be used anytime and EPA recommends that TEM be used. PCM may be used for smaller size Work Areas as specified below.**
 - a. For schools:

TEM analysis is required for projects disturbing 260 lin ft or 160 sq ft.
 - b. For NON-SCHOOL sites in Connecticut

TEM analysis is required for projects disturbing 500 lin ft or 1500 sq ft
- 17. Standard For PCM:**

Each of 5 aggressive air samples in the Work Area must have a concentration of 0.010 fibers/cc or less.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

18. For TEM:

Average of 5 samples in Work Area below 70 S/MM² or statistically less than the Asbestos determined outside the Work Area.

19. Collection of FINAL TEM Samples

- a. 0.4 micrometer porosity MCE or polycarbonate filter.
- b. Calibrate pump flow rate using a rotometer at beginning and end of sampling on a representative filter.
- c. Be especially CAREFUL not to contaminate the sample cassettes. Use a separate filter of the same lot to calibrate.
- d. Aggressive sampling
- e. Collect AT LEAST 1200 LITERS of air
- f. Collect the same volume of air for samples inside and outside the Work Area
- g. Collect 2 field blanks by opening the cassettes in the sample pouch for the duration of sampling: one collected inside and one outside
- h. Collect 1 sealed blank: This is a filter from the same lot as the previous 12, taken to the work site, never opened, labeled, and returned to the laboratory.

20. For TEM or PCM samples:

- a. Never sample within an hour after spraying lock-down since the filter will likely be blinded by the spray.
- b. This can be a costly mistake since one blinded sample will void a set of five.

20. Laboratory Qualification Requirements for Asbestos Air Samples

a. PCM

1) Labs running finals in Connecticut must be Accredited by the AIHA (American Industrial Hygiene Association). Accreditation requires application to AIHA, and many rigorous requirements including staff qualifications and procedures, analyst training, participation in the PAT (Proficiency Analytical Testing) program, an adequate quality assurance program, and site audit visits by AIHA. **For scope on site AIHA AAR Registered analyst must be used.**

2) DPH Approved Public Health Lab or Approved Environmental Lab

b. TEM Accreditation

National Institute of Standards and Technology (NIST) **required for schools**, recommended for all buildings. **Note as of 12/31/04 DPH will require NIST accreditation for all TEM finals.**

21. No occupancy until test is satisfactorily completed

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

22. Need for site specific instructions by Project Designer for final inspection and air clearance.

- a. Influence on project cost vs possible shortcuts to be avoided.
- b. Exercise of Project designer's greater expertise.

23. Relationship between Visual Inspection and Air Test Results.

- a. 90 % of failures is due to failed visual inspection.
- b. Must always be an explanation for failed air test results, inside vs outside contamination, final too soon after abatement, improper lock-down or hidden residue.
- c. Discussion of subjective nature of visual inspections and how a specification can impose objective criteria that will help ensure successful air tests.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 10-1

Legal Responsibilities/Liabilities of Project Monitors:

- **SPECIFICATION ENFORCEMENT CAPABILITIES;**
- **REGULATORY ENFORCEMENT;**
- **LICENSING AND POWERS DELEGATED TO PROJECT MONITORS THROUGH CONTRACT DOCUMENTS.**

Preface:

This training material is intended as a general guide to legal issues, and is not to be considered as legal advice.

Consultants involved in monitoring in buildings must be aware of the legal implications of their work and the potential liability involved. It is important to thoroughly plan and execute the work.

The Project Monitor must plan carefully to avoid legal problems, disputes or litigation. He should obtain advice from a competent attorney addressed to the general parameters of the work and the contract and to the particular job situation.

A. PROJECT MONITOR RESPONSIBILITIES

1. DPH Regulations Authorizing Legal Responsibility and Liability

Following is a key statement extracted from DPH regulations fixing responsibility and liability for not only the Project Monitor own work but for other work associated with the abatement project monitored.

20-440-3. (d) (4) (A)

Project Monitor Scope of Licensure. Licensure as a Project Monitor authorizes the asbestos consultant to function in the capacity of on-site representative of the facility owner or other persons, interpret project specifications or abatement management plans, monitor and evaluate contractor or employee compliance with applicable regulations or specifications and ensure that abatement projects are properly conducted and completed.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. General Project Monitor Duties:

- a. Specification Enforcement Capabilities; Regulatory Enforcement
- b. Final clearance testing.
- c. Authority:

Project monitor by virtue of his license has enforcement authority. This should be consented by the owner so that the Project Monitor should have authority from the owner to shut down or restrict work operations in the event of:

- 1) Non-compliance or
- 2) In emergency situations including excessive airborne fibers observed outside the Work Area: either greater than 0.01 fibers/cc or any value above the baseline level.

3. Enforcement of Contractor Duties:

The Project Monitor may be held responsible for Contractor requirements, including any of those listed below. In general, the Project Monitor is expected to enter the containment for the Pre-abatement inspection and again for the final. Otherwise the Project Monitor must be stationed outside the perimeter of the containment to protect the building occupants. It is recommended to use clear vision ports installed in the containment walls so that the Project Monitor can see what is going on inside. Most of the compliance items can be checked from the outside perimeter. If the Project Monitor must enter the containment during removal, he must use the same personal protection as the abatement personnel.

- a. Personal Protection including appropriate respirators, disposable suits, and other safety equipment. This includes the Project Monitor when he goes in the containment.
- b. Posting signs to comply with OSHA 1926.1101 and NESHAP Supervisor's training Certificate. Proof of AHERA Accreditation and State of Connecticut DPH required Asbestos Supervisor/Monitor training is required to be posted to show compliance with the NESHAP requirement.
- c. Maintaining copies of Regulations on site including 1926.1101 and 40 CFR.61 and the Connecticut General Statutes Sections 19a-332-1 through 19a-332-16 inclusive.
- d. Proper Decontamination procedures such as proper use of suits and shower and that the shower and other safety equipment are properly functioning. Make sure workers are not wearing street clothes under their suits, this is an indication that they are not using the shower. Also look into the clean room as the workers are exiting. Hair should be wet otherwise showers are not being used properly.
- e. Ensuring OSHA requirement for no smoking is observed.
- f. General Condition of the Work Area and operation of control equipment at each phase of the project is in accordance with regulations.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

g. Proper preparation of the Work Areas including:

- 1) Electrical preparation and fire safety
- 2) Temporary power and lighting.
- 3) Locations of Decons and negative air units.
- 4) Shut down and/or isolation of heating, cooling and ventilating air systems to prevent contamination and fiber dispersal to other areas of the facility.
- 5) Integrity test of critical barriers.
- 6) Pre-cleaning completeness
- 7) Airlocks at entrances to and exits from the Work Areas.
- 8) Maintenance and marking of emergency exits.
- 9) Preparation of the Decontamination (Decon)) Unit
- 10) Proper separation of Work Areas from Occupied Areas
- 11) Proper tent enclosure, walls and floors as applicable.
- 12) Access Routes controlled
- 13) Negative air pressure
- 14) Signs posted

h. Proper Abatement Procedures including:

- 1) Respirators
- 2) Personal Monitoring
- 3) Fit testing
- 4) Suits
- 5) Wet removal
- 6) Shower and Decon use
- 7) Security and fire safety
- 8) Double bagging, proper labeling
- 9) Disposal practices

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Personal Inspection and Measurements: (Besides air samples)

The Project Monitor should personally inspect and/or measure to verify the following and maintain a daily record of this data:

- a. Visual inspection of Work Area for conformity.
- b. No breaches in the containment.
- c. Chemical smoke tests.
- d. Negative pressure within the containment of no less than 0.02 inches of water.
- e. Negative airs are not leaking or plugged and all are running at the proper flow rate.
- f. The perimeter is secure at all times
- g. The waste dumpster is locked at all times when not in immediate use and wastes are properly transported and transferred to the dumpster.
- h. All aspects of Contractor's work and site conditions are in compliance with the regulations and specifications.

5. During Work Background Air Monitoring:

a. Baseline Samples:

- 1) Approaches to the abatement areas such as hallways
- 2) Negative air exhausts
- 3) Just outside Decon

b. During Work Air Sampling:

Begin this monitoring as soon as the Decon, negative air and critical barriers are established and continue this monitoring throughout work for each work shift at the same locations specified above for baseline tests.

6. Post Abatement Testing: See pages 152-154

7. Contingency Procedures for Air Sample Non-Compliance:

a. General:

The Project Monitor should immediately notify the owner of any increase from baseline readings or findings above the stop action level of 0.010 f/cc and instruct the asbestos Contractor to stop work and implement corrective actions.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. Corrective actions should at least include the following: In approach corridors or areas:

- 1) Restrict access to the contaminated area where high fiber counts are observed to those with only full protective equipment.
- 2) Verify existing negative air operation and notify the Contractor to replace any units not properly operating.
- 3) Inspect for breaches in the containment and notify the Contractor to correct any leaks.
- 4) Instruct the Contractor to add negative air units strategically placed to suck contaminated air back from the contaminated area.
- 5) Instruct the Contractor to HEPA vacuum all surfaces in the contaminated area.
- 6) If appropriate, at an appropriate time in the work sequence, the Project Monitor should instruct the Contractor to install critical barriers around this area and extend the Work Area to be cleared by the final to include this area after performing all required final cleaning of surfaces.

b. Corrective actions should at least include the following when negative air exhausts exceed the baseline values or the stop action level:

- 1) Individual units should be tested at once to identify the defective unit. The Project Monitor should instruct the Contractor to replace the suspect units promptly and the Project Monitor shall verify the operation of the replacement unit.
- 2) Seal the defective unit in polyethylene until maintenance can be performed at an appropriate time to decontaminate the unit.

c. In the event that fiber concentrations cannot be reduced below the baseline levels or stop action level of 0.010 f/cc, the building may not be occupied until causes of this exceedance are found and corrected.

8. Final Report Preparation and Recordkeeping as detailed in Section 10-2 to follow.

B. OWNER'S RESPONSIBILITIES:

1. Specific Statutory Responsibilities of the LEA:

- a. LEA is responsible for all activities related to ACBM at their schools.
- b. The LEA must maintain records at each school and generally direct asbestos related activities.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. General Common Law and Statutory Responsibilities of Building Owners:

- a. Primary responsibility for the abatement of hazards within any structure, including asbestos.
- b. Should know that asbestos exists in a building, and that it is likely to be hazardous to those exposed to it, including their own and other's employees, tenants, outside service people and contractors, visitors and the public. The owner may be liable to any of these parties for failure to act properly or allowing any extended delay in identifying hazards or in instituting proper asbestos management and/or remediation program.
- c. Responsible for the actions of an employee while employed or an independent contractor while engaged and acting within the scope of their employment or work.
- d. Has a duty to warn persons who may be affected by the danger including possible degradation or disturbance of ACM.
- e. Owner's responsibility does not relieve tenants and outside contractor of their responsibilities including responsibility to protect its business patrons or its employees.
- f. Responsibilities of owners carry through to loan and sale transactions and to disclosure to subsequent prospective purchasers and lenders who may carry a mortgage on the property.

C. LIABILITY TYPES

1. Statutory: Violation of government regulation.

- a. Negligence
- b. Gross negligence
- c. Performing a prohibited act
- d. Conspiracy
- e. Fraud

2. Contract:

a. Nature of the Contract

- 1) May be a formal Document, a combination of a letter of proposal and a purchase order or letter of reply.
- 2) Always should include:
 - a) The scope of work
 - b) Prices of services

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

b. Breach of Contract:

- 1) means the contract is not properly performed.
- 2) Use written change orders for any changes in the work.

3. Tort:

a. A legal wrong. Requires two conditions:

- 1) Someone is aggrieved (harmed personally or financially)
- 2) Someone is responsible.

b. Anyone and everyone may be sued.

c. The likelihood and degree of adverse affect on the defendant depends on:

- 1) Following regulations
- 2) Following contract specifications
- 3) Risk contribution
- 4) Proof- documentation, witnesses and medical evidence
- 5) Degree of harm

D. INSURANCE:

1. Claims Made vs Occurrence:

- a. Claims made: Covers claims which occur and are made during the term of the contract.
- b. Occurrence: Covers incidents which occur during the policy term, regardless of when the claim is made.

2. Limits

- a. Aggregate Limit: The maximum amount of liability payable for all losses during the policy period.
- b. Single Limit: The maximum amount of liability payable for a single incident.
- c. Time Limit - Length of policy- usually renewed annually

3. Errors and Omissions Insurance (The preferred insurance for consultants)

- a. Cost- Premiums start at about \$40,000/ year plus typically 10%.
- b. Availability: Difficult.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

4. Comprehensive General Liability Insurance Policies:

- a. Property damage
- b. Premises fire, theft and injury.
- c. Automobile liability, usually combined single limit.
- d. Completed Operations- claims made after leaving the site.
- e. Damage During on-Site Operations
- f. Excludes employees and errors and omissions.
- g. Rates may be lower for consultants who have errors and omission insurance.

5. Worker's Compensation Insurance, State Mandated Liability Insurance

- a. Covers employees of the insured for job related injury or illness.
- b. Required by state law for all employee's.
- c. Owners may be exempted.
- d. Report illness or injury attributed to their work immediately.

6. Exclusions:

- a. Pollution: excludes a broad list of substances, can exclude asbestos
- b. Asbestos: policy may specifically exclude asbestos related injury.
- c. Anticipatory damage.
- d. Exclusion of coverage for employees, tenants and/or subcontractors.

7. Other Items to Investigate

- a. Best's ratings are useful. A. M. Best Company, Oldwick, NJ. 908-43902200. A+ = good company B or lower = marginal or poor company.
- b. Paperwork and reporting requirements: may be burdensome
- c. The financial stability age and stature of the insurance company
- d. Special features such as work guidelines which may be burdensome.
- e. Authorized in Connecticut.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

8. Bonding:

a. Supplement to insurance which reserves a guaranteed amount of cash to be paid in case of default.

b. Availability: More difficult to obtain than insurance and requires very complex applications and collateral.

c. Types

1) Performance bond: usually a cash amount equal to the contract sum.

2) Bid bond: Usually 5% of the bid sum.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 10-2

Record Keeping and Report Writing

- **PROJECT MONITOR FINAL REPORT PREPARATION AND RECORDKEEPING**
- **REQUIREMENTS UNDER STATE AND FEDERAL REGULATIONS:**

A. WHAT PAPERWORK COPIES THE PROJECT MONITOR MUST BRING WITH HIM TO THE PROJECT:

- 1. Project Monitor's license**
- 2. Latest refresher AHERA certificate**
- 3. Fit testing record within one year**
- 4. Medical approval within one year**
- 5. Copies of Asbestos Regulations and guidance, Company SOP's and Health and Safety Plan.**
- 6. Copy of Lab Qualifications**
- 7. Blank Forms: See samples in the handout on W.W.W.Chem-scope.com**
 - Asbestos Pre-Abatement Inspection Form FL-12A 11/97
 - Daily Perimeter Containment Monitoring Check List FL 12C 11/97
 - Daily Sign-In Sheet Form SIS 11/97
 - Final Clearance Inspection Check List FL-22V 4/20/91 (Use reverse side for Drawing)
 - Air Sampling/ NIOSH 7400 Sample Record FL-22 2/95
 - Air Sampling / Analysis by TEM AHERA FL-22T 1/95
 - Air Sampling/ OSHA ID-160 Sample Record FL-22-160 10/97
 - Respirator Instruction and Qualitative Fit-Testing Certificates If fit testing is conducted, Fit Test Record (See sample in the handout on W.W.W.Chem-scope.com.)
 - Microscope Calibration Logs For Q-21 12/9/91
 - Chain of Custody Form FL-4 1/92
 - Quality Control Report

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

B. WHAT PAPERWORK COPIES THE PROJECT MONITOR MUST COLLECT AND/OR DEVELOP AT THE PROJECT:

1. General

- a. Items marked with * The Project Monitor is responsible for having these documents on site at all times and including them in the final report preparation. They must be turned over daily to the Firm who engages the Project Monitor and copies retained on site. Finally, copies are kept and documents are turned over to the owner and, as applicable, to other contractor employers at the site.
- b. Document each step of the project include: who, what, where and when.
- c. ** indicates additional requirements for AHERA covered schools.

2. Specific EPA, DPH and OSHA Paperwork Requirements for Day 1:

- a. Before Abatement Starts, Obtain and Check Copies of Contractor's:
 - 1) DPH Notification
 - 2) Contractor asbestos license
 - 3) Daily Sign-In Sheet Form SIS 11/97: Get all abatement staff to complete and cross check paperwork for each employee vs this sheet. You can assist them in completing the cert #'s as you check their certs but make sure they ** sign it next to their printed names. Place a check on the sheet as you check the credentials. If there are any deficiencies, that individual is not to work on the project.
 - 4) Workers/supervisors AHERA training certificates complete including initial and refresher training to date.
 - a) Initial training: **Effective 4/18/90, all training must be completed within a two week period.** Supervisor must have a 40 hour approved course period. Except after September 1988 and **before 4/18/90 one could upgrade a 32 hour worker course with an Asbestos Supervisor Upgrade Course if the upgrade course was taken within 6 months of the last day of the initial course.**
 - b) Refresher training:
 - Current refresher must not have expired.
 - Refreshers must be taken every 12 months to work continuously.
 - Longest lapse between courses is 24 months; otherwise initial training must be taken over.
 - Effective 4/3/94, workers and supervisors must take the specified refresher, i.e. a worker can't take a supervisor refresher and vice-versa.
 - c) Date training was completed must be on cert **
 - d) Location of training must be on cert **

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- e) Number of hours completed must be on cert **
- 5) Fit testing records current within one year.
- 6) Medical respirator approval within the last year.
- 7) MSDS's for all chemicals brought to the site and including replacement materials (Make sure they are asbestos free). Required OSHA Hazard Communication information and training for any hazardous chemicals at this site according to CFR 29.1926.59. A list of all the hazardous chemicals to be brought to the site including amounts to be brought in, the intended use, and Material Safety Data Sheets (MSDS's) for each chemical.
- 8) Certification that vacuums, Negative Air equipment, and other local exhaust/ventilation equipment conform to ANSI Z9.2-1979.
- 9) Certification that fire safety requirements have been met or will be met. Contractor is responsible for applicable notifications, coordination regarding fire safety, alarm and sprinkler management. Emergency response plans must be determined in advance. The contractor must have provided worker fire extinguisher training according to OSHA 1926.50 (a)(5). Escape route breakthroughs and avenues of exit in the event of a fire must be visibly marked inside the containment. Fire extinguishers must be provided inside and outside the containment. Emergency lighting must be installed and properly operating.
- b. Obtain copies of any alternate work practice (AWP) requests and DPH response to the request(s).
- c. Perform a Pre-abatement Inspection
 - Use Form FL-12A and complete all items.

3. Specific EPA, DPH and OSHA Paperwork Requirements for Each Project Day:

- a. Check any new employees entering the site as in 2. a. 3) above.
- b. Daily Sign-In Sheet Form SIS 11/97 plus contractors dive sheets (time cards or daily logs of access to the Work Area, showing times of entry, exit and proof of control of the Work Area by a supervisor and daily contractor narratives).
 - 1) Signatures** vs printed names and job title or function (worker or supervisor).
 - 2) Social security number
 - 3) State and certification number and agency of initial asbestos training and current refresher.**
 - 4) Times of entry and leaving the Work Area
 - 5) Work description for each shift

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- 6) If the Project Monitor finds any of the above are missing or incomplete, he will deny access to those who are not in compliance and/ or not permit work to commence.
- c. Daily Personal Sample records for contractor and for Monitor
- d. Air Monitoring and Visual Inspection Reports Including Pre-Abatement, During Work and Finals:
- 1) Name and signature** of any person collecting any air sample on the air sample worksheet
 - 2) The locations where those samples were collected. description plus a good drawing showing sample location and identifying absolutely the location of the Work Area.
 - 3) Date and location of collection.
 - 4) Name and address of analyzing laboratory (on the lab report).
 - 5) Date of analysis (on the lab report)
 - 6) Results of analysis (on the lab report)
 - 7) Method of analysis (on the lab report)
 - 8) Name and signature** of person performing analysis (on the lab report)
 - 9) Laboratory accreditation statement** (on the lab report)
 - 10) A statement for each final clearance report as to the visible residue criterion passing or failing the inspection.
 - 11) A statement as to what suspect ACM remains in each Work Area after each final clearance.
 - 12) Air Sample Records
 - a) Must show diagram showing placement of each pump.
 - b) Documentation of final Visual inspection. Final Clearance Check list (See sample of form FL 22v in the handout on W.W.W.Chem-scope.com)
 - c) PCM: (See sample of form FL 22 in the handout on W.W.W.Chem-scope.com)
 - d) If TEM samples are collected:
 - (1) Air Sample Record for TEM samples (See sample of form FL 22 T in the handout on W.W.W.Chem-scope.com)
 - (2) Chain of custody form.
 - (3) Copy of Shipping records of samples.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

e. Project Logs and Daily Logs:

- Developing Project Logs and Daily Logs; What Should Be Included and Who Sees Them:
- Project Monitor's daily logs must include the following information for each shift:
 - 1) The date and times and description of each activity including entry to and leaving the site, contacts made, work done, etc.
 - 2) List of all asbestos personnel and function of each (can refer to the sign in sheet for that day), **Must include the project monitor's name. Even when going to a site to do a final you must sign in..**
 - 3) The names of Work Areas being worked on and the activity in each area.
 - 4) Synopsis of air sample results as to whether in or out of compliance**.

4. Final Report Assembly

- a. Assemble the above daily data in chronological order.
- b. Double Check to see that the Specification scope of work matches the actual work done and that complete paperwork is present for each day's operation. Make sure the same name for each area is used on the spec and the project work.
- c. Make sure each page is labeled with the full date and a unique project identifier. This includes each side of two- sided pages.
- d. Make sure monitor signs the logs and visual report.
- e. Prepare a synopsis of the project like this:

Site name:

The reason for the abatement was to

Contractor name and address:

Start and end date:

Summary of the scope of work completed including the quantity and exact location of ACBM removed **

Summary of what suspect ACM is left in the area

Air samples were/ were not in compliance. If not, explain why and what corrective action was taken.

Monitor name and signature.
- f. If there is no written project design, include detailed written description including Methods used for the Asbestos Abatement Project** supplement check lists with narrative as needed.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

- g. Attach all the data to the summary sheet and prepare a table of contents. Verify all data is present.
- h. Compare site copies with retain sheets kept at the shop.
- i. Turn over to the IH Firm for typing of lab reports.
- j. Add the waste disposal manifests as soon as they are available for all waste leaving the site.
- k. Copy of the specification (which for schools** also includes a copy of the Project Designer's licence and AHERA certificates.)
- l. For each Work Area, Project Monitor pre-abatement inspection report according to the Pre-abatement Check List in the handout on W.W.W.Chem-scope.com.
- m. Project Monitor's during work check list (See check list in the handout on W.W.W.Chem-scope.com).
- n. Copies of Lab credentials **:
 - 1) AIHA Accreditation Certificate for each PCM lab used.
 - 2) NIST Accreditation Certificate for each TEM lab used.
- o. DPH alternate work practice applications and approvals or rejections.
- p. Air sampling data for personals and final clearance.
- q. Certification of asbestos free replacement materials used when applicable.

5. Records must be kept for at least 30 years.

6. Supplementary Records:

- a. All correspondence related to the project
- b. Contracts, proposals, purchase orders and specifications showing the scope of work.
- c. Equipment servicing and maintenance records.
- d. Additional record keeping specified by project designer.
- e. Supplementary testing such as bulk sampling of suspect materials encountered.
- f. Photos of the Work Area setup
- g. Videos of crucial work operations such as changing HEPA filters and containment and decontamination unit set up and use.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

C. AHERA REQUIRED O&M WORK RECORDS FOR SCHOOLS:

- 1. Name of person(s) performing the activity**
- 2. Start and completion dates**
- 3. Location**
- 4. Description of activity**
- 5. If removal, the name and location of storage and disposal sites**

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Section 11

Terminology and Selective Index

Numbered Definitions are from the DPH regulations 20-440.

Underlined definitions are from the DPH asbestos standard 19a-332a-1-16; bold caps reflect new additions and line out reflect deleted text as of 4/04

(A definition which is numbered and underlined is the same in both standards.)

AAR: (Asbestos Analysts Registry, American Industrial Hygiene Association) page 158

AIHA: American Industrial Hygiene Association. Lab requirements for: pages: PLM 38; 61, 158, 173.

(1) "Accredited" or "Accreditation" when referring to an individual means that an individual has successfully completed the training requirements as set forth in subsection 20-440-6(c) of these regulations or the refresher training requirements as set forth in subsection 20-441-2 of these regulations and has been issued a document of accreditation by the training provider. Accreditation is necessary in order to obtain certification by the Department.

Accredited or Accreditation (EPA): A person or laboratory is also accredited in accordance with section 206 of Title II of the AHERA Act. Specifically this lab accreditation refers to NIST Accredited. Persons who are accredited by the DPH per the above definition are also accredited by EPA under AHERA. Other DPH regulations also specify AIHA Accredited lab. To avoid confusion in this text, we specifically say "NIST Accredited", "AIHA Accredited", etc.

Addendum: Change in work before the bid. page 85

Add-Option: Optional work itemized in the bid form which may or not be done. page 85

"Adequately wetted" means sufficiently mixed or coated with water, amended water or an aqueous solution; or the use of a removal encapsulant to prevent dust emissions;

Aggressive Sampling: Conducting Air sampling where the air is agitated before and during air sampling according to CFR 40 Part 763, Subpart E. A one-horsepower leaf blower is used to blow off the Work Area surfaces until 5 minutes before sampling pumps are started and 20 inch fans or equivalent blowers are used during sampling. pages 153-4, 173.

A.I.A.: American Institute of Architects. page 85

Airless Sprayer: pages 96, 104, 105, 115.

Airlock: A system for permitting ingress and egress while assuring air movement to a contaminated area from an uncontaminated area consists of 2 curtained doorways separated by a distance of at least 3 ft. pages 59, 96, 108, 177.

Air Monitoring: The process of measuring the fiber content of a specific volume of air in a stated period of time. See Section 7. See personal air samples, area air samples.

Alternate Work Practice (AWP): A project designer function and not detailed in this course. A variance granted by DPH allowed by Asbestos Standard. page 61.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

"Amended Water" means water to which a chemical wetting agent or removal encapsulant has been added to improve penetration;

Air-Cell (Aircell): Pipe insulation with a fibrous, air filled honeycomb center. page 74

Anemometer: Air flow measuring device. page 100

(2) **"Approved training provider"** means any individual or entity which satisfactorily demonstrates through application and submission of course agenda, faculty resumes, training manuals, examination materials, and equipment inventory that it meets the minimum requirements established by Sections 20-440-1 through 20-440-8 of the Regulations of Connecticut State Agencies;

Area samples: (pre-abatement, during work and finals) pages 151-155; locations pages 81, 154; equipment page 133; methods allowed page 145.

(3) **"Asbestos"** means the asbestiform varieties of actinolite, amosite, anthophyllite, chrysotile, crocidolite and tremolite;

(4) **"Asbestos abatement"** means the removal, encapsulation, enclosure, renovation, repair, demolition or other disturbance of asbestos-containing materials, but does not include activities which are related to (A) the removal or repair of asbestos cement pipe and are performed by employees of a water company as defined in Section 25-32a of the Connecticut General Statutes or (B) the removal of nonfriable asbestos-containing material found exterior to a building or structure other than material defined as regulated asbestos-containing material in 40 CFR 61, the national emission standards for hazardous air pollutants, as amended from time to time;

"Asbestos Abatement Project" means any asbestos abatement performed within a facility involving more than three (3) linear feet or three (3) square feet of asbestos-containing material;

"Asbestos abatement site supervisor" " means any individual ~~EMPLOYEE who is employed or engaged by an~~ **OF A LICENSED** asbestos contractor to supervise an asbestos abatement project **WHO HAS SPECIFICALLY BEEN TRAINED AS A SUPERVISOR IN A TRAINING PROGRAM APPROVED BY THE DEPARTMENT AND WHO HAS BEEN ISSUED A CERTIFICATE BY THE DEPARTMENT . ;**

"Asbestos abatement worker" means any employee of an **A LICENSED** asbestos contractor who engages in asbestos abatement; **HAS COMPLETED A TRAINING PROGRAM APPROVED BY THE DEPARTMENT AND HAS BEEN ISSUED A CERTIFICATE BY THE DEPARTMENT.**

(7) **"Asbestos-containing material" (ACM)** means material composed of asbestos of any type and in an amount greater than one percent by weight, either alone or mixed with other fibrous or nonfibrous material;

Asbestos Containing Building Material: (ACBM) Surfacing ACM, thermal system insulation ACM, or miscellaneous ACM that is found in or on interior structural members or other parts of a school building.

"Asbestos contractor" means any person or entity engaged in asbestos abatement whose employees actually perform the asbestos abatement work;

(8) **"Asbestos consultant"** means a certified and licensed individual who engages in any activity involving asbestos abatement consultation services: inspector; management planner; project designer or Project Monitor;

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

(10) "**Asbestos consultation services**" means the inspection or evaluation of a facility for asbestos hazards, including, but not limited to, the development of asbestos abatement plans, site inspections, air monitoring and the provision of industrial hygiene services related to asbestos abatement;

Asbestosis: pages 17-19.

ASTM: American Society for Testing and Materials: ASTM E 1368. Guidance on visual inspection at the completion of asbestos abatement. pages 168-169; aggressive sampling 154;

Authorized Person: Properly trained and equipped persons who are:

- 1) Employed by the asbestos contractor or consultant or
- 2) Other persons representing or working for the owner, consultant and / or asbestos contractor who may be tradesman doing class IV work or for other valid reasons.
- 3) Federal, State or local inspectors. pages 31, 32

AWP: See alternate work practice.

Base Bid: The price bid for work that is in the Scope of Work but not including any add options. page 85

Bid Opening: The deadline for bids to arrive at a specified location, and the time the bids are to be opened after. page 85

Boilers: pages 73-74; 83; 14, 15, 170.

Calibration: flow-rate pages 135-139; temperature and pressure correction pages 100-101; field pump calibration pages 146; microscope calibration pages 159.

Cassette: air monitoring filter assembly. pages 134-135; pages 146-147; reloading prohibited page 147; inspection and troubleshooting pages 136-137, 139, 155; operation pages 153, 173; TEM 153, 173.

Category 1 (NESHAP) non-friable asbestos means resilient flooring, asphalt roofing, gaskets, and packings > 1% asbestos by PLM. page 24.

Category 2 (NESHAP) non-friable asbestos means any other non-friable material with > 1% asbestos by PLM. page 24.

Ceilings: pages 77-79, 84, 108.

(13) "**Certificate** ,, means a document issued by the department indicating that the individual has satisfied training requirements and any other applicable requirements of the department;

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

(14) "**Certified**" or "**Certification**" when referring to an individual means that a certificate has been issued by the department under the provisions of Sections 20-4401 through 20-440-8 of the Regulations of Connecticut State Agencies to an individual upon successful completion of an approved training or refresher training course, the receipt of a document of accreditation issued by the training provider and the fulfillment of any other requirements of the department. Certification is required for employment as either an asbestos abatement worker or asbestos abatement site supervisor and is a condition for licensure as an asbestos consultant. Asbestos consultant disciplines for which certification may be issued include: inspector, management planner, project designer and Project Monitor;

Celsius: .C = degrees Celsius. Temperature scale formerly known as Centigrade. To convert from Celsius to Fahrenheit: $.F = (1.8) (.C) + 32$; To convert from Fahrenheit to Celsius:
 $.C = (.F-32) (0.56)$;

deg Kelvin = deg Celsius + 273

CFM: Cubic feet per minute. Volume moving past a reference point per unit time. pages 100-101; HEPA vacuum page 94; calculation pages 98, 102, 141; negative air pages 101; PAPR page 119; supplied air page 121; see also SCFM.

Change order: A change in the work after the contract signing. This is the owner's acknowledgement of extra or less work to be done which differs from the original contract. "Add-on" or "extra". pages 85, 92.

Cilia: Hair-like projections that line the bronchial tubes. pages 18, 19

Class I Work, Class II Work, Class III Work, Class IV Work:
 OSHA pages 30-56, definition: page 31.

Clean Room: = Clean change room. An uncontaminated area or room which is a part of the Worker Decontamination Enclosure with provisions for storage of worker's street clothes and protective equipment. See Decon.

(15) "**Commissioner**" means the commissioner of the Connecticut Department of Public Health;

Crawl spaces: A confined space, usually at basement or attic level, where one can't normally stand erect. pages 154, 74, 105.

Competent Person: OSHA assessment pages 33, 40-41; inspect protective clothing page 34; required on Class I job 42; evaluate transite and roofing removal pages 44-46; asbestos definition and requirements; job site inspection page 52; scaffold erection pages 161-162.

CONES: Consortium of North East States: CT, MA, VT, RI, NH, VT, and NJ. page 68.

Critical Barrier: The last layer of plastic sheeting separating Work Areas from non Work Areas. pages 107, 57.

Curtained Doorway: A device to allow passage from one room to another while permitting minimal air movement between the rooms, typically constructed by placing two overlapping sheets of plastic over an existing or temporarily framed doorway, securing each along the top of the doorway, securing the vertical edge of one sheet along one vertical side of the doorway, and securing the vertical edge of the other sheet along the opposite vertical side of the doorway. Two curtained doorways spaced a minimum of six (6) feet apart form an Airlock.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Decontamination Enclosure System Decon or: A series of connected rooms, with Curtained Doorways between any two (2) adjacent rooms, for the decontamination of workers and of materials and equipment. A Decontamination Enclosure System always contains at least one Airlock. Construction pages 34, 108; entry and exit-OSHA pages 35-6, DPH page 58; OSHA exterior pages 34-35, 44-46; DPH notification when shower not contiguous 57; DPH requirements page 58; combined requirements page 96; during precleaning page 106; equipment decon 108; use of protective suits page 128-129; remote shower page 34. Also called worker decontamination unit or enclosure.

Demarcation including Signs: OSHA page 31.

Demolition (DPH) means the wrecking or taking out of any load-supporting structural member of a facility ~~and any related razing, removing or stripping of asbestos~~ **TOGETHER WITH ANY RELATED HANDLING OPERATIONS OR THE INTENTIONAL BURNING OF ANY FACILITY**

Demolition (NESHAP) means any work involving taking out load supporting building members or intentional burning. page 24.

DEP: CT Dept of Environmental Protection: page 70.

DPH: or (16) "Department" means the Connecticut Department of Public Health;

DOT: US Department of Transportation pages 69-70.

(17) **EPA** means the United States Environmental Protection Agency.

Electrical Safety: pages 77, 110, 161; OSHA variance for water 42; fire 49, 82; OSHA regulations cited page 51; upgrade page 83; sampling page 152.

"Emergency Asbestos Abatement Project" means an asbestos abatement project which was not planned but results from a sudden unexpected event. This includes operations required by non-routine failures of equipment;

Emergency response: pages 116-118; 53, 81.

Encapsulant (sealant): a liquid material which can be applied to Asbestos-Containing Material and which controls the possible release of Asbestos fibers from the material either by creating a membrane over the surface (bridging encapsulant or be penetrating into the material and binding its components together (penetrating encapsulant). Any such encapsulants must be in conformance with Building and/or Fire Safety Code requirements. See encapsulation.

Encapsulation: An abatement option; all procedures necessary to apply an encapsulant to Asbestos-containing building materials to control the possible release of Asbestos fibers into the ambient air. pages 104-105, 59.

Enclosure, to enclose: A method. An asbestos abatement option involving surrounding ACM with an airtight barrier. page 105.

Enclosure (s): Synonym for Containment. Also refers to the abatement Work Area containment system which includes plastic enclosures such as the worker decontamination enclosure, the equipment decontamination enclosure, the Work Area enclosure.) See also negative pressure enclosure, mini-enclosure. Flooring work page 44; outdoors page 44; DPH requirements pages 57, 107; construction of page 107; maintenance of page 109.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Equipment Decontamination Enclosure: That portion of a Decontamination Enclosure System (Decon) designed for controlled transfer of materials and equipment, typically consisting of a Washroom and a Holding area. See Decon.

Equipment Room: A contaminated area or room which is part of the Worker Decontamination Enclosure with provisions for storage of contaminated clothing and equipment. See Decon.

Exemptions: OSHA for unspecified methods page 43; OSHA for class II work page 44.; DOT page 69; consultant licence page 9; OSHA labeling page 39. See also Alternate work practices, wet methods.

Excursion Limit: (EL) OSHA 30 minute exposure standard of 1.0 fibers/cc. pages 157, 32, 143, 148, 149.

(18) "**Facility**" means the interior and exterior of any private or public building or structure including but not limited to those used for institutional, residential (including single family homes), commercial or industrial purposes and vessels while ashore or in dry dock;

(19) "**Facility owner**" means the person having title to the facility. For purposes of publicly owned property only, the facility owner shall be defined to be the chief executive officer of the federal, state or municipal agency which owns or controls the use of the facility;

Exterior: page 44 OSHA; page 79; ACM pages 71-72, 80; see also roofing.

(18) "**Facility**" means the interior and exterior of any private or public building or structure including but not limited to those used for institutional, residential (including single family homes), commercial or industrial purposes and vessels while ashore or in dry dock;

(19) "**Facility owner**" means the person having title to the facility. For purposes of publicly owned property only, the facility owner shall be defined to be the chief executive officer of the federal, state or municipal agency which owns or controls the use of the facility;

Fibrous Aerosol Monitors (FAM): page 133

Field blanks: pages 146, 147, 140, 158, 173.

Final Clearance: (final reoccupancy testing): pages 153-156; 173-175; EPA recommendation 28; DPH lab requirements 60, 67; failed 107, 153, 156, 158; sampling method 134; PCM criteria 141, 144; TEM criteria 143, 144; methods allowed 146, 152; records 188..

Fire safety: pages 162-163, 117-118; 49, 51, 82, 116, 130.

Fixed Object: A unit of equipment or furniture in the Work Areas which cannot be removed from the Work Area. pages 57, 106.

Friable ACM: EPA- An Asbestos Material that can be crumbled, pulverized or reduced to powder when dry by hand pressure and which releases Asbestos fibers into the environment. page 60, shipment, RACM page 24.

(20) "**Friable asbestos-containing material**" means any asbestos-containing material that hand pressure can crumble, pulverize, or reduce to powder when dry and non-friable asbestos-containing material that potentially can be broken, crumbled, pulverized or reduced to powder as a result of asbestos abatement.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Flooring ACM: construction pages 13, 24, 38, 79; abatement pages 44, 84; visual after abatement page 170; maintenance page 47; dirt floor page 171.

GFCI: Ground fault circuit interrupter. A device designed to shut off the current in milliseconds before injury can occur

"Glove Bag" means a manufactured polyethylene bag type of enclosure with built-in gloves, such as is placed with an air-tight seal around asbestos- containing material and which permits the asbestos-containing material contained by the bag to be removed without releasing asbestos fibers to the atmosphere;

Health and Safety Plans: pages 51-55 Lead compliance page 51; respiratory protection 53, emergency response page 53, hazard communication page 55; medical surveillance page 55.

Heat related disorders: 163-164.

HEPA Filter: A high efficiency particulate air (HEPA) filter in compliance with ANSI Z9.2-1979. page 98.

HEPA Vacuum Equipment: Vacuum equipment with a HEPA filter system for filtering the air effluent from the unit. pages 94-95, 98.

(21) "High-efficiency particulate air (HEPA)" means a filtering system capable of trapping and retaining at least 99.97 percent of all monodispersed particles 0.3 micrometer in diameter or larger;

Holding Area: A chamber in the Equipment Decontamination Enclosure located between the Washroom and an uncontaminated area. The Holding area comprises an Airlock. See Decon.

(22) HVAC means heat, ventilation and air conditioning; pages 75-76; 83; 11, 45, 46, 81. 110, 117, 165.

(23) "Individual" means any human being;

(24) "Inspector" means any licensed individual who identifies, assesses the condition of, or collects bulk samples of suspected asbestos-containing material;

Kelvin: .K = Absolute temperature scale. 0.K is absolute zero and is the theoretical temperature in outer space. deg Kelvin = deg Celsius + 273.

Ladder safety: page 160.

Latency Period: pages 16-17, 20.

LEA: Local Education Agency;

Lead: Dust on asbestos jobs: pages 166-167; lead compliance plan page 51.

(25) "License" means a document issued by the department authorizing an asbestos contractor to engage in asbestos abatement work or an asbestos consultant to engage in any activity directly involved with asbestos consultation services. Licensure shall be restricted pursuant to the limitations of each discipline. See pages 62-67.

Liquidated damages: A penalty, usually daily, the contractor pays when the completion of the job is not in compliance, usually because it is not on schedule. page 85

Lock-down: Final spray after abatement using an encapsulant. pages 114, 116; interference in air samples page 156, visual pages 170, 172.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Lung Cancer: pages 17-19.

(26) "**Management planner**" means any licensed individual who uses data gathered by asbestos inspectors to assess asbestos hazards, determine-responses and develop implementation plans;

Manometer: pressure/flow measuring device. pages 99, 42, 137, 141.

MagnahelicR Gauge pressure/flow measuring device. page 99

Man-Made Mineral Fibers: page 20.

MCE: Mixed cellulose ester. Polymer used for air sampling filters.

Medical Surveillance: OSHA requirements page 36.

Mercury: Toxic liquid element used in fluorescent lights, thermometers, barometers (atmospheric pressure gauges) and elsewhere. Use pages 99, 164;

mm: Millimeter. 0.001 meter.

mm of mercury atmospheric pressure pages 100, 133, 138, 139. (mm of mercury) (0.565) = inches of water.

Mesothelioma: Rare form of cancer. pages 17-19, 28.

Mini-Enclosure or Mini-Containment: A small full containment. pages 43, 46, 107.

Miscellaneous Material: ACM or ACBM other than surfacing or TSI, such as transite, floor and ceiling tiles, roofing, mastics, tars, putties, glues, caulks, preformed sheets, etc. page 15, sampling page 38; paint page 78.

Movable Object: A unit of equipment or furniture in the Work Area which can be removed from the Work Area.

MSDS: Material Safety Data Sheet. page 48-50.

Negative Air Units or Negative Pressure Exhaust Ventilation: A portable local exhaust system equipped with HEPA filtration used to create negative pressure in a contaminated area (negative with respect to adjacent uncontaminated areas) and capable of maintaining a constant discharge of filtered air outside and creating suction so that air flow direction moves from uncontaminated areas into the Work Areas. pages 59, 94, 98, 102, 172, 178; certification 186; measuring flow pages 99-100, 102, 141; locations page 103; monitoring 103; cleanup page 114; troubleshooting finals pages 157, 179; troubleshooting high baseline airs page 179.

Negative initial exposure assessment (NEA): pages 41-42, 55.

Negative Pressure Enclosure = or negative pressure containment): pages 31, 42, 44, OSHA Specs page 43, monitoring pages 99, 103.

Negative Pressure Respirators: pages 33, 36, 119, 123-127.

(27) "**NESHAP**" asbestos regulations (40 CFR 61, Subpart M) means National Emission Standard for Hazardous Air Pollutants;

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

NIST: National Institute of Standards and Technology: PLM pages 12, 21, 29, 38; TEM 28, 173, 189;

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

NIOSH: National Institute for Occupational Safety and Health.

NIOSH 582: Required 5 day training course for PCM analysts. page 158.

NIOSH 7400 method: page 145, 47, 140, 143, 153.

(28) "Non-friable asbestos-containing material" means any asbestos-containing material that hand pressure cannot crumble, pulverize or reduce to powder when dry; See also Category 1, 2.

Notification: DPH pages 56-57; EPA pages 24-25; OSHA requirements pages 39-40; to OSHA 43; DPH fees page 43; DEP page 70, fire marshal page 82.

O&M: Operations and Maintenance pages 106, 46, 191.

(29) OSHA means the Occupational Safety and Health Administration of the United States Department of Labor;

OSHA Method ID-160: Microscopic method that only counts asbestos fibers, (Same as the method in Appendix B of 1926.1101) may be used for samples other than final samples. pages 32, 140, 143, 145, 149; baseline monitoring page 157.

PACM: Presumed ACM (OSHA) page 38.

PAPR: Powered air purifying respirator. pages 119, 123.

PAT: Proficiency Analytical Testing program. See AIHA.

PCB'S: Polychlorinated biphenyls. Highly toxic oils used in transformers and fluorescent light ballasts. Ballasts or transformers which do not say "PCB free" should be treated as PCB containing. Must be disposed of as Hazardous Waste; contact DEP for a list of Licensed Hazardous Waste contractors to be contacted for disposal instructions.

PCM: phase contrast microscopy. pages 143-145, 153, 139, 149, 158; DPH standard page 172; qualifications page 173.

Permissible Exposure Limit (PEL): for asbestos OSHA Standard. The employer must ensure that no employee is exposed to an airborne concentration of Asbestos, tremolite, anthophyllite, actinolite, or a combination of these materials is excess of the PEL of 0.1 fibers per cubic centimeter of air as an eight (8) hour time weighted average (TWA), or in excess of 1 fiber/cubic centimeter as a 30- min excursion limit as determined by the method prescribed in Appendix A to OSHA Regulations 29 CFR 1926.1101, or by an equivalent method. (See TWA). PEL's exist for other substances and are listed in CFR 29 1910.1000, subpart Z.

(30) "Person" means any individual, corporation, partnership, firm, association, sole proprietorship, the State of Connecticut or any of its political subdivisions, or any other entity;

Personal Samples: Air samples collected in breathing zone. pages 145-147, 149; methods page 32, 140; flow rate page 47; calculations page 156.

Photohelic^R gauge: page 99

Pipes: ACM on pages 73-76, 13, 15, 83

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Plasticize: To cover floors and walls with plastic sheeting as specified in the DPH regulations in Section 4. pages 107, 58.

PLM: Polarized light microscopy. The method used for determining if materials are asbestos containing. More than 1% asbestos found by this method proves a material is ACM under all the asbestos regulations. pages 12, 21, 24; AIHA pages 38; 140, 144, 145.

Poly: Short for polyethylene (plastic) sheet.

PPE: personal protective equipment pages 128-131

Presumption of asbestos: OSHA page 38.

Protection factor (respirator): calculation pages 122; 126, 127.

(31) "**Project designer**" means any licensed individual who determines how asbestos abatement work should be conducted and who prepares for purposes of an abatement project, plans, designs, procedures, workscope or other substantive direction or criteria;

(32) "**Project monitor**" means any licensed individual who functions as an on-site representative of the facility owner or other persons by over-seeing the activities of the asbestos abatement contractor. Scope of license and qualifications page 65; enforcement responsibilities pages 89, 93, 175-177; pre-cleaning page 106; analyst page 140; visuals and finals pages 168-174; measurements besides air samples page 178; corrective action page 179; paperwork pages 184-190. See other individual topics by subject.

PSIG: Pounds per square inch gauge pressure. Gauge pressure automatically zeros out the normal atmospheric pressure of about 14.7 PSI or about 760 mm of mercury. Compressor and supplied air pages 119-121.

Quality assurance: pages 158-159; interlab participation requirement 47.

RACM: NESHAP regulated ACM. page 24.

Records: DPH required page 57; OSHA record retention page 37; notifications disclosed to owner page 40; air sampling & calculations page 139, 146; combined DPH/EPA/OSHA pages 185-189; AHERA/O&M page 190; forms in the handout on W.W.W.Chem-scope.com.

Regulated Area: OSHA Page 31.

"Removal" means the taking out or stripping of any asbestos-containing materials from surfaces or structural components of a facility;

"Renovation" means altering, in any way other than demolition, one or more structural components. Operations in which load-supporting structural members are taken out are excluded;

Renovation (NESHAP) means altering a facility component in any way including stripping of asbestos. pages 24.

"Repair" means the restoration of damaged asbestos-containing material; including but not limited to the sealing, patching, enclosing or encapsulating of damaged asbestos-containing material to prevent fiber release; DPH/EPA Procedures page 60; Class III OSHA 31, 46.

CHEM SCOPE PROJECT MONITOR TRAINING **Updated 4/2/10**

Respirator: A device used to protect against inhalation hazards. pages 119-127

(33) "**Response action**" means a method, including removal, encapsulation, enclosure, repair and operation and maintenance that protects human health and the environment from ACM;

Roofing: pages 14, 15, 22, 24, 38; OSHA requirements pages 44-45.

Rotometer: flow measuring device. page 99

Scaffold safety: pages 161-162.

SCFM: Standard cubic feet per minute. CFM corrected to standard conditions of pressure and temperature, i.e., 760 mm of mercury and 70 degrees F. pages 100-101, 141; compressor page 119; see also CFM.

School: Any elementary or secondary school as defined in section 198 of the Elementary and Secondary Education Act of 1965 (20 U.S.C. 2854). AHERA pages 21-22; DPH pages 61, 67; Finals pages 144, 146, 154, 174, 180; abatement records pages 186-190; O&M work page 191, see also O&M. (see school building).

School Building:

1. Any structure suitable for use as a classroom, including a school facility such as a laboratory, library, school eating facility, or facility used for the preparation of food.
2. Any gymnasium or other facility which is specially designed for athletic or recreational activities for an academic course in physical education.
3. Any other facility used for the instruction or housing of students or for the administration of educational or research programs.
4. Any maintenance, storage, or utility facility, including any hallway, essential to the operation of any facility described in this definition of School Building under paragraphs (1), (2), or (3).
5. Any portico or covered exterior hallway or walkway.
6. Any exterior portion of a mechanical system used to condition interior space.

Shower Room: A room between the Clean Room and the Equipment Room in the Worker Decontamination Enclosure with hot and cold or warm running water and suitably arranged for complete showering during decontamination. The Shower Room comprises an Airlock between contaminated and clean areas. See Decon. pages 34-36, 96, 108, 111; exception to contiguous page 36; outdoors page 44; OSHA regs page 51; procedures page 58; use until final clearance page 172.

Soap Bubble Buret: primary calibration standard. pages 137-138; 135; 139.

Synergistic effect: Combination of more than one hazard multiplies the risk of disease. page 20

(34) "**Spot repair**" means any asbestos-abatement activity involving not more than three (3) linear feet or three (3) square feet of asbestos-containing material;

Static pressure: pages 99, 101.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Stripping: Taking of Asbestos materials from any surface.

"Structural Component" means any pipe, duct, boiler, tank, reactor, turbine, furnace or other component at or in a facility or any structural member of a facility;

"Structural Member" means any load-supporting member of a facility such as beams and load-supporting walls or any non-load supporting member, such as ceilings and non-load supporting walls;

Supplied air respirator: pages 119-121; Class I work pages 33, 42.

Surfacing Material: Material in a building that is sprayed-on, troweled-on, or otherwise applied to surfaces, such as acoustical plaster on ceilings and fireproofing materials on structural members, or other materials on surfaces for acoustical, fireproofing, or other purposes. Includes sheetrock locations page 11; OSHA Class I page 31, OSHA Class IV page 36, presumption of ACM/testing page 38; no exemption page 39; glove bag page 46; drill and cut page 46; construction page 77; spray on page 79; vs encapsulation page 104.

Surfactant: A chemical wetting agent added to water to improve penetration. See amended water.

Transite: Hard gray ACM sheet or tubing. pages 13, 14, 44; exterior removal pages 77, 78, 79, 81, 105.

TEM: Transmission Electron Microscopy: see also final clearance. pages 142-143; EPA recommendation page 28; EPA/DPH Standards pages 60, 145, 172, 173; filters page 134; collection pages 141, 153, 173.

TSI = Thermal System Insulation: Material in a building applied to pipes, fittings, boilers, breeching, tanks, ducts or other interior structural components to prevent heat loss or gain, or water condensation, or for other purposes.

(35) **"TSCA"** means Title II of Toxic Substance Control Act, 15 U.S.C. 2641 et seq. page 21

TWA: Time weighted average: calculation page 156.

Type C respirator:(see Supplied air respirator: pages 119-121;

Unit price: The charge per given unit of work such as dollars per man hour, per square foot, etc. page 85

Vaneometer: Sensitive air flow measuring device page 100.

Variances: See wet cleaning, alternate work practices, exemptions.

Velocity pressure: page 99

"Visible Residue" means any debris or dust on surfaces in areas within the enclosed work area where asbestos abatement has taken place and which is visible to the unaided eye. All visible residue is assumed to contain asbestos;

Walls: Plasticization pages 58, 108; construction page 78; demolition page 84.

Washroom: A room between the Work Area and the Holding Area in the Equipment Decontamination Enclosure with provisions for storage of contaminated clothing and equipment. Synonym of shower.

CHEM SCOPE PROJECT MONITOR TRAINING**Updated 4/2/10**

Waste Disposal: pages 114-117; manifests page 26; water page 58; DOT label page 70; DEP page 70; containers page 97; EPA required bagging page 113, labels page 113; respirators and suits page 129.

Wet Cleaning, Wet Methods: The process of eliminating Asbestos contamination from building surfaces and objects by using cloths, mops, or other cleaning tools which have been dampened with amended water, and by afterwards disposing of these cleaning items as Asbestos contaminated waste. page 112; wet methods exemptions OSHA pages 42, 44, 45, 46; DPH/EPA/OSHA: page 112.

"Work Area" means the specific area or location where the actual asbestos abatement work is being performed or such other areas of a facility which the Commissioner determines may be hazardous to public health as a result of such asbestos abatement.

Worker Decontamination Enclosure System: That portion of a Decontamination Enclosure System designated for controlled passage of workers, and other personnel and authorized persons; typically consisting of a Clean Room, a Shower Room, and an Equipment Room. See Decon.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

CHEM SCOPE

8 HOUR REFRESHER TRAINING
ASBESTOS PROJECT MONITOR

COURSE PROGRAM

<u>TIME</u>	<u>TOPIC</u>
7:45- 8:00 AM	REGISTRATION & PRE-COURSE QUIZ
8:00-10:00	COURSE INTRODUCTION AND OVERVIEW ROLE AND RESPONSIBILITIES OF THE PROJECT MONITOR CHARACTERISTICS OF ASBESTOS AND ACM POTENTIAL HEALTH EFFECTS OF ASBESTOS EXPOSURE ASBESTOS REGULATIONS
10:00-10:15	BREAK
10:15-11:15	ASBESTOS REGULATIONS (CONT)
11:15- 12:00	FACILITY CONSTRUCTION AND SYSTEMS CONTRACTS, SPECIFICATIONS AND DRAWINGS ENFORCEMENT RESPONSIBILITIES OF PROJECT MONITOR ASBESTOS ABATEMENT EQUIPMENT, RESPONSE ACTIONS AND ABATEMENT PRACTICES PERSONAL PROTECTIVE EQUIPMENT
12:00-12:30	LUNCH
12:30-1:45	AIR MONITORING
1:45-2:00	BREAK
2:00-2:45	SAFETY/HEALTH ISSUES BESIDES ASBESTOS CONDUCTING VISUAL INSPECTIONS LEGAL RESPONSIBILITIES AND LIABILITIES RECORDKEEPING ASSEMBLING THE FINAL REPORT
2:45-3:15	COURSE REVIEW
3:15-4:00	EXAMINATION

CHEM SCOPE PROJECT MONITOR TRAINING

Updated 4/2/10

CHEM SCOPE 40 HOUR INITIAL TRAINING: ASBESTOS PROJECT MONITOR

COURSE PROGRAM

DAY #1

<u>TIME</u>	<u>TOPIC</u>
7:45- 8:00 AM	REGISTRATION
8:00-10:00	PRE-COURSE QUIZ COURSE INTRODUCTION AND OVERVIEW ROLE AND RESPONSIBILITIES OF THE PROJECT MONITOR CHARACTERISTICS OF ASBESTOS AND ACM
10:00-10:15	BREAK
10:15-11:00	POTENTIAL HEALTH EFFECTS OF ASBESTOS EXPOSURE
11:00-12:00	ASBESTOS REGULATIONS EPA REGULATIONS
12:00-12:30	LUNCH
12:30-2:00	EPA ASBESTOS REGULATIONS (CONT) OSHA REGULATIONS
2:00-2:15	BREAK
2:15-4:00	OSHA REGULATIONS (CONT) DPH REGULATIONS OTHER REGULATIONS

CHEM SCOPE PROJECT MONITOR TRAINING**Updated 4/2/10****CHEM SCOPE****40 HOUR INITIAL TRAINING: ASBESTOS PROJECT MONITOR****COURSE PROGRAM****DAY #2**

<u>TIME</u>		<u>TOPIC</u>
8:00-9:00		FACILITY CONSTRUCTION AND SYSTEMS
9:00-10:00		CONTRACTS, SPECIFICATIONS AND DRAWINGS ENFORCEMENT RESPONSIBILITIES OF PROJECT MONITOR
10:00-10:15	BREAK	
10:15-12:00		ASBESTOS ABATEMENT EQUIPMENT, RESPONSE ACTIONS AND ABATEMENT PRACTICES
12:00-12:30	LUNCH	
12:30-1:45		PERSONAL PROTECTIVE EQUIPMENT
1:45-2:00	BREAK	
2:00-4:00	HANDS-ON	WORKSHOP A CONTRACTS, SPECIFICATIONS AND DRAWINGS

CHEM SCOPE PROJECT MONITOR TRAINING**Updated 4/2/10****CHEM SCOPE****40 HOUR INITIAL TRAINING: ASBESTOS PROJECT MONITOR****COURSE PROGRAM****DAY #3**

<u>TIME</u>		<u>TOPIC</u>
8AM-9:45 AM		AIR MONITORING
9:45-10:00	BREAK	
10:00-12:00		AIR MONITORING (CONT)
12:00-12:30	LUNCH	
12:30-1:45		AIR MONITORING (CONT)
1:45-2:00	BREAK	
2:00-4:00	HANDS-ON	WORKSHOP B AIR MONITORING STRATEGIES AND ABATEMENT EQUIPMENT OPERATION AND CALIBRATION OF SAMPLING PUMPS SET UP NEGATIVE AIR, DECON, CRITICAL BARRIERS OVER OPENINGS MEASURE PRESSURE AND AIR FLOW

CHEM SCOPE PROJECT MONITOR TRAINING

Updated 4/2/10

CHEM SCOPE

40 HOUR INITIAL TRAINING: ASBESTOS PROJECT MONITOR

COURSE PROGRAM

DAY #4

<u>TIME</u>	<u>TOPIC</u>
8:00-8:45	SAFETY/HEALTH ISSUES BESIDES ASBESTOS
8:45-9:45	CONDUCTING VISUAL INSPECTIONS
9:45-10:00	BREAK
10:00-12:00	WORKSHOP C, INTERACTIVE VIDEO CONDUCTING VISUAL INSPECTIONS
12:00 - 12:30	LUNCH
12:30- 1:45	LEGAL RESPONSIBILITIES AND LIABILITIES
1:45-2:00	BREAK
2:00-4:00	WORKSHOP PERSONAL PROTECTIVE EQUIPMENT, FIT TESTING

CHEM SCOPE PROJECT MONITOR TRAINING**Updated 4/2/10****COURSE PROGRAM****40 HOUR INITIAL TRAINING: ASBESTOS PROJECT MONITOR
DAY #5**

<u>TIME</u>		<u>TOPIC</u>
8:00-9:45		RECORDKEEPING
9:45 - 10:00	BREAK	
10:00-11:30		RECORDKEEPING (CONT) ASSEMBLING THE FINAL REPORT
11:30-12:00	LUNCH	
12:00-2:00		COURSE REVIEW
2:00-2:15	BREAK	
2:00-3:00		COURSE REVIEW (CONT)
3:00-4:00		EXAMINATION

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Negative Exposure Assessment Summary Form:

1. Are the present crew and supervision at least as experienced and competent as prior crews/supervisors? ____
2. Do the process, conditions, materials, work practices of the historical jobs cited, closely resemble the present job being evaluated? ____
3. Does any days monitoring results indicate a mean TWA (8 hr) greater than 0.05 f/ cc for any employee? ____
4. Does any days monitoring results indicate a single EL value (30 min) greater than 0.5 f/ cc for any employee? ____
5. What training does the Competent Person performing this evaluation have: AHERA training as contractor/supervisor: ____ project designer ____ or inspector management planner course ____.
 Does the Competent Person meet the requirements in 1926.32: "one who is capable of identifying existing and predictable hazards in the surroundings or working conditions which are unsanitary, hazardous, or dangerous to employees, and who has authorization to take prompt corrective measures to eliminate them." ____
6. What is expected employee exposures during the job: PEL is ____ is not ____ statistically less than 0.1 f/cc. EL is ____
 is not ____ statistically less than 1 f/cc.
7. Are all control systems appropriate for the operation and will they work properly? ____

To confirm this, complete a Preabatement Inspection of the actual work setup using the attached 2 page form.

Conclusion: After consideration of all observations, information and calculations which indicate employee exposure to asbestos, including any previous monitoring: There is ____ is not ____ a high degree of certainty that employee exposures are likely to be below the PEL and EL using the processes and practices outlined above for this job.

Recommendations: Workers will use a minimum of _____ NIOSH approved HEPA filtered respirators for this job.

Negative Initial Exposure Assessment? Yes ____ No: ____

_____/_____
 Competent Person Print Name Competent Person Signature/date

Attach Personal Monitoring Data for the Present Job: (PEL and EL) when available.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

Field Air Monitoring Job Description

1. Site Monitoring:

- a. Obtain job information, check equipment and provide personal transportation.
- b. Perform Asbestos abatement site supervision and air monitoring*
- c. Pre-abatement inspection to ensure the asbestos Work Area is properly prepared (using smoke tubes and air flow measurement techniques) according to the regulations and also according to the job specifications and collection of required contractor's paperwork (employee certs, notifications, alternate work practices, etc. Ensuring that contractors supervisor certificates are posted on the job.*
- d. During work monitoring ensuring that asbestos contractor is performing in compliance with the regulations and specifications and collecting copies of required contractor's paperwork including and ensuring results are posted on site. Collecting area samples for PCM analysis at least at Decon entries and negative air exhausts.*
- e. Final Air Clearance visual inspection and aggressive final samples collected by PCM or TEM as required by regulations.
- f. Test PCM samples on site or at lab as required for the job.
- g. See that TEM samples are properly transported to the TEM laboratory in the time frame required for the job.
- h. Complete paperwork at job site to the extent possible.
- i. Fit testing of clients and collection of personal air samples. Note client is to provide his own personal air sampling pumps unless otherwise specifically instructed by supervisor. (Check with the office for billing information on this or other extra work requested).
- j. Bringing paperwork, samples and slides to the lab and completing as needed and placing in proper locations. *

* See check list on standard forms and the Project Monitor Manual procedures.

CHEM SCOPE PROJECT MONITOR TRAINING
Updated 4/2/10

2. QC/QA duties:

- a. Maintain scope calibration records including entries in scope log.
- b. Inspect scope and kit before and after use.
- c. Test reference samples
- d. Place all completed slides in individual racks at lab and place cassettes in lab sample storage box.
- e. 10 % recounts

3. Equipment and supplies maintenance:

- a. Responsible for maintenance and safety checking of all issued equipment and having all needed supplies.
- b. Report any defects or missing equipment to supervisor at once.
- c. Purchase any routine supplies when needed and not available at shop and include in expense report.
- d. Report any supplies shortages at lab so that material can be ordered.

4. Maintenance of professional requirements

- a. Responsible for timely taking of required annual refresher courses, annual medicals and fit testing every year.
- b. Responsible for maintaining participation in AAR program

5. Compliance with regulations: At all times the incumbent must conduct himself in accordance with regulations. This includes having, maintaining and properly using personal protective equipment, reporting any deficiencies, and maintaining copies of certifications, fit tests, medical fitness and Chemical Hygiene Plan including respirator program Hazard Communication Program, MSDS's with person at all times during work assignments.